THE STATE OF

State of New Mexico **Energy Minerals and Natural Resources**

For drilling and production facilities, submit to appropriate NMOCD District Office
For downstream facilities, submit to Santa Fe

Form C-144

June 1 2004

Oil Conservation Division 1220 South St. Francis Dr. Santa Fe, NM 87505 Pit or Below-Grade Tank Registration or Closure

ohone. <u>505-623-4735</u> e-mail address <u>jennifer@m</u>	-grade tank AUG 0 3 2007 nckayorl com OCD-ARTESIA		
75-63788 U/L or Qtr/Qtr_FSec_12	T 68 P 225		
NAD 1927 ☐ 1983 ☐ Surfa			
Below-grade tank			
Volumebbl Type of fluid: Construction material Double-walled, with leak detection? Yes If not, explain why not.			
Less than 50 feet	(20 points)		
50 feet or more, but less than 100 feet	(10 points)		
100 feet or more	(0 points)		
Yes	(20 points)		
<u>No</u>	(0 points)		
Less than 200 feet	(20 points)		
200 feet or more, but less than 1000 feet	(10 points)		
1000 feet or more	(0 points)		
Ranking Score (Total Points)	0		
Yes If yes, show depth helow ground surface_ons			
est of my knowledge and belief I further certify the state of the stat			
Signature Jahry			
s not relieve the operator of liability should the content of the operator of its responsibility for compliance w			
Signature Signed By Mile &	AUG 0 6 2007		
to be constructed es are to be obtained mitted to OCD Minsmum 3' (Llean topsoil to be enfire excavated area		
	NAD 1927		

Reserve Pit Remediation Plan

LL&E C Federal #3 1500'FNL & 2180'FWL Sec. 12, T6S, R22E

- 1. Collect soil samples from the walls of the reserve pit as shown on attached plat (from surface to depth reading 250 ppm chlorides).
- 2. Pile cuttings and original pit liner to one side of reserve pit.
- 3. Collect soil samples from inside the pit on the cleared side of reserve pit (trench area) at surface.
- 4. Dig trench in cleaned out side of the pit, big enough to put all of the cuttings in and leave enough room for 3' backfill material. (NOTE: Trench size depends on amount of cuttings, rock formations, surrounding terrain and mud solidity.)
- 5. Collect soil samples from inside trench area to a depth reading 250 ppm chloride.
- 6. Line trench with 20 MIL liner.
- 7. Fill the trench with cuttings and original pit liner.
- 8. Cap trench with 20 MIL liner.
- 9. Collect soil samples from points within the reserve pit (not including the trench area which were collected in Step 5) as shown on attached plat from surface to depth reading 250 ppm chlorides.
- 10. Back fill area (trench -3' and reserve pit -1') with topsoil.
- 11. Seed area per BLM specifications.

LL&E C FEDERAL # 3 1500' FNL AND 2180' FWL Sec. 12, T6S, R22E

