Submit 3 Copies To Appropriate District State of New Mexico Form C-103 Office • Energy, Minerals and Natural Resources May 27, 2004 District I WELL API NO. 1625 N. French Dr., Hobbs, NM 88240 District II 30-015-22563 OIL CONSERVATION DIVISION 1301 W. Grand Ave., Artesia, NM 88210 5. Indicate Type of Lease 1220 South St. Francis Dr. District III STATE 🖂 1000 Rio Brazos Rd, Aztec, NM 87410 Santa Fe, NM 87505 6. State Oil & Gas Lease No. District IV 1220 S St. Francis Dr., Santa Fe, NM 87505 L-3647 SUNDRY NOTICES AND REPORTS ON WELLS 7. Lease Name or Unit Agreement Name (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH Siegrest JS State Com PROPOSALS.) 8. Well Number 1. Type of Well: Oil Well Gas Well 2. Name of Operator 9. OGRID Number Yates Petroleum Corporation 025575 JAN 28 2008 3. Address of Operator 10. Pool name or Wildcat 105 S. 4<sup>th</sup> Street, Artesia, NM 88210 OCD-ARTESIA Dagger Draw; Wolfcamp, West 4. Well Location 660 North line and 1980 Unit Letter feet from the feet from the West line 30 Township 19S Range 24E **NMPM** Section Eddy County 11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3813'GR Pit or Below-grade Tank Application or Closure Pit type Depth to Groundwater Distance from nearest fresh water well Distance from nearest surface water Below-Grade Tank: Volume bbls; Construction Material Pit Liner Thickness: mil 12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF: PERFORM REMEDIAL WORK □ REMEDIAL WORK П ALTERING CASING □ COMMENCE DRILLING OPNS.□ TEMPORARILY ABANDON CHANGE PLANS PLUG AND ABANDON ☐ П PULL OR ALTER CASING П MULTIPLE COMPL CASING/CEMENT JOB  $\Box$ OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion. Yates Petroleum Corporation plans to plug and abandon this well as follows: 1. Rig up safety equipment as needed. 2. Set a 5-1/2" CIBP at 6174' with 35' cement on top. 3. Shoot squeeze holes as follows: 3768', 1703', 964' and 100'. 4. Spot a 100' (35 sx) cement plug inside and outside the casing from 3668'-3768'. ~ 7~5 Notity OCD 24 hrs. prior 5. Spot a 100' (35 sx) cement plug inside and outside the casing from 1603'-1703'. 6. Spot a 100' (35 sx) cement plug inside and outside the casing from 864'-964'. Tag plug. To any work done. 7. Install a 5-1/2" casing swedge and spot a 100' cement plug to surface. Tag plug. 8. Cut off wellhead and install marker and clean up location as per regulated. NOTE: Yates Petroleum Corporation will use steel pits and no earth pits I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or belowgrade tank has been/will be constructed or closed according to NMOCD guidelines , a general permit or an (attached) alternative OCD-approved plan.



