

Submit 3 Copies To Appropriate District Office
District I
1625 N. French Dr., Hobbs, NM 88240
District II
1301 W. Grand Ave., Artesia, NM 88210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

RM Form C-103
June 19, 2008

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO. 30-015-29778
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. VB-183
7. Lease Name or Unit Agreement Name Experimental State
8. Well Number 1
9. OGRID Number 245872
10. Pool name or Wildcat Scanlon; Delaware

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well ☐ Gas Well ☐ Other ☐

2. Name of Operator
Judah Oil, LLC

3. Address of Operator
P.O. Box 568 Artesia, NM 88211-0568

4. Well Location
Unit Letter N : 660 feet from the South line and 1650 feet from the West line
Section 2 Township 21S Range 28E NMPM County Eddy

11. Elevation (Show whether DR, RKB, RT, GR, etc.)
GR 3306

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☒ PLUG AND ABANDON ☐
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐
DOWNHOLE COMMINGLE ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ P AND A ☐
CASING/CEMENT JOB ☐

OTHER: Csg repair ☐

OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

5-11-09 Possible hole in csg

Top of cement behind 4 1/2 is 5100' Temp survey.

5-12-09 Propose MIRU PU, POOH w/ Rods, NU BOP and test to 5000#, POOH with 2 3/8 tbg, RIH w/ RBP and packer, Set RBP @ 5230 +/-, Test plug to 2000 #, Locate hole in 4 1/2 csg, Set packer above hole and establish circulation, Pump enough cement to circulate to surface, let set for 24 hrs, bump plug, Drill out cement and test csg to 500#. RIH and retrieve RBP, RIH w/ tbg, rods and pump. Put on production.

Spud Date:

Rig Release Date:

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE James B Campanella TITLE member/manager DATE 5-14-2009

Type or print name James B Campanella E-mail address: judahoil@yahoo.com PHONE: 575-746-1280
For State Use Only

APPROVED BY: Angie Bear TITLE Geologist DATE 5/18/2009
Conditions of Approval (if any):