

Submit 3 Copies To Appropriate District
Office
District I
1625 N. French Dr., Hobbs, NM 87240
District II
1301 W. Grand Ave., Artesia, NM 88210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

JUL 17 2009

Form C-103
May 27, 2004

WELL API NO. 30-015-00903
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. B-10456
7. Lease Name or Unit Agreement Name: EMPIRE ABO UNIT 'R'
8. Well Number 6
9. OGRID Number 00778
10. Pool name or Wildcat EMPIRE ABO

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well <input checked="" type="checkbox"/> Gas Well <input type="checkbox"/> Other <input type="checkbox"/>	2. Name of Operator BP America Production Company
3. Address of Operator P.O. Box 1089 Eunice NM 88231	4. Well Location Unit Letter <u>F</u> : <u>1650</u> feet from the <u>N</u> line and <u>1650</u> feet from the <u>W</u> line Section <u>16</u> Township <u>18S</u> Range <u>27E</u> NMPM County <u>EDDY</u>
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3484' GR	
Pit or Below-grade Tank Application <input type="checkbox"/> or Closure <input type="checkbox"/> Pit type _____ Depth to Groundwater _____ Distance from nearest fresh water well _____ Distance from nearest surface water _____ Pit Liner Thickness: _____ mil Below-Grade Tank: Volume _____ bbls; Construction Material _____	

12. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

- MIRU PU. Check tbq, csg and surface pipe for pressure - bleed off into containment. Kill well as necessary.
- Monitor well and assure it is stable. ND WH, remove tubing joint/sub, NU BOP. Test BOP and casing to 500 psi.
- TIH with bull plug and perf nipple on 2 3/8" work string to CIBP/cement at 5433'. Circulate hole with mud-laden fluid (9 ppg, 1250# gel/100 bbl).

Continued on page 2.

I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or below grade tank has been/will be constructed or closed according to NMOCD guidelines ☐ , a general permit ☐ or an (attached) alternative OCD-approved plan ☐

SIGNATURE Barry C. Price TITLE Area Operations Team Lead DATE 7/15/09
Type or print name Barry C. Price E-mail address: barry.price@bp.com Telephone No. 575-394-1648

For State Use Only

APPROVED BY [Signature] TITLE Approval Granted providing work is complete by 10/17/09 DATE 7/17/09
Conditions of Approval, if any:

NO NMOCD 24 hrs. prior to any work done

Form C-103
Empire Abo Unit R-6
30-015-00903
Continued from Page 1

4. TOH to 3150' (Glorieta top = 3029'). Spot 250' balanced cement plug from 3150' – 2900' using 25 sx Class C neat. PU to 2500' and WOC 2 hours minimum. Tag Glorieta plug and record depth on daily report; re-spot if necessary.
5. TOH to 1560' (surface casing shoe = 1511', Queen top = 782'). Fill 4 ½" casing from 1560' to surface with 110 sx Class C neat (estimated, pump until good cement returns). TOH LD tubing.
6. If necessary, fill casing with cement to 3' below ground level after LD tubing.
7. RD PU.
8. Dig out WH and cut-off casingheads to 3' below GL.
9. Install regulation dry-hole marker. Clean location and prepare for NMOCD inspections.

TD 5700'

TD 5700'