bmit 3 Copies To Appropriate District State of New Mexico Form C-103 Office Energy, Minerals and Natural Resources May 27, 2004 District I WELL API NO. 1625 N. French Dr., Hobbs, NM 88240 District II 30-015-34143 OIL CONSERVATION DIVISION 1301 W. Grand Ave., Artesia, NM 88210 Indicate Type of Lease District III 1220 South St. Francis Dr. STATE 🖂 FEE 1000 Rio Brazos Rd., Aztec, NM 87410 Santa Fe, NM 87505 State Oil & Gas Lease No. District IV 1220 S. St. Francis Dr., Santa Fe, NM 87505 SUNDRY NOTICES AND REPORTS ON WELLS 7. Lease Name or Unit Agreement Name (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH Willow State PROPOSALS.) 8. Well Number 1. Type of Well: Oil Well Gas Well Other 007 2. Name of Operator 9. OGRID Number 229137 COG Operating LLC 3. Address of Operator 10. Pool name or Wildcat 550 W. Texas Ave., Suite 1300 Midland, TX 79701 Fren: Glorieta-Yeso 26770 Well Location Unit Letter 330 feet from the South line and 330 feet from the East line Section Township 17S Range 31E **NMPM** County Eddv 11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3841 GR Pit or Below-grade Tank Application ☐ or Closure ☐ Depth to Groundwater Distance from nearest fresh water well Distance from nearest surface water Pit Liner Thickness: mil Below-Grade Tank: Volume bbls; Construction Material 12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF: PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON П REMEDIAL WORK ☐ ALTERING CASING \Box TEMPORARILY ABANDON ☐ CHANGE PLANS COMMENCE DRILLING OPNS. □ PANDA П PULL OR ALTER CASING ☐ MULTIPLE COMPL \Box CASING/CEMENT JOB П DOWNHOLE COMMINGLE П \boxtimes OTHER: \Box OTHER: Deepen 13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion. RECEIVED See Attached procedure OCT 29 2010 NMOCD ARTESIA **SIGNATURE** - TITLE Regulatory Analyst DATE 10/28/2010 Type or print name Natalie Krueger E-mail address: <u>nkrueger@conchoresources.com</u> PHONE: 432-221-0300 For State Use Only DATE 11/1/ 2010 APPROVED BY: Conditions of Approval (if any):

COG Operating, LLC Willow State No. 7 API# 30-015-34143 P-16-17S-31E 330 FSL & 330 FEL Eddy Co, NM

Deepening Procedure

- 1. MIRU rig.
- 2. Sqz upper Yeso w/ +/- 400 sx of Class C neat. Drill out squeeze.
- 3. PU 4-3/4" bit and drill 4-3/4" hole from 5325' to 6700'.
- 4. POOH w/ bit and drillstring.
- 5. RIH w/ logs and log from TD to 4900'.
- 6. RIH w/ 4", 11.3# casing. See section 11 for general centralizer program.
- 7. Cement casing from TD to 5261' w/ 120 sxs Class C cmt. Drop plug and open DV tool. Circ cmt off DV tool. Drop plug to close DV tool.
- 8. PU workstring and RIH and drill out DV tool. POOH and LD workstring.
- 9. RDMO rig.

Completion Procedure

- 1. MIRU rig.
- 2. RIH/ w/ perforating guns and perforate Yeso from 6100 6300 w/ 2 spf, 30 holes.
- 3. Acidize w/ 2500 gals of 15% HCl. Frac zone w/ 179,800 # of sand. Set plug at 6050'.
- 4. RIH w/ perforating guns and perforate Yeso from 5800' 6000'.
- 5. Acidize w/ 2500 gals of 15% HCl. Frac zone w/ 179,800 # of sand. Set plug at 5750'.
- 6. RIH w/ perforating guns and perforate Yeso from 5500' 5700'.
- 7. Acidize w/ 2500 gals of 15% HCl. Frac zone w/ 179,800 # of sand.
- 8. RIH and drill out plug at 5750' and 6050'.
- 9. RIH and cut or back off 4" casing at 5261'. POOH w/ 4" casing. Leave 4" liner from 5261' to 6700' (TD).
- 10. RIH w/tbg and locate end of tbg at 5210'.
- 11. RiH w/ rods and pump.
- 12. RDMO rig.