

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLI
(Other instructions on
reverse side)

5. LEASE DESIGNATION AND SERIAL NO.
N.M. - 0400030

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME
Clark

9. WELL NO.
1

10. FIELD AND POOL, OR WILDCAT
Linda San Andres

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA
S 4, T 7 S, R 26 E

12. COUNTY OR PARISH
Chaves

13. STATE
N. M.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back into different reservoirs.)
Use "APPLICATION FOR PERMIT" for such proposals.)

MAR 28 1977

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR
H.E. Prince

3. ADDRESS OF OPERATOR
P. O. Box 129, Roswell, New Mexico, 88201

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface
Unit letter F - 1666.5' from N. line
1657.6 from W. line

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, OR, etc.)
3609 G R

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

16. NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF <input type="checkbox"/>	PULL OR ALTER CASING <input type="checkbox"/>	WATER SHUT-OFF <input type="checkbox"/>	REPAIRING WELL <input type="checkbox"/>
FRACTURE TREAT <input type="checkbox"/>	MULTIPLE COMPLETE <input type="checkbox"/>	FRACTURE TREATMENT <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
SHOOT OR ACIDIZE <input type="checkbox"/>	ABANDON* <input type="checkbox"/>	SHOOTING OR ACIDIZING <input type="checkbox"/>	ABANDONMENT* <input checked="" type="checkbox"/>
REPAIR WELL <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	(Other) <input type="checkbox"/>	

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Plug and abandon as follows:

Well depth 1074'

Run 15 sacks of cement from 1074' back to 892.10

Cut casing at 675.50' from surface

Run mud from 892.10 back to 155'

Run 100' cement plug 50' in and 50' out to surface pipe.

Run mud from 55' back to 10'

Run cement to surface and set marker.

Clean debris from site.

RECEIVED

AUG 13 1976

U. S. GEOLOGICAL SURVEY
ARTESIA, NEW MEXICO

POSTED
ID
4-1-77

18. I hereby certify that the foregoing is true and correct

SIGNED H.E. Prince TITLE Owner DATE 8/10/76

(This space for Federal or State office use)

TITLE _____ DATE _____

APPROVED

CONDITIONS OF APPROVAL, IF ANY:

MAR 20 1977

R. L. McNEEL
ACTING DISTRICT ENGINEER

*See Instructions on Reverse Side