

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION

P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	<input checked="" type="checkbox"/>
FILE	<input checked="" type="checkbox"/>
U.S.G.S.	
LAND OFFICE	<input checked="" type="checkbox"/>
OPERATOR	<input checked="" type="checkbox"/>

AUG 01 1983

O.C.D.

ARTESIA OFFICE

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
LG-0158	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT - " (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Pace Exploration, Inc. <input checked="" type="checkbox"/> H.D. Pace	8. Farm or Lease Name Barnburner
3. Address of Operator P.O. Box 588, Artesia, N.M. 88210	9. Well No. #1
4. Location of Well UNIT LETTER <u>L</u> <u>660</u> FEET FROM THE <u>West</u> LINE AND <u>1980</u> FEET FROM THE <u>South</u> LINE, SECTION <u>16</u> TOWNSHIP <u>8S</u> RANGE <u>26E</u> N.M.P.M.	10. Field and Pool, or Wildcat Wildcat S.A.
15. Elevation (Show whether DF, RT, GR, etc.) GL 3783.3 KB 3793.30	12. County Chaves

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐

PLUG AND ABANDON ☐
CHANGE PLANS ☐
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOBS ☐
OTHER ☐
ALTERING CASING ☐
PLUG AND ABANDONMENT ☒

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

7-12-83 Pull retrievable bridge plug @1458', TIH to 1500' pump 25 bbls mud, with wireline set CIBP @1400', dump bail 35' cement, set CIBP @430', dump bail 35' cement.

7-19-83 Load inside and outside 4½" csng w/mud laden fluid.

7-21-83 With wireline service, tag top fluid @26', top cement @392', 38' cement on top CIBP @430', set CIBP @70', dump bail cement to surface - run 2½ cu. yds. ready mix cement outside 4½" csng. Erected dry hole marker and cut off tie downs.

Post ID-2
8-10-84
P+H

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>WTB Notes</u>	TITLE <u>President</u>	DATE <u>07/22/83</u>
APPROVED BY <u>DR. LARRY BROOKS</u> GEOLOGIST - NMCD	TITLE _____	DATE <u>11/15/83</u>
CONDITIONS OF APPROVAL, IF ANY:		