

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

dsf
up

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

P.O. Box 2088
Santa Fe, New Mexico 87504-2088

JUL 23 1992

O. C. D.

WELL API NO.
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. L-6812
7. Lease Name or Unit Agreement Name Pennzoil "A" State
8. Well No. 1
9. Pool name or Wildcat S. Pecos Slope
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3765 GR

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER
2. Name of Operator El Ran, Inc.
3. Address of Operator P.O. Box 911, Lubbock, TX 79408
4. Well Location Unit Letter J : 1980 Feet From The south Line and 1980 Feet From The east Line Section 16 Township 9-S Range 26-E NMPM Chaves County
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3765 GR

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Plug At
3360-3460

Mud between
All Plugs

1. Set CIBP at 4250' and spot 35' cement plug on top.
2. Perforate 4 1/2" casing at 2125' (top of Glorietta formation).
3. Run 2 3/8" x 4 1/2" cement retainer at 2075' and pump 50 sacks of Class "C" Neat cement. Dump 2 sacks of cement on top of retainer.
4. Load hole with mud.
5. Perforate 4 1/2" casing at 982'.
6. Run 2 3/8" x 4 1/2" cement retainer at 932' and pump 50 sacks of Class "C" Neat cement. Dump 2 sacks of cement on top of retainer.
7. Load hole with mud.
8. Spot 15 sacks of cement at surface and set up P.A. marker.

Notify N.M.O.C.C. in sufficient time to witness

Plugging

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Jerry R. Hseng

TITLE Engineering Manager

DATE 7/21/92

TYPE OR PRINT NAME

TELEPHONE NO. 806/763-4091

(This space for State Use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY: