
	~ *
Submit 3 Copies To Appropriate District State of New Mexico	Form C-103
Office District I Energy, Minerals and Natural Resources	Revised March 25, 1999
1625 N. French Dr., Hobbs, NM 88240	WELL API NO.
District II 811 South First, Artesia, NM 88210 OIL CONSERVATION DIVISION	30005-61110 5. Indicate Type of Lease
District III 2040 South Pacheco 1000 Rio Brazos Rd., Aztec, NM 87410	STATE FEE
District IV 2040 South Pacheco, Santa Fe, NM 87505	6. State Oil & Gas Lease No.
	7 I N II i A
SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A	7. Lease Name or Unit Agreement Name:
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	Twin Lakes San Andres Unit
1. Type of Well:	
Oil Well Gas Well Other Injection 2. Name of Operator	7. Well No.
Concho Oil & Gas Corp.	97 97
3. Address of Operator	8. Pool name or Wildcat
110 W. Louisiana Ste 410; Midland, Tx 79701 4. Well Location	Twin Lakes; San Andres (Assoc)
4. Well Education	
Unit Letter C: 330 Feet from the North line and 1650 feet to	rom the West line
Section 8 Township 9S Range 29E	NMPM Chaves County
10. Elevation (Show whether DR, RKB, RT, GR, etc.	
3922.7 GR 11. Check Appropriate Box to Indicate Nature of Notice, F	Conort or Other Data
	SEQUENT REPORT OF:
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK	ALTERING CASING
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐ COMMENCE DRIL	LING OPNS. DPLUG AND
PULL OR ALTER CASING MULTIPLE CASING TEST AN	ABANDONMENT
COMPLETION CEMENT JOB	
OTHER: OTHER:	
12. Describe proposed or completed operations. (Clearly state all pertinent details, and gi	
of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach or recompilation.	wellbore diagram of proposed completion
Concho Oil & Gas Corp. respectfully requests approval to plug and aband	on the TLSAU #97 well according to
the following procedure:	
1. Notify NMOCD Artesia 24 hrs prior to commencement of procedure.	
2. Set 150' cmt plug @ 2770 -2920'. WOC. Tag. 3. Circ hole w/ mud.	
4. Set 100' cmt plug @ 2125-2225'.	
5. Cut csg 1755' & POOH.	
6. Set 100' cmt @ 1705-1805'. WOC. Tag.	
7. Set 100' cmt plug @ 1070-1170'.	
8. Circ cmt from 180' to surface.9. Cut off wellhead & install dry hole marker.	
9. Cut on weinicad & instant dry note marker.	
I hereby certify that the information above is true and complete to the best of my knowledge	and helief
Thereby copy that his thiormation above is true and complete to the best of my knowledge	and benef.
SIGNATURE TITLE <u>Production Analys</u>	DATE 9-28-01
Type or print name Terri Stathem Telephone No. 91546	83 -/1 443
· · · · · · · · · · · · · · · · · · ·	
(This space for State use) APPPROVED BY TITLE	DATE 10-10-01

TLSAU #97

Formerly - O'Brien GG #2



Original Perf Details: P1: 2820.5, 21, 21.5, 29, 29.5, 30, 42, 42.5, 43, 43.5, 47.5, 48, 48.5, 51, 51.5, 52

8000 gals 28% acid

May-88 Add P1: 2816, 17, 18, 24, 25, 26, 36, 37, 38, 39, 40, 41, 45, 46

Add P2: 2878-2895'

Acdz'd P2 only w/ 1500 gals 20%

Put on injection