

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

N. M. Oil Cons. Division
811 S. 1ST ST.
ARTESIA, NM 88210-2834

FORM APPROVED
Budget Bureau No. 1004-0133
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

Grynberg Petroleum Company

3. Address and Telephone No.

5000 S. Quebec St., Suite 500, Denver, CO 80237 (303) 850-9790

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1980 FSL, 660 FWL, Sec 12, T6S-R24E

5. Lease Designation and Serial No.

USA-NM-11795

6. If Indian, Allottee or Tribe Name

NA

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Hobbs Canyon Fed #3

9. API Well No.

30-005-61455

10. Field and Pool, or Exploratory Area

Pecos Slope Abo

11. County or Parish, State

Chaves, NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other _____
☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Plan to P&A well as follows: Procedure revised 2-29-96

1. Set CIBP @ approx. 3450'.
2. Dump 35' cement on top with bailer.
3. Lay cement plug in 4½ casing from 1550 to 1450. (Bond log cement top is 1442'.)
4. Perforate 4½ casing @ 908' and squeeze 60 sax plug into 4½ x 10 3/4 annulus; OR Cut 4½ casing below 10 3/4 shoe and lay cement plug from 960' to 860'. WOC and feel for plug.
5. Lay surface plug in 10 3/4 casing below ground and install dry hole marker.
7. Contour and re-seed location.

Wellbore sketch attached.

14. I hereby certify that the foregoing is true and correct

Signed K.R. Williams

Title Engineer

Date 2-29-96

(This space for Federal or State office use)

Approved by _____

Title _____

Date _____

Conditions of approval, if any: _____