

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

NOV 19 1992

A.C.D.
ARTESIA OFFICE

WELL API NO.
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. L-6811
7. Lease Name or Unit Agreement Name Pennzoil SL
8. Well No. #1
9. Pool name or Wildcat

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER
2. Name of Operator El Ran, Inc. ✓
3. Address of Operator P.O. Box 911, Lubbock, TX 79408
4. Well Location Unit Letter B Feet From The 990 Line and north Feet From The 1980 Line Section 16 Township 9S Range 26E NMPM Chaves County
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3771 GL

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
PLUG AND ABANDON <input checked="" type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>
OTHER: <input type="checkbox"/>	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set CIBP@ 4250'. Spot 35' cement plug on top.
2. Set plug @ 3460' - 3360' w/ 25sks. Load hole w/ mud.
3. Perforate 4 1/2" csg @ 2125' (top of Glorietta)
4. Run 2 3/8" of 4 1/2" cement retainer @ 2075' and pump 50 sks of Class C Neat cement. Dump 2 sks of cement on top of retainer.
5. Load hole w/ mud. Perforate 4 1/2" csg @ 875'.
6. Run 2 3/8" of 4 1/2" cement retainer @ 825' and pump 50 sks of Class C Neat cement. Dump 2 sks on top of retainer.
7. Load hole w/ mud.
8. Spot 15 sks of cement @ surface and set P&A marker..

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Kay McCain TITLE Production Analyst DATE 11/16/92

TYPE OR PRINT NAME Kay McCain TELEPHONE NO. 806/763-4091

(This space for State Use)

APPROVED BY [Signature] TITLE Field Asst DATE 11/24/92

CONDITIONS OF APPROVAL, IF ANY: