

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

N.M. Oil Cons. Division
811 S. 1st Street
Artesia, NM 88210-2834

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT--" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

YATES PETROLEUM CORPORATION

3. Address and Telephone No.

105 South 4th St., Artesia, NM 88210

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1980' FSL & 660' FWL of Section 15-T9S-R26E (Unit L, NWSW)

5. Lease Designation and Serial No.

NM-28171

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Spear OA Federal #3

9. API Well No.

30-005-62079

10. Field and Pool, or Exploratory Area

Foor Ranch Wolfcamp

11. County or Parish, State

Eddy Co., NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment Ordovician
☒ Recompletion Wolfcamp
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other
☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Propose to temporarily abandon perforations 5922-6094' (Ordovician) and recomple to Wolfcamp as follows:

1. Kill well with 2% KCL. Load the backside. Nipple down wellhead and nipple up BOP.
2. Unseat packer and TOOH with tubing and packer.
3. Set RBP at 5878'. Load hole with 2% KCL and test casing and RBP to 500 psi. POOH with tubing.
4. Perforate 5020-5392' (Wolfcamp), acidize as necessary for production.
5. Swab/flow test.
6. If Wolfcamp will produce, place well into production.
7. If Wolfcamp is not productive, decision will be made whether to return to Ordovician perforations or to Temporarily Abandon well.

14. I hereby certify that the foregoing is true and correct

Signed

Rusty Klen

Title Operations Technician

Date Oct. 18, 1999

(This space for Federal or State office use)

(ORIG. SGD.) DAVID R. GLASS

Approved by

Title

PETROLEUM ENGINEER

Date

OCT 20 1999

Conditions of approval, if any: