

Submit 3 Copies To Appropriate District Office

District I
1625 N. French Dr., Hobbs, NM 88240

District II
811 South First, Artesia, NM 88210

District III
1000 Rio Brazos Rd., Aztec, NM 87410

District IV
2040 South Pacheco, Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION
2040 South Pacheco
Santa Fe, NM 87505

Form C-103
Revised March 25, 1999

WELL API NO.
30-005-62635

5. Indicate Type of Lease

STATE ☐ FEE ☒xx

6. State Oil & Gas Lease No.

7. Lease Name or Unit Agreement Name:
LE 6

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

Oil Well ☒xx Gas Well ☐ Other

2. Name of Operator
Jalapeno Corporation

8. Well No. 1

3. Address of Operator
P. O. Box 1608 Alburquerque, New Mexico 87103-1608

9. Pool name or Wildcat
Racetrack San Andres

4. Well Location

Unit Letter O 330 feet from the South line and 2310 feet from the East line

Section 6 Township 10S Range 28E NMPM Chaves County

10. Elevation (Show whether DR, RKB, RT, GR, etc.)
3824.5 GR.

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒xx

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

* 25 sack cement plug 2187'-2087' TAG or CIBPW/35' cement D 2187'

- 1) Set 25 sack plug from 1615' to 1695' to cover top of San Andres and tag.
- 2) Fill hole with mud and cut casing.
- 3) Set 35 sack plug across casing stub and tag.
- 4) Set 35 sack plug from 1000' to 1100' to cover top of Queen.
- 5) Set 35 sack plug from 215' to 315' to cover base of surface casing. TAG
- 6) Set ten sack plug at surface and set dry hole marker.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE J. A. Gustamantes TITLE Production Supervisor DATE Feb. 7, 2000

Type or print name J. A. Gustamantes Telephone No. 505-347-2375

(This space for State use)

APPROVED BY mae Stillfield TITLE Field Rep. II DATE 2/24/2000
Conditions of approval, if any:

* Notice given to witness Plugging Operations