

151
DP

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

P.O. Box 2088
Santa Fe, New Mexico 87504-2088

MAR 27 '89

O. C. D.

| |
|---|
| WELL API NO. 30-005-62639 |
| 5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/> |
| 6. State Oil & Gas Lease No. |
| 7. Lease Name or Unit Agreement Name Mustang |
| 8. Well No. #1 |
| 9. Pool name or Wildcat Wildcat - Montoya |

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

| | |
|---|---|
| 1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/> | 2. Name of Operator Fred Pool Drilling, Inc. |
| 3. Address of Operator P.O. Box 1393, Roswell, NM 88202-1393 | |

4. Well Location
Unit Letter G 1980 Feet From The North Line and 1980 Feet From The East Line

Section 11 Township 6S Range 27E NMPM Chaves County
10. Elevation (Show whether DF, RKB, RT, GR, etc.)
4056 GR

| | |
|---|---|
| 11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data | |
| NOTICE OF INTENTION TO: | SUBSEQUENT REPORT OF: |
| PERFORM REMEDIAL WORK <input type="checkbox"/> | REMEDIAL WORK <input type="checkbox"/> |
| TEMPORARILY ABANDON <input type="checkbox"/> | ALTERING CASING <input type="checkbox"/> |
| PULL OR ALTER CASING <input type="checkbox"/> | COMMENCE DRILLING OPNS. <input type="checkbox"/> |
| OTHER <input type="checkbox"/> | PLUG AND ABANDONMENT <input type="checkbox"/> |
| | CASING TEST AND CEMENT JOB <input type="checkbox"/> |
| | OTHER <input type="checkbox"/> |

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- We intend to P & A the subject well as follows:
- 1) Set CIBP at 4850' with 35' of cement on top of it.
 - 2) Spot 100' cement plug inside 5½" at 4700', top of ABO.
 - 3) Shoot of 5½" casing at 4280' (top of cement by CBL) and pull 5½" casing.
 - 4) TIH with tubing and spot 200' cement plug accross top of stub of 5½" casing, 50' in and 50' out.
 - 5) Spot 100' cement plug accross top of Glorieta, 2550'.
 - 6) Spot 100' cement plug accross shoe of 8 5/8" casing at 1352', 50' in and 50' out.
 - 7) Spot 50' plug and surface.
 - 8) Install regulation dry hole marker.
 - 9) All plugs will be class "C" with salt gel between plugs.

25sx plug at 350'

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Fred F. Pool, III TITLE Engineer DATE 3/24/89
TYPE OR PRINT NAME Fred F. Pool, III TELEPHONE NO. 623-8202

(This space for State Use) *As noted above

APPROVED BY Johnny Robinson TITLE OIL AND GAS INSPECTOR DATE 3-29-89

CONDITIONS OF APPROVAL, IF ANY:

Notify N.M.O.C.C. in sufficient time to witness

Plugging