

Submit 3 Copies To Appropriate District
Office
District I
1625 N. French Dr., Hobbs, NM 88240
District II
811 South First, Artesia, NM 88210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
1220 S. St. Francis Dr., Santa Fe, NM
87505

State of New Mexico
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

Form C-103
Revised March 25, 1999

WELL API NO.

30-005-62594

5. Indicate Type of Lease

STATE ☒ FEE ☐

6. State Oil & Gas Lease No.

VA-2071

7. Lease Name or Unit Agreement Name:

Window AWT State

7. Well No.

#1

8. Pool name or Wildcat

Wildcat Glorieta

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-103) FOR
PROPOSALS.)

1. Type of Well:

Oil Well ☐ Gas Well ☐ Other ☒

2. Name of Operator

Yates Petroleum Corporation

3. Address of Operator

105 S. 4th Street Artesia, NM 88210

4. Well Location

Unit Letter E : 1980 feet from the North line and 660 feet from the West line

Section 10 Township 10S Range 26E NMPM Chaves County

10. Elevation (Show whether DR, RKB, RT, GR, etc.)

3839' GR

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

PLUG AND ABANDON ☐

TEMPORARILY ABANDON ☐

CHANGE PLANS ☐

PULL OR ALTER CASING ☐

MULTIPLE
COMPLETION ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐

ALTERING
CASING ☐

COMMENCE DRILLING OPNS. ☐

PLUG AND
ABANDONMENT ☒

CASING TEST AND
CEMENT JOB ☐

OTHER: ☐

Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation. 3/15/02 - MIRU pulling unit.

3/18/02 - Put 35' cement on top of CIBP at 5900'. Set CIBP at 5510' and cap with 35' cement.

Perforate 4 squeeze holes at 2400' to squeeze cement behind 4" csg. Set cement retainer at 2350'.

3/19/02 - Pumped 200 sxs Pecos Valley Lite through retainer at 2350'. Circ 3 bbls.

3/21/02 - TIH and tagged cement at 1870'. Clean out to 2350'.

3/22/02 - Run CBL. TOC 700'. Perforate Glorieta 2254-2260' with 24 holes, .38". Swab test.

3/27/02 - Received verbal permission to plug and abandon and plugging instructions from Van Barton with Artesia OCD. Plugged well as follows:

Set CIBP at 2190', capped with 35' cement to cover the Glorieta perms.

TIH with tbg open ended to 2150'. Set neat cement plug 2150-1000' to cover the 5-1/2" casing shoe at 2000' and the 8-5/8" casing shoe at 1130'. WOC 3 hours. TIH and tag cement at 910'.

Perforate 4 squeeze holes at 60'. Circulate cement down 4" csg and up 5-1/2" csg to surface.

Well is plugged and abandoned - final report.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

TITLE

Engineering Technician DATE April 8, 2002

Type or print name

Susan Hagan

Telephone No. 505-748-1471

(This space for State use)

APPROVED BY

TITLE

MAY 23 2002

Conditions of approval, if any: