

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-79

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

DEC 11 1980

O.C.D.

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
L-5070	
7. Unit Agreement Name	
8. Farm or Lease Name	
Bolderheli	
9. Well No.	
1	
10. Field and Pool, or Wildcat	
Wildcat	
12. County	
De Baca	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT - " (FORM C-101) FOR SUCH PROPOSALS.)

OIL WELL <input type="checkbox"/>	GAS WELL <input type="checkbox"/>	OTHER- Dry Well
1. Name of Operator		
McClellan Oil Corporation ✓		
2. Address of Operator		
Post Office Drawer 730, Roswell, New Mexico 88201		
3. Location of Well		
UNIT LETTER	D	660 FEET FROM THE North LINE AND 660 FEET FROM
THE West	LINE, SECTION 36	TOWNSHIP 3-S RANGE 26-E NMPM.

15. Elevation (Show whether DF, RT, GR, etc.)
3805 G.L.

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK	<input type="checkbox"/>
TEMPORARILY ABANDON	<input type="checkbox"/>
PULL OR ALTER CASING	<input type="checkbox"/>
OTHER	<input type="checkbox"/>

PLUG AND ABANDON	<input checked="" type="checkbox"/>
CHANGE PLANS	<input type="checkbox"/>
OTHER	<input type="checkbox"/>

REMEDIAL WORK	<input type="checkbox"/>
COMMENCE DRILLING OPNS.	<input type="checkbox"/>
CASING TEST AND CEMENT JOBS	<input type="checkbox"/>
OTHER	<input type="checkbox"/>

ALTERING CASING	<input type="checkbox"/>
PLUG AND ABANDONMENT	<input type="checkbox"/>
OTHER	<input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Will plug and abandon well following proposed procedure:

- Pull 4½" casing from 3700' to surface.
 - Set 150' Class C plug from 4090' to 4240' (CIBP set at 4240').
 - Set 100' Class C plug from 3650' to 3750' inside and out of 4½" casing.
 - Set 100' Class C plug across Glorieta from 1900' to 2000'.
 - Set 100' Class C plug from 1150' to 1250' inside and out of the 8-5/8" casing **stay*
 - Set 100' Class C plug from 100' to surface and install dry hole marker.
- Note: Salt gel mud will be placed between all plugs.
- Clean location of debris and fill and level all working pits and restore surface to as near as possible to original condition.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED	<u>Paul Raglsdale</u>	TITLE	Engineer	DATE	12/09/80
APPROVED BY	<u>W.A. Gressett</u>	TITLE	SUPERVISOR, INSTRUCTION	DATE	DEC 12 1980
CONDITIONS OF APPROVAL, IF ANY:					
* as noted above					
Note: N.M.O.C.C. is sufficient cause to witness					
<u>Plugging</u>					