

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

AUG 20 1981

O. C. D.
ARTESIA, OFFICE

Form C-103
Revised 12-1-79

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
LG 7545

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT TO DRILL" (FORM C-101) FOR SUCH PROPOSALS.)

OIL WELL <input type="checkbox"/>	GAS WELL <input checked="" type="checkbox"/>	OTHER <input type="checkbox"/>
Name of Operator		
TERRA OF NEW MEXICO, INC. 303-799-3311		
Address of Operator		
7409 South Alton Court - Suite 210, Englewood, Colorado 80112		
Location of Well		
UNIT LETTER <u>N</u> <u>2452</u> FEET FROM THE <u>West</u> LINE AND <u>650</u> FEET FROM		
THE <u>South</u> LINE, SECTION <u>25</u> TOWNSHIP <u>10S</u> RANGE <u>19E</u> NMPM.		

7. Unit Agreement Name
8. Farm or Lease Name
Riley State
9. Well No.
1
10. Field and Pool, or Wildcat
Wildcat
11. Elevation (Show whether DF, RT, GR, etc.)
4776 A
12. County
Lincoln

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPER. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

7. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1109.

Cement plug & abandon after losing 13 drill collars & 10 joints drill pipe in hole at 2687' 7-10-81 Back drill pipe off at 1838' - run drill pipe to 1761 - unable to get deeper - pump 50 sx class c plug at 1761 - WOC 6 hrs. - Tag cement plug at 1637 - Pull drill pipe to 804 Pump 75 sx class C plug - WOC 6 hrs - Tag cement plug at 754' - Pull drill pipe to 450' no circulation - Pump 20 bbls gel water & 2 sx hulls & 5000# 20-40 sand - Wait 30 minutes Tag sand plug at 554' - Pull drill pipe to 450' - mix 10 bbls gel water & 1 sx hulls & 3500# 20-40 sand - Wait 30 minutes no fill up - mix 10 bbl gel water & 1 sx hulls & 1500# 20-40 sand - Wait 30 minutes - no fill up - order gravel truck 7-12-81 Dump approx. 1.5 yards pea gravel in hole - pea gravel bridged at 110' - unable to return to bottom to set final plug consult with state man - run drill pipe down to bridge - set cement plug back to surface using 60 sx class c & 3% C.C.

8. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Field Engineer DATE August 10, 1981

APPROVED BY [Signature] TITLE OIL AND GAS INSPECTOR DATE JUN 29 1982

CONDITIONS OF APPROVAL, IF ANY: