

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	/
FILE	/
U.S.G.S.	
LAND OFFICE	
OPERATOR	/

NEW MEXICO OIL CONSERVATION COMMISSION

RECEIVED

JUL 24 1978

O. C. C.

ARTESIA, OFFICE

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	
N/A	
7. Unit Agreement Name	
8. Farm or Lease Name	
J.M. Lewelling	
9. Well No.	
#1	
10. Field and Pool, or Wildcat	
Lewelling Wildcat	
12. County	
Otero	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL <input checked="" type="checkbox"/> GAS <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator
Houston Oil & Minerals Corp. ✓
3. Address of Operator
242 Main Bldg, 1212 Main Street, Houston, TX 77002
4. Location of Well
UNIT LETTER <u>D</u> 660 FEET FROM THE <u>NL</u> LINE AND 660' FEET FROM
THE <u>WL</u> LINE, SECTION <u>12</u> TOWNSHIP <u>12.S</u> RANGE <u>9E</u> NMPM.
15. Elevation (Show whether DF, RT, GR, etc.)
4706' G.L.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

P&A expected to begin August 21, 1978.

Cy. in Hole 13 3/8" - 420 - 290 Cms.
9 5/8" - 2491 - 820 "
5 1/2" 8705 - 1400 SX + 400 SX

- Use Baker MOD "D". Permanent Packer with plug, set at 8550'.
- Put 30' cement plug over packer to plug 8572' zone.
- Load hole with 9.5 # mud.
- Spot 25 sack cement plug at 7912'.
- Spot 25 sack cement plug at 5140'.
- Cut 5 1/2" casing as deep as possible. Spot 50' cement plug inside and 50' above casing stub with 30 sacks.
- Spot cement plug 50' below and 50' into 9 5/8" casing with 30 sacks at 2441' to 2541'.
- Spot 20' cement plug at surface with 5 sacks.
- Place marker and level and clear location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED R. F. Baker TITLE Engineer DATE 7/18/78

APPROVED BY W. A. Gressett TITLE SUPERVISOR, DISTRICT II DATE JUL 28 1978

CONDITIONS OF APPROVAL, IF ANY:

* as noted above

Notify N.M.O.C.C. in sufficient time to witness

Plugging