

7. Acidize Abo 6107'-34' w/ 4000 gals NEFE HCL acid @ 1-2 BPM dropping 90- 1.3 SG ball sealers in sets of 3, evenly spaced throughout. Maximum pressure: 1500 psi. Flush to bottom perf w/ formation water. SI for 30 min.
8. Flow/swab back load and evaluate w/ Engineering.
9. Release packer. TOH, laying down 2-3/8" workstring. Test in hole w/ CA to 4000# below slips as per production department specifications. ND BOP. NU WH. RD PU. Clean location. Release rig. TOPS.
- Note: CA will consist of Baker FL on-off w/ L81" R Profile and Baker 4-1/2" Lok-set and 2-3/8", 4.7#, EUE, J-55, IPC tbg. *Set plr above squeeze perfs.*

*L. M. Thompson*  
L. M. Thompson

Approval:

*RDR 6-26-90*

R. D. Reynolds

*JES*

J. E. Shields