

State of New Mexico
Energy, Minerals and Natural Resources Department

DISTRICT I

P.O. Box 1980, Hobbs NM 88240

DISTRICT II

P.O. Drawer DD, Artesia NM 88210

DISTRICT III

1000 Rio Brazos Rd., Aztec NM 87410

OIL CONSERVATION DIVISION

P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-015-20395

5. Indicate Type of Lease
State ☐ FEE ☒

6. State Oil & Gas Lease No.

7. Lease Name or Unit Agreement Name
WHITE BU

8. Well No. 1

9. Pool Name or Wildcat
EAGLE CREEK SAN ANDRES

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)


1. Type of Well:
OIL ☐ GAS ☐
WELL ☒ WELL ☐ OTHER ☐

2. Name of Operator
Yates Petroleum Corporation

3. Address of Operator
105 South 4th., Artesia, NM 88210

4. Well Location
Unit Letter F : 2310 Feet From The NORTH Line and 2310 Feet From The WEST Line
Section 14 Township 17S Range 25E NMPM EDDY COUNTY

10. Elevation (Show whether DF, RKB, RT, GR, etc.)
3508' KB



11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐

OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☒

CASING TEST AND CEMENT JOB ☐

OTHER ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

YATES PETROLEUM CORPORATION respectfully requests permission to plug & abandon as follows:

RU wireline. Make guage ring run to 1320'. Set 4-1/2" CIBP @ 1300'; dump 35' cement on plug.
MIRU WSU; ND wellhead. TIH w/ tubing to 1260' & circ hole w/ mud laden fluid. Spot 25 sk plug 1196-1096'. -TAG
Rig up wireline. Perforate 5-1/2' casing @ 768'. TIH w/ tubing & packer. Set packer @ 450'. Attempt to pump into perfs; if circ can be established, circ cement to surface. Displace cement to 668' inside casing. WOC & tag plug. If able to circ cement, spot cement plug from 246' to surface. Perforate 5-1/2" casing @ 246'. Attempt to pump into perfs; circ cement plug from 246' to surface.
Cut off wellhead & install regulation marker.

Notify OCD 24 hrs. prior to any work done

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE *Donna Clack*

TITLE Operations Technician

DATE 3/8/02

TYPE OR PRINT NAME DONNA CLACK

TELEPHONE NO. 505-748-1471

(This space for State Use)

APPROVED BY *[Signature]*

TITLE

DATE

MAR 15 2002

CONDITIONS OF APPROVAL, IF ANY