

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs NM 88240

DISTRICT II
811 South First, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd, Aztec, NM 87410

OIL CONSERVATION DIVISION
2040 South Pacheco
Santa Fe, New Mexico 87505

WELL API NO.
30-015-10809

5. Indicate Type of Lease
STATE ☒ FEE ☐

6. State Oil & Gas Lease No.
B-1266

7. Lease Name or Unit Agreement Name
G J West Coop Unit

8. Well No.
37

9. Pool name or Wildcat
Grbg Jackson SR Q Grbg SA

10. Elevation (Show whether DF, RKB, RT, GR, etc.)
3595 GR

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS).

1. Type Of Well:
OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. Name of Operator
MACK ENERGY CORPORATION

3. Address of Operator
P.O. Box 960, Artesia, NM 88211-0960 (505) 748-1288

4. Well Location
Unit Letter G : 1980 Feet From The North Line and 1980 Feet From The East Line
Section 21 Township 17S Range 29E NMPM Eddy, NM County

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>		CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER: <input type="checkbox"/>		OTHER: <input type="checkbox"/>	

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Set CIBP 100' above perfs at 2166' with 35' cement

2. Set 100' cement plug 738-538' tag. 2. Perforate 4 1/2" csg @ 738'. Squeeze 100' cement Plug inside + outside 4 1/2" csg. TAG

3. Perf 4 1/2" csg at 288', squeeze 100' cement plug in-out 4 1/2" csg and tag. 395'

4. Set 60' surface plug.

5. Install dry hole marker and cut off anchors and level location and fill in pit.

* Brine gel between all cement Plugs.

* Notifie N.M.O.C.D. to witness Plugging Operations.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

Crissa D. Carter

TITLE

Production Analyst

DATE

TYPE OR PRINT NAME

Crissa D. Carter

TELEPHONE NO. (505)748-1288

(This space for State Use)

APPROVED BY

Mark S. Webb

TITLE

Field Rep. II

DATE

5/16/2000

CONDITIONS OF APPROVAL, IF ANY:



