

45F

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

RECEIVED  
AUG 19 1991

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: September 30, 1990

SUNDRY NOTICES AND REPORTS ON WELLS

O. C. D.  
ARTESIA, OFFICE

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Texaco Exploration & Production Inc.

3. Address and Telephone No.

P.O. Box 730, Hobbs, NM 88241-0730 (505) 393-7191

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

Letter H, 2130' FNL & 660' FEL; Sec. 15, T-17-S, R-31-E

5. Lease Designation and Serial No.

LC-029420-B

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

Skelly Unit

8. Well Name and No.

Skelly Unit #154

9. API Well No.

30-015-22532

10. Field and Pool, or Exploratory Area

Fren Seven Rivers

11. County or Parish, State

Eddy, New Mexico

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

☒ Notice of Intent \*\*  
☐ Subsequent Report  
☐ Final Abandonment Notice

TYPE OF ACTION

☒ Abandonment  
☐ Recompletion  
☐ Plugging Back  
☐ Casing Repair  
☐ Altering Casing  
☐ Other  
☐ Change of Plans  
☐ New Construction  
☐ Non-Routine Fracturing  
☐ Water Shut-Off  
☐ Conversion to Injection

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

- 1) Inform BLM 24 hrs. prior to commencement of work.
- 2) MIRU pulling unit. Pull rods and pump. Install BOP. Pull tubing.
- 3) RIH with 2 3/8" tubing and cement retainer. Set retainer at 2300'. Squeeze perfs with 75 sx Class "C" cement (1.32 cuft/sx). Flush with 7 BBLs of water. Sting out of retainer and flush remaining cement on top of retainer.
- 4) Load hole with salt gel mud consisting of 10 lb. brine with 25 lbs. of gel per barrel.
- 5) Pull up and spot a 25 sx plug of Class "C" cement (1.32 cuft/sx) from 1920'-1680' (base of salt 1684'). Tag plug.
- 6) Pull up and spot a 25 sx plug of Class "C" cement (1.32 cuft/sx) from 715'-475' (top of salt 696', surface casing shoe at 662'). Tag plug.
- 7) Pull up and pump 6 sx of Class "C" cement (1.32 cuft/sx) from 50'-surface.
- 8) Cut off wellhead. Install marker. Clean location.

\*\* Please disregard any previous notice of intent for abandonment on this well.

4. I hereby certify that the foregoing is true and correct

Signed Mc. Lane Title Engr. Asst.

Date 08-14-91

(This space for Federal or State office use)

Approved by \_\_\_\_\_  
Conditions of approval, if any: \_\_\_\_\_

Title \_\_\_\_\_ Date 8/16/91

2010