

Submit 3 Copies To Appropriate District Office  
District I  
1625 N. French Dr., Hobbs, NM 88240  
District II  
811 South First, Artesia, NM 88210  
District III  
1000 Rio Brazos Rd., Aztec, NM 87410  
District IV  
2040 South Pacheco, Santa Fe, NM 87505

State of New Mexico  
Energy, Minerals and Natural Resources

Form C-103  
Revised March 25, 1999

OIL CONSERVATION DIVISION  
2040 South Pacheco  
Santa Fe, NM 87505

WELL API NO.  
**30-015-31052**

5. Indicate Type of Lease  
STATE ☒ FEE ☐

6. State Oil & Gas Lease No.  
**B6846**

7. Lease Name or Unit Agreement Name:  
**STATE '20B'**  
**(25235)**

8. Well No.  
**7**

9. Pool name or Wildcat **(28509)**  
**Grayburg Jackson-7R's, QN, GB, SA**

10. Elevation (Show whether DR, RKB, RT, GR, etc.)  
**3617'**

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:  
Oil Well ☒ Gas Well ☐ Other ☐
2. Name of Operator  
Clayton Williams Energy, Inc.
3. Address of Operator  
Six Desta Drive, Suite 3000, Midland, Texas 79705
4. Well Location

Unit Letter **B** : **330** feet from the **north** line and **2310** feet from the **east** line

Section **20** Township **17S** Range **29E** NMPM **Eddy** County

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

- PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐
- TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
- PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐
- OTHER: ☐

SUBSEQUENT REPORT OF:

- REMEDIAL WORK ☒ ALTERING CASING ☐
- COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
- CASING TEST AND CEMENT JOB ☐
- OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

July 17 thru 31, 2000

- Set RBP @ 3800' and temporarily abandon Yeso perms.
- Perforate Lower San Andres 3393'-3735', 25 shots. Stimulate Lower San Andres.
- Set RBP @ 3190'.
- Perforate Upper San Andres 2450'-3091', 27 shots. Stimulate Upper San Andres.
- Set RBP @ 2400'.
- Perforate Grayburg Jackson 1933' - 2360', 23 shots. Stimulate Grayburg Jackson.
- Retrieve RBP's at 3190' and 2400'. Clean out to BP at 3800'.
- Run tubing, rods and pump.
- Start pumping load water.

RECEIVED  
OCD - ARTESIA

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Betsy Luna TITLE Engineering Technician DATE 8/21/00

Type or print name Betsy Luna Telephone No. (915) 682-6324

(This space for State use)

APPROVED BY ORIGINAL SIGNED BY TIM W. GUM  
DISTRICT II SUPERVISOR TITLE

Conditions of approval, if any:

DATE AUG 28 2000