

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPlicate
NM Oils & Gas Construction
verse side

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

5. LEASE DESIGNATION AND SERIAL NO.

LC-051102-B

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

C/SF

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME
Hallard B

9. WELL NO.
4

10. FIELD AND POOL, OR WILDCAT
Loco Hills-Q-G-SA

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Unit B, Sec. 1-18S-29E

12. COUNTY OR PARISH

Eddy

13. STATE

NM

1. NAME OF OPERATOR
Yates Petroleum Corporation

2. ADDRESS OF OPERATOR
207 South 4th St., Artesia, NM 88210

3. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface
990 FNL & 1650 FEL, Sec. 1-T18S-R29E

14. PERMIT NO.

15. ELEVATIONS (Show whether DP, RT, CR, etc.)

3348' KB

RECEIVED BY
DEC 12 1985
O. C. D.
ARTESIA OFFICE

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF
FRACTURE TREAT
SHOOT OR ACIDIZE
REPAIR WELL
(Other)

PULL OR ALTER CASING
MULTIPLE COMPLETE
ABANDON*
CHANGE PLANS

WATER SHUT-OFF
FRACTURE TREATMENT
SHOOTING OR ACIDIZING
(Other)

REPAIRING WELL
ALTERING CASING
ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Propose to plug well as follows:

- Spot sufficient cement across producing interval to tie back 50' into production casing shoe. Tag plug.
- Isolate Queen formation from overlying zones with 100' cement plug. Top of Queen is at 2250'; top of cement is at 1400'.
- Perforate 50' below base of salt at 1215' and squeeze with 50 sx cement, leaving 100' plug in casing. Tag plug.
- Perforate 50' above top of salt at 398' and squeeze with 50 sx cement, leaving 100' plug in casing. Tag plug.
- Set ^{50'} ~~30'~~ surface plug and install regulation abandonment marker. *both sides of csg.*

- NOTE: 1) NOTIFY BLM, CARLSBAD, NM, (887-6544) 24 HOURS PRIOR TO BEGINNING WORK.
- 2) Mud between plugs to be 10#/gallon mud-laden fluid.

18. I hereby certify that the foregoing is true and correct

SIGNED *[Signature]*

TITLE Production Supervisor

DATE 11-26-85

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE 12-10-85

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side