

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT  
Artesia, NM 88210

SUBMIT IN TRIPPLICATE  
(Other instructions on  
reverse side)

Form approved.  
Budget Bureau No. 1004-0135  
Expires August 31, 1985

C/SF

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR  
Harvey E. Yates Company

3. ADDRESS OF OPERATOR  
Box 1933, Roswell, NM 88201

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\*  
See also space 17 below.)  
At surface  
1980' FNL & 1980' FWL

14. PERMIT NO.  
30-015-21387

15. ELEVATIONS (Show whether DP, RT, GR, etc.)  
3271' GL

RECEIVED BY  
MAR 17 1986  
O.G.P.  
ARTESIA, OFFICE

5. LEASE DESIGNATION AND SERIAL NO.  
NM-03677

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME  
Yates "A" Federal

9. WELL NO.  
1

10. FIELD AND POOL, OR WILDCAT  
Wildcat Bone Springs

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA  
Sec 21, T-20S, R-29E

12. COUNTY OR PARISH  
Eddy

13. STATE  
NM

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other) ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

ABANDON\* ☒

CHANGE PLANE ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other) ☐

REPAIRING WELL ☐


ALTERING CASING ☐

ABANDONMENT\* ☐

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) \*

- 1) MI & RU PU.
- 2) POOH w/rods & pump.
- 3) ND well head/NU BOP.
- 4) POOH w/SN, tailpipe, anchor, & 2-3/8" tbg.
- 5) GIH & set CIBP @ 7775'. POOH.
- 6) GIH & perforate 4 holes @ 1000'.
- 7) GIH w/tbg & pump 35' cmt on top of CIBP.
- 8) Pull tbg above CIBP & pump cmt plugs as follows:
  - a) 100' plug from 6600' to 6500'
  - b) 450' plug from 5600' to 5150' over perms (tag)
  - c) 100' plug from 4300' to 4200'
  - d) 100' plug from 3175' to 3075' over shoe-tag
  - e) 100' plug from 1020' to 920' inside & behind 4-1/2" csg
  - f) 100' plug from 543' to 443' inside & behind 4-1/2" csg
- 9) POOH w/tbg. ND BOP.
- 10) Pump 50' surface plug inside & behind 4-1/2" csg. Install dry hole marker.
- 11) RD & release all rentals.
- 12) Clean location.



18. I hereby certify that the foregoing is true and correct

SIGNED

*Stephen L. Lake*

TITLE

Petroleum Engineer

DATE

3-5-86

(This space for Federal or State office use)

By: Spc. Charles S. [unclear]

APPROVED BY

Area Manager

TITLE

DATE

3-14-86

CONDITIONS OF APPROVAL, IF ANY:

\*See Instructions on Reverse Side