

Submit 3 Copies To Appropriate District Office
District I
1625 N. French Dr., Hobbs, NM 88240
District II
1301 W. Grand Ave., Artesia, NM 88210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
Revised March 25, 1999

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO.
30-025-01270

5. Indicate Type of Lease
STATE ☒ FEE ☐

6. State Oil & Gas Lease No.
E-1814

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

7. Lease Name or Unit Agreement Name:

New Mexico A

1. Type of Well:
Oil Well ☒ Gas Well ☐ Other ☐

8. Well No. **3**

2. Name of Operator
PENROC OIL CORP

3. Address of Operator
P.O. Box 2769, Hobbs, NM 88241

9. Pool name or Wildcat
Wildcat

4. Well Location

Unit Letter **J** : **1980** feet from the **EAST** line and **1980** feet from the **SOUTH** line

Section **25** Township **16S** Range **33E** NMPM **65A** County

10. Elevation (Show whether DR, RKB, RT, GR, etc.)

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☒ PLUG AND ABANDON ☐

REMEDIAL WORK ☐ ALTERING CASING ☐

TEMPORARILY ABANDON ☒ CHANGE PLANS ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐

PULL OR ALTER CASING ☒ MULTIPLE COMPLETION ☐


CASING TEST AND CEMENT JOB ☐

OTHER: ☐

OTHER: ☐

2. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

- Well currently open in Wolfcamp pay. Proposed plans are as follows:**
1. RU IN.O.U. Pull & LD rods to 4500'. Pull & stand off log in derrick.
 2. Set CIBP @ 9900'. Spot 35' cement on top.
 3. Determine Free point, cut & pull 5 1/2" CSG. LD same.
 4. Replace hole w/ 9" gelled brine from ABTD to 5 1/2" CSG stub.
 5. Set 50 sx plug (25-25) @ CSG stub. - TAG
 6. Perforate & test Grayburg & San Andres.
 7. If commercial put on production. If NOT, make decision either to TA per OCD rules or Plug & abandon.



I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE **M. Y. Merchant** TITLE **Drill** DATE **4/4/04**

or print name **M. Y. Merchant** Telephone No. **(505) 492-1236**

APPROVED BY **GARY W. WINK** DATE **APR 05 2004**
Title **OG FIELD REPRESENTATIVE II/STAFF MANAGER**