

Submit 3 Copies To Appropriate District Office

District I

1625 N. French Dr., Hobbs, NM 88240

District II

1301 W. Grand Ave., Artesia, NM 88210

District III

1000 Rio Brazos Rd., Aztec, NM 87410

District IV

1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico  
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION  
1220 South St. Francis Dr.  
Santa Fe, NM 87505

Form C-103

March 4, 2004

WELL API NO.

3002512116

5. Indicate Type of Lease

STATE ☐ FEE ☒

6. State Oil & Gas Lease No.

7. Lease Name or Unit Agreement Name  
Belcher

8. Well Number

1

9. OGRID Number

012024

10. Pool name or Wildcat  
Brunson Drinkard Abo, South

Tubb  
846

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

John H. Hendrix Corp.

3. Address of Operator

Box 3040 Midland, Texas 79704

4. Well Location

Unit Letter L : 1980 feet from the SOUTH line and 660 feet from the West line

Section 7

Township 22S Range 38E

NMPM

County Lea

11. Elevation (Show whether DR, RKB, RT, GR, etc.)  
3348 GR

Pit or Below-grade Tank Application (For pit or below-grade tank closures, a form C-144 must be attached)

Pit Location: UL L Sect 7 Twp 22S Rng 38E Pit type STEEL Depth to Groundwater 45' Distance from nearest fresh water well \*

Distance from nearest surface water \* Below-grade Tank Location UL  Sect  Twp  Rng  ;

feet from the  line and  feet from the  line

\* Over 1000'

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

See Attachments

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.

I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or below-grade tank has been/will be constructed or closed according to NMOC guidelines ☐ a general permit ☐ or an (attached) alternative OCD-approved plan ☐.

SIGNATURE

H. Boatright

TITLE

Agent

DATE

5-3-04

Type or print name

E-mail address:

Telephone No.

570 5382

(This space for State use)

APPROVED BY

TITLE

DATE

JUN 02 2004

Conditions of approval, if any:

OC FIELD REPRESENTATIVE II/STAFF MANAGER

**WELL NAME AND NUMBER**


Belcher Well No. 1

John H. Hendrix Corp

Lea County, New Mexico

Proposed Plugging

**WELLBORE CONFIGURATION**




**WELL NAME AND NUMBER**

Belcher Well No. 1  
John H. Hendrix Corp  
Lea County, New Mexico

**WELLBORE CONFIGURATION**

---



## Belcher Well No. 1

### Proposed Plugging

1. We will circulate all fluids into an above ground steel pit and dispose of the fluid as needed.
2. Rig up P&A unit. Move in steel pits and workstring.
3. Tally in hole w/ 2-3/8" workstring to the base of the 5" liner (approximately 6828')
4. Spot a 50 sx. plug from 6828' to 6728'. PUH and WOC.
5. Tag top of cement at 6728'.
6. Perforate 5" liner at 5600'.
7. RIH w/ 7" packer and set packer at 5250'.
8. Squeeze perforations and top of liner w/ 100 sx. of cement. Displace top of cement to 5450'. SWI and WOC.
9. Tag top of cement at 5450'.
10. PUH with packer and set at 2600'.
11. Perforate casing at 2900' (base of salt)
12. Squeeze perforations w/ 100 sx. of cement. Displace top of cement to 2800'. SWI and WOC and Tag.
13. Perforate casing at 1100'. Squeeze w/ 100 sx. and tag (top of salt).
14. Perforate casing at 356'. Circulate cement to surface, leaving 7" full- (140 sx.)
15. Cut off wellhead and install marker.

# John H Hendrix Corp Belcher #1

## 2 Above Ground Steel Pits

Anchors

Anchors

Well Bore  
⊗

100'

Anchors

Anchors

