

Submit 3 Copies To Appropriate District  
Office  
District I  
1625 N. French Dr., Hobbs, NM 88240  
District II  
1301 W. Grand Ave., Artesia, NM 88210  
District III  
1000 Rio Brazos Rd., Aztec, NM 87410  
District IV  
1220 S. St. Francis Dr., Santa Fe, NM  
87505

State of New Mexico  
Energy, Minerals and Natural Resources

Form C-103  
May 27, 2004

OIL CONSERVATION DIVISION  
1220 South St. Francis Dr.  
Santa Fe, NM 87505

WELL API NO. 30 025 <del>02546</del> 02537
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. B-6807
7. Lease Name or Unit Agreement Name KAISER STATE
8. Well Number 8
9. OGRID Number
10. Pool name or Wildcat Wilson Yates Seven Rivers Assoc.

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well ☒ Gas Well ☐ Other

2. Name of Operator  
HAL J. RASMUSSEN OPERATING, L.P.

3. Address of Operator  
550 W. TEXAS, SUITE 200, MIDLAND, TEXAS 79701

4. Well Location  
Unit Letter O : 990 feet from the SOUTH line and 2310 feet from the EAST line  
Section 13 Township 21-S Range 34-E NMPM LEA County

11. Elevation (Show whether DR, RKB, RT, GR, etc.)

Pit or Below-grade Tank Application ☐ or Closure ☐

Pit type STEEL Depth to Groundwater 110 Distance from nearest fresh water well Distance from nearest surface water

Pit Liner Thickness: mil Below-Grade Tank: Volume bbls; Construction Material

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐

OTHER: ☐

SUBSEQUENT REPORT OF:


REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ P AND A ☐  
CASING/CEMENT JOB ☐

OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

SEE ATTACHED PROCEDURE.

THE COMPLETION MUST BE NOTIFIED 24  
HOURS PRIOR TO THE BEGINNING OF  
PLUGGING OPERATIONS FOR THE C103  
TO BE APPROVED.



I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or below-grade tank has been/will be constructed or closed according to NMOCD guidelines ☐, a general permit ☐ or an (attached) alternative OCD-approved plan ☐.

SIGNATURE Tommy Taylor TITLE AGENT DATE 10/8/2004

Type or print name TOMMY TAYLOR

E-mail address: ttaylor@tetrathec.com

For State Use Only

APPROVED BY: Hay W. Wink  
Conditions of Approval (if any):

TITLE


OC FIELD REPRESENTATIVE II/STAFF

DATE

OCT 14 2004

COMPANY: Hal J. Rasmussen Operating, L.P.  
WELL NAME: Kaiser State  
WELL #: 8  
API#: 30-025-02546  
COUNTY: Lea

BEFORE



16" @ 123', cmt'd w/ 150 sx

12 1/2" @ 752'

10" @ 1238'


Q1238

7" @ 3436' cmt'd w/ 300 sx

PBTD 3775'

TD 3810'

AFTER



75 SX F/ SURF- 173'

25 SX F/ 702-802'

25 SX FROM 1178-1278'

PERF @ 1773'  
35 SX FROM 1663'-1773'

10 SX PLUG 3350'-3300'  
CIBP @ 3400'

**PROPOSED PLUGGING PROCEDURE FOR  
HAL J. RASMUSSEN OPERATING, L.P.**

**WELL: KAISER STATE 8**  
**FIELD: WILSON YATES SEVEN RIVERS ASSOC.**  
**COUNTY: LEA**

1. MIRU; REMOVE TREE; SET BOP.
2. RIH W/ WORKSTRING, 7" BIT & SCRAPER TO 3400'.
3. POOH & LD BIT & SCRAPER, RIH W/ 7" CIBP TO 3400'.
4. SET CIBP, RELEASE SETTING TOOL.
5. CIRCULATE WELL W/ 130 BBLS 9.5 PPG MUD LADEN FLUID.
6. SET 10 SX CEMENT PLUG FROM 3350'-3400'.
7. POOH W/ TUBING, STAND BACK 1500'.
8. RIH W/ 7" PACKER AND TAIL PIPE TO 1550'.
9. RU WIRELINE; RIH AND PERFORATE 7" CASING @ 1773' (50' BELOW BASE OF SALT).
10. POOH, RD WIRELINE.
11. ESTABLISH INJECTION RATE.
12. PUMP 35 SX CEMENT BELOW PACKER.
13. DISPLACE TOC TO 1663'. WOC.
14. POOH W/ TUBING AND LD PACKER.
15. LOWER TUBING TO TOC, TAG AND RECORD.
16. PULL TUBING UP TO 1278'.
17. SET 25 SX CEMENT PLUG FROM 1178'-1278' (10" CASING SHOE).
18. PULL TUBING UP TO 802'. SET 25 SX CEMENT FROM 702'-802' (12 1/2" CASING SHOE).
19. POOH W/ TUBING.
20. RU WIRELINE, PERFORATE CASING @ 210'.
21. RIH W/ TUBING TO 160'.
22. OPEN CASING VALVE AND ESTABLISH CIRCULATION.
23. SET 75 SX CEMENT PLUG FROM SURFACE TO 173' (SURFACE CASING SHOE & GROUND WATER PLUG).
24. INSTALL DRY HOLE MARKER.
25. RDMO.