
Submit 3 Copies To Appropriate District Office	State of New Mexico	Form C-103
District I Energy, 1625 N. French Dr., Hobbs, NM 88240	Minerals and Natural Resources	WELL API NO.
District II	ONSERVATION DIVISION	30 025 02546
District III 1	220 South St. Francis Dr.	5. Indicate Type of Lease
1000 Rio Brazos Rd., Aztec, NM 87410 District IV	Santa Fe, NM 87505	STATE FEE 6. State Oil & Gas Lease No.
1220 S. St. Francis Dr., Santa Fe, NM 87505		B6807
SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH		7. Lease Name or Unit Agreement Name KAISER STATE
PROPOSALS.) 1. Type of Well: Oil Well Gas Well Other		8. Well Number 41
2. Name of Operator HAL J. RASMUSSEN OPERATING, L.P.		9. OGRID Number
3. Address of Operator P O BOX 2517, MIDLAND, TEXAS 79702		10. Pool name or Wildcat
4. Well Location YATES SEVEN RIVERS AS		YATES SEVEN RIVERS ASSOC.
Unit Letter E : 2310 feet from the NORTH line and 1270 feet from the WEST line		
	rnship 21-S Range 34-E	NMPM LEA County
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3667' GL		
Pit or Below-grade Tank Application or Closure		
Pit type_STEELDepth to Groundwater_110_Distance from nearest fresh water wellDistance from nearest surface water		
Pit Liner Thickness: mil Below-Gra	de Tank: Volumebbls; C	onstruction Material
12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data		
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:		
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK ALTERING CASING		
TEMPORARILY ABANDON CHANGE P PULL OR ALTER CASING MULTIPLE		ILLING OPNS. P AND A
TOLE ON ALTEN CASING LI MOLTIPLE	COMPL*** [] CASING/CEMEN	IT JOB L
OTHER:	OTHER:	
13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.		
•		
SEE ATTACHED PROCEDURE.		
		-+IEIED 74
	COMMISSION MUS	ST BE NOTIFIED OF
THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF HOURS OPERATIONS FOR THE C-103		
THE COMMISSION TO THE BEGINNING HOURS PRIOR TO THE C-103 PLUGGING OPERATIONS FOR THE C-103 PLUGGING OPERATIONS		
	TO BE APPROVED	•
I hereby certify that the information above is true a	nd complete to the heat of my lengants I	11 1' C
I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or below-grade tank has been/will be constructed or closed according to NMOCD guidelines , a general permit or an (attached) alternative OCD-approved plan.		
SIGNATURE Sommy Saylor	TITLEAGENT	DATE_10/8/2004_
Type or print name For State Use Only Control of the Indian E-mail address: ttaylor@tetratec.compafficerione No. 432/570-5283 OC FIELD REPRESENTATIVE TO THE PROPERTY OF THE		
For State Use Only OC FIELD REPRESENTATIVE 11/3/ AFTE DEPRIOR NO. 432/3/0-3283		
APPROVED BY: Hay W. Win	R TITLE	DATE
Conditions of Approval (if any):	and apply a property and a second	OCT 1 4 2004



PROPOSED PLUGGING PROCEDURE FOR HAL J. RASMUSSEN OPERATING, L.P.

WELL:

KAISER STATE 41

FIELD:

YATES SEVEN RIVERS ASSOC

COUNTY: LEA

TOP OF SALT: 1750'

SURFACE WATER: 110'

- 1. MIRU; REMOVE TREE, SET BOP.
- 2. RIH W/ WORKSTRING & 7" BIT & SCRAPER TO 3610'.
- 3. POOH & LD BIT & SCRAPER.
- 4. RIH W/ TUBING AND 7" CIBP, SET CIBP @ 3600'.
- 5. RELEASE SETTING TOOL FROM CIBP.
- 6. CIRCULATE WELL W/ 9.5 PPG MUD LADEN FLUID.
- 7. SET 10 SX CEMENT PLUG ON TOP OF CIBP.
- 8. PULL TUBING UP TO 1800'.
- 9. SET 25 SX CEMENT FROM 1700'-1800' (TOP OF SALT).
- 10. PULL TUBING UP OUT OF CEMENT; REVERSE OUT; WOC.
- 11. LOWER TUBING TO TOC, TAG AND RECORD.
- 12. PULL TUBING UP TO 1289'.
- 13. SET 25 SX CEMENT FROM 1189'-1289' (10" CASING SHOE).
- 14. PULL TUBING UP OUT OF CEMENT; REVERSE OUT; WOC.
- 15. LOWER TUBING TO TOC, TAG AND RECORD.
- 16. PULL TUBING UP TO 920'.
- 17. SET 25 SX CEMENT FROM 820'-920' (12 1/2" CASING SHOE).
- 18. PULL TUBING UP OUT OF CEMENT; REVERSE OUT; WOC.
- 19. LOWER TUBING TO TOC, TAG AND RECORD.
- 20. POOH W/ TUBING; RU WIRELINE.
- 21. RIH & PERFORATE @ 284'; POOH, RD WIRELINE (16").
- 22. RIH W/ 7" PACKER TO 150'.
- 23. OPEN CASING VALVE, ESTABLISH CIRCULATION.
- 24. SQUEEZE 85 SX CEMENT BELOW PACKER, DISPLACE TOC TO 184', WOC.
- 25. POOH W/ TUBING, LD PACKER.
- 26. RIH W/ TUBING TO TOC, TAG AND RECORD.
- 27. SET 15 SX CEMENT PLUG INSIDE 4 1/2" CASING FROM SURFACE TO 184'.
- 28. POOH W/ TUBING.
- 29. CUT OFF, REMOVE WELLHEAD.
- 30. INSTALL DRY HOLE MARKER.
- 31. RDMO.