
Submit 3 Copies To Appropriate District Office	State of New Mo	exico	Form C-103
District I 1625 N. French Dr., Hobbs, NM 88240	Energy, Minerals and Nati	ural Resources	March 4, 2004 ELL API NO.
District II	OIL CONSERVATION DIVISION		30-025-02182
1301 W. Grand Ave., Artesia, NM 88210 District III	1220 South St. Fra	5	Indicate Type of Lease
1000 Rio Brazos Rd., Aztec, NM 87410 District IV	Santa Fe, NM 8		STATE FEE State Oil & Gas Lease No.
1220 S. St. Francis Dr., Santa Fe, NM 87505	,	0.	B-8097
SUNDRY NOTION	CES AND REPORTS ON WELLS	S 7.	Lease Name or Unit Agreement Name
(DO NOT USE THIS FORM FOR PROPOSE DIFFERENT RESERVOIR. USE "APPLICATION OF THE PROPOSE OF THE PR	SALS TO DRILL OR TO DEEPEN OR PL	UG BACK TO A	West Vacuum Unit
PROPOSALS.) 1. Type of Well:	,		Well Number
	Other		14
2. Name of Operator		9.	OGRID Number
Chevron US	SA Inc		
3. Address of Operator 15 Smith R	d, Midland, TX 79705	10	Pool name or Wildcat
4. Well Location			Vacuum Grayburg San Andres
Unit Letter E .	1980 feet from the North	th G	20
Unit Letter E :	1980 feet from the North	line and 6	feet from the West line
Section 33			MPM Lea County
	11. Elevation (Show whether DR	R, RKB, RT, GR, etc.)	49.000 P. 10.000
Pit or Below-grade Tank Application (For	pit or below-grade tank closures, a form	n C-144 must be attached)	Alexander Description of the Control
			Distance from nearest fresh water well Over 1000'
Distance from nearest surface water			Rng ;
1980 feet from the North line and			<u> </u>
	,	Steel Tank)	port or Other Data
	Appropriate Box to Indicate NTENTION TO: PLUG AND ABANDON CHANGE PLANS	Nature of Notice, Rep SUBSE REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND	QUENT REPORT OF: ALTERING CASING
12. Check A NOTICE OF IN PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING	Appropriate Box to Indicate NTENTION TO: PLUG AND ABANDON CHANGE PLANS	Nature of Notice, Rep SUBSE REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND CEMENT JOB	QUENT REPORT OF: ALTERING CASING BG OPNS. PLUG AND ABANDONMENT
12. Check A NOTICE OF IN PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER:	Appropriate Box to Indicate NTENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION	Nature of Notice, Rep SUBSE REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND CEMENT JOB	QUENT REPORT OF: ALTERING CASING DISTRIBUTION DISTRIBUTI
12. Check A NOTICE OF IN PERFORM REMEDIAL WORK TEMPORARILY ABANDON TEMPORARILY ABANDON TO THER: 13. Describe proposed or comples of starting any proposed wo	Appropriate Box to Indicate NTENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION deted operations. (Clearly state all	Nature of Notice, Rep SUBSECTION REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND CEMENT JOB OTHER:	QUENT REPORT OF: ALTERING CASING IG OPNS. PLUG AND ABANDONMENT
12. Check A NOTICE OF IN PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or completion of starting any proposed wo or recompletion.	Appropriate Box to Indicate NTENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION leted operations. (Clearly state all rk). SEE RULE 1103. For Multip	Nature of Notice, Rep SUBSECTION REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND CEMENT JOB OTHER:	QUENT REPORT OF: ALTERING CASING IG OPNS. PLUG AND ABANDONMENT The perform dates including estimated date
12. Check A NOTICE OF IN' PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or completion of starting any proposed wood or recompletion. 1. Notify OCD 24 hrs prior to MI and 2. RIH Tag CIBP at 4188, spot 25sx	Appropriate Box to Indicate NTENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION Leted operations. (Clearly state all rk). SEE RULE 1103. For Multip	Nature of Notice, Rep SUBSECT	QUENT REPORT OF: ALTERING CASING ABANDONMENT PLUG AND ABANDONMENT Pe perfiment dates, including estimated date wellbore diagram of proposed completion
12. Check A NOTICE OF IN' PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or compl of starting any proposed wo or recompletion. 1. Notify OCD 24 hrs prior to MI and 2. RIH Tag CIBP at 4188, spot 25sx 3. Displace hole w/MLF, 9.5# Brine 4. Spot 25sx, plug from 2600-2400 (Appropriate Box to Indicate NTENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION Leted operations. (Clearly state all rk). SEE RULE 1103. For Multiput IRU. It, plug from 4188-4000 (San Andres) Ww/25# gel P/BBL. Leter Section (Yates, B-Salt).	Nature of Notice, Rep SUBSECT	QUENT REPORT OF: ALTERING CASING BIG OPNS. PLUG AND ABANDONMENT PROPOSED Reperiment dates, including estimated date wellbore diagram of proposed completion
12. Check A NOTICE OF IN' PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or completion of starting any proposed work or recompletion. 1. Notify OCD 24 hrs prior to MI and 2. RIH Tag CIBP at 4188, spot 25sx 3. Displace hole w/MLF, 9.5# Brine 4. Spot 25sx, plug from 2600-2400 (5. Spot 25sx, plug from 1000-750 (8.)	Appropriate Box to Indicate NTENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION Leted operations. (Clearly state all rk). SEE RULE 1103. For Multiput RRU. Complete of the property of the prope	Nature of Notice, Rep SUBSE REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND CEMENT JOB OTHER: pertinent details, and giv ole Completions: Attach	QUENT REPORT OF: ALTERING CASING ABANDONMENT PLUG AND ABANDONMENT Pe perfiment dates, including estimated date wellbore diagram of proposed completion
12. Check A NOTICE OF IN' PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or compl of starting any proposed wo or recompletion. 1. Notify OCD 24 hrs prior to MI and 2. RIH Tag CIBP at 4188, spot 25sx 3. Displace hole w/MLF, 9.5# Brine 4. Spot 25sx, plug from 2600-2400 (5. Spot 25sx, plug from 1000-750 (6. Perf 4 holes at 300, sqz 85sx, plug 7. Install dry hole marker.	Appropriate Box to Indicate NTENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION deted operations. (Clearly state all rk). SEE RULE 1103. For Multiple RU. st, plug from 4188-4000 (San Andres) Ww/25# gel P/BBL. (Yates, B-Salt). 3 5/8 Shoe, T-Salt) WOC Tag. g from 300-Surf, 5 1/2 x 8 5/8 csgs (Sur	Nature of Notice, Rep SUBSECTION REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND CEMENT JOB OTHER: pertinent details, and give one completions: Attach OCC Tag.	QUENT REPORT OF: ALTERING CASING ABANDONMENT REPORT OF: ALTERING CASING REPORT OF: ALTERING CASING REPORT OF: ABANDONMENT REPORT OF: ABA
12. Check A NOTICE OF IN' PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or compl of starting any proposed wo or recompletion. 1. Notify OCD 24 hrs prior to MI and 2. RIH Tag CIBP at 4188, spot 25sx 3. Displace hole w/MLF, 9.5# Brine 4. Spot 25sx, plug from 2600-2400 (5. Spot 25sx, plug from 1000-750 (8 6. Perf 4 holes at 300, sqz 85sx, plu 7. Install dry hole marker. I hereby certify that the information a	Appropriate Box to Indicate NTENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION Leted operations. (Clearly state all rk). SEE RULE 1103. For Multiple RU. Splug from 4188-4000 (San Andres) Ww/25# gel P/BBL. (Yates, B-Salt). S5/8 Shoe, T-Salt) WOC Tag. Sg from 300-Surf, 5 1/2 x 8 5/8 csgs (Surabove is true and complete to the below to the selection of the selection	Nature of Notice, Rep SUBSECTION REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND CEMENT JOB OTHER: pertinent details, and give one completions: Attach OC Tag.	QUENT REPORT OF: ALTERING CASING ABANDONMENT Repertment dates, including estimated date wellbore diagram of proposed completion
12. Check A NOTICE OF IN PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or compl of starting any proposed wo or recompletion. 1. Notify OCD 24 hrs prior to MI and 2. RIH Tag CIBP at 4188, spot 25sx 3. Displace hole w/MLF, 9.5# Brine 4. Spot 25sx, plug from 2600-2400 (5. Spot 25sx, plug from 1000-750 (8 6. Perf 4 holes at 300, sqz 85sx, plu 7. Install dry hole marker. I hereby certify that the information a grade tank has been/will by constructed or	Appropriate Box to Indicate NTENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION deted operations. (Clearly state all rk). SEE RULE 1103. For Multiple RU. Apply from 4188-4000 (San Andres) Ww/25# gel P/BBL. (Yates, B-Salt). B 5/8 Shoe, T-Salt) WOC Tag. B from 300-Surf, 5 1/2 x 8 5/8 csgs (Surabove is true and complete to the bisosed according to NMOCD guidelines [Insert Post of the complete in the	Nature of Notice, Rep SUBSE REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND CEMENT JOB OTHER: pertinent details, and giv ole Completions: Attach /OC Tag.	QUENT REPORT OF: ALTERING CASING GOPNS. PLUG AND ABANDONMENT reperiment dates, including estimated date wellbore diagram of proposed completion belief. I further certify that any pit or below- (attached) alternative OCD-approved plan
12. Check A NOTICE OF IN' PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or compl of starting any proposed wo or recompletion. 1. Notify OCD 24 hrs prior to MI and 2. RIH Tag CIBP at 4188, spot 25sx 3. Displace hole w/MLF, 9.5# Brine 4. Spot 25sx, plug from 2600-2400 (5. Spot 25sx, plug from 1000-750 (8 6. Perf 4 holes at 300, sqz 85sx, plu 7. Install dry hole marker. I hereby certify that the information a grade tank has been/will be constructed or	Appropriate Box to Indicate NTENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION Leted operations. (Clearly state all rk). SEE RULE 1103. For Multiple RU. See RULE 1103. For Mul	Nature of Notice, Rep SUBSECT	ALTERING CASING ALTERING CASIN
12. Check A NOTICE OF IN PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or compl of starting any proposed wo or recompletion. 1. Notify OCD 24 hrs prior to MI and 2. RIH Tag CIBP at 4188, spot 25sx 3. Displace hole w/MLF, 9.5# Brine 4. Spot 25sx, plug from 2600-2400 (5. Spot 25sx, plug from 1000-750 (8 6. Perf 4 holes at 300, sqz 85sx, plu 7. Install dry hole marker. I hereby certify that the information a grade tank has been/will by constructed or	Appropriate Box to Indicate NTENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION deted operations. (Clearly state all rk). SEE RULE 1103. For Multiple RU. st, plug from 4188-4000 (San Andres) Ww/25# gel P/BBL. (Yates, B-Salt). 3 5/8 Shoe, T-Salt) WOC Tag. g from 300-Surf, 5 1/2 x 8 5/8 csgs (Surabove is true and complete to the belosed according to NMOCD guidelines [Institute of the complete in the	SUBSECTION OF THE SUBSECTION O	ALTERING CASING ALTERING CASIN
12. Check A NOTICE OF IN' PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or compl of starting any proposed wo or recompletion. 1. Notify OCD 24 hrs prior to MI and 2. RIH Tag CIBP at 4188, spot 25sx 3. Displace hole w/MLF, 9.5# Brine 4. Spot 25sx, plug from 2600-2400 (5. Spot 25sx, plug from 1000-750 (8 6. Perf 4 holes at 300, sqz 85sx, plu 7. Install dry hole marker. I hereby certify that the information a grade tank has been/will be constructed or	Appropriate Box to Indicate NTENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION deted operations. (Clearly state all rk). SEE RULE 1103. For Multiple RU. st, plug from 4188-4000 (San Andres) Ww/25# gel P/BBL. (Yates, B-Salt). 3 5/8 Shoe, T-Salt) WOC Tag. g from 300-Surf, 5 1/2 x 8 5/8 csgs (Surabove is true and complete to the belosed according to NMOCD guidelines [Institute of the complete in the	Nature of Notice, Rep SUBSECT	ALTERING CASING ALTERING CASIN
12. Check A NOTICE OF IN' PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or completion of starting any proposed wo or recompletion. 1. Notify OCD 24 hrs prior to MI and 2. RIH Tag CIBP at 4188, spot 25sx, 3. Displace hole w/MLF, 9.5# Brine: 4. Spot 25sx, plug from 2600-2400 (5. Spot 25sx, plug from 1000-750 (8. Perf 4 holes at 300, sqz 85sx, plug 7. Install dry hole marker. I hereby certify that the information a grade tank has been/will be constructed or SIGNATURE Type or print name Type or print name	Appropriate Box to Indicate NTENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION Leted operations. (Clearly state all rk). SEE RULE 1103. For Multiple IRU. See the public plant of the public pl	SUBSECTION OF THE SUBSECTION O	ALTERING CASING ALTERING CASIN
12. Check A NOTICE OF IN' PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING OTHER: 13. Describe proposed or completion of starting any proposed woor recompletion. 1. Notify OCD 24 hrs prior to MI and 2. RIH Tag CIBP at 4188, spot 25sx 3. Displace hole w/MLF, 9.5# Brine 4. Spot 25sx, plug from 2600-2400 (5. Spot 25sx, plug from 1000-750 (8. Perf 4 holes at 300, sqz 85sx, plug 7. Install dry hole marker. I hereby certify that the information a grade tank has been/will be constructed or SIGNATURE Type or print name (This space for State use)	Appropriate Box to Indicate NTENTION TO: PLUG AND ABANDON CHANGE PLANS MULTIPLE COMPLETION deted operations. (Clearly state all rk). SEE RULE 1103. For Multiple RU. st, plug from 4188-4000 (San Andres) Ww/25# gel P/BBL. (Yates, B-Salt). 3 5/8 Shoe, T-Salt) WOC Tag. g from 300-Surf, 5 1/2 x 8 5/8 csgs (Surabove is true and complete to the belosed according to NMOCD guidelines [Institute of the complete in the	SUBSECTION OF THE SUBSECTION O	ALTERING CASING ALTERING CASIN

BE NOTIFIED 24 HOU BEGINNING OF PLUGGING OPERATIONS.

PLUGGING & ABANDONMENT WORKSHEET

(2 STRING CSNG)



TD 4710

OPERATOR		U USA I	ارد،	
LEASENAM	WEST. 1	lacuum U	MT	<u> </u>
		WEL	. #	14
SECT	_33TW	N <u>17-5</u>	RNG	34-E
FROM	1980 198	666	EWL	
TD:	4710	FORMATIC	OT @ NC	S. AMDRES
PBTD:		FORMATIC		

	SIZE	SET @	TOC	TOC DET	ERMENED BY
SURFACE	8518	818	SURF	cie	C
INTMED 1					
INTMED 2					
PROD	51/a	4266	850	TS	
	SIZE	TOP	BOT	TOC	DETERMINED BY
LINER 1				L	
LINER 2					ļ
	CUT &	PULL @		TC	P - BOTTOM
INTMED 1			PERFE		•
INTMED 2			OFERRIOLE	4266	<u>- 4710</u>
PROD				[

*REQUIRED PLU	CS DISTRICT
RUSTLER (MENTS)	
YATER	
QUEEN	
CRAYBURG	1
BAN ANDRES	
CAPITAN BEET	
DELAWARE	
BEST CYNACK	
CHESTALCONINGN	
ERMITY CANTON	
BOME BATHO	+
	
OLORETA .	
al Durant.	
TUES	
CABITAND	
ABO	
	-
wc	
PERM	+
ETRANK	-
ATOKA	+
Prosson	
1410	
DEVOSIAN	+
T	

nuo	TYPE	8ACKS	DEPTH
	PLUG	CMINT	
EWALE			
PLUDIN	OH	35 ZKZ	6400'
PLUD # 3	SHOE	20/202	53507-54507
TUDE	CIBP/35'		4800'
eus a	CIBP	25.535	4900
MTD04	STUB	50 5005	3600'-3700'
PLUOFS	RETNR SQZ	200 202	400
PLUD46	SURF	10 505	0-10
MLUD41	S. AMBRES	25	4188
MTTG 3	B-SALT	25	2600
PLUDES	85/85HE		1000
PL0064	SULF	85	300
RUDES			
PLES # 1			
яшол т			
12069			
rworr			
PLUO 6 10			
MUD .			
PLUID 6			
			<u> </u>
	·	J	
		1	