

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEYCOPY TO 3.6  
SUBMIT IN TRIPlicate\*  
(Other instructions on re-  
verse side)Form approved.  
Budget Bureau No. 42-R1424.

## SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER		5. LEASE DESIGNATION AND SERIAL NO. <b>NM 4039-B</b>
2. NAME OF OPERATOR <b>BTA Oil Producers</b>		6. IF INDIAN, ALLOTTEE OR TRIBE NAME
3. ADDRESS OF OPERATOR <b>104 S. Deceas, Midland, Texas 79701</b>		7. UNIT AGREEMENT NAME
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface <b>"H" 1980' FNL &amp; 660' FNL</b>		8. FARM OR LEASE NAME <b>Will 693 Ltd.</b>
14. PERMIT NO.		9. WELL NO. <b>2</b>
15. ELEVATIONS (Show whether DF, RT, GR, etc.)		10. FIELD AND POOL, OR WILDCAT <b>Vada Penn</b>
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA <b>8-5</b> <b>Sec. 34, 35-E N44M</b>
		12. COUNTY OR PARISH <b>Roosevelt</b>
		13. STATE <b>New Mexico</b>

## 16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

## NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON\*

CHANGE PLANS

## SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT\*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

## 17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Plugging Procedure

1. Moved in Permian Basin Casing Pullers.
2. Layed down 318 jts of 2-7/8" tbg & Model "R" DG pkr.  
Set CIBP @ 9700' w/3 ex cmt on top.
3. Shot 5-1/2" csg @ 8033'. Rec 8033' of 5-1/2" csg.  
Set 50 ex cmt @ 7992', 50 ex @ 5432' & 50 ex @ 4030'.
4. Shot 8-5/8" csg @ 4131'. Rec 1431' of 8-5/8" csg.  
Set 50 ex @ 1431', 50 ex @ 390'. & 10 ex @ surface.
5. Installed dry hole marker.

P &amp; A

1-7-74

## 18. I hereby certify that the foregoing is true and correct

SIGNED

*J. Jones*

TITLE

Prod. Clerk, J. Jones

DATE

1-9-74

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

APPROVED

NOV 29 1974

ARTHUR R. BROWN  
DISTRICT ENGINEER

\*See Instructions on Reverse Side