

Form 310-1  
01-1989

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

FOURTH EDITION  
Budget Bureau No. 1044-10-1  
Expires: March 31, 1993

**SUNDRY NOTICES AND REPORTS ON WELLS**

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals

5. Lease Designation and Serial No.

NM-0554967

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Government "K" #2

9. API Well No.

30-025-29749

10. Field and Pool, or Exploratory Area  
Querecho Plains  
Upper Bone Springs

11. County or Parish, State

Lea

**SUBMIT IN TRIPLICATE**

1. Type of Well

☐ Oil Well ☐ Gas Well ☒ Other

2. Name of Operator

Mewbourne Oil Company

3. Address and Telephone No.

P.O. Box 5270 Hobbs, New Mexico 88241 (505) 393-5905

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1950' FSL & 1980' FWL  
Sec. 23 T18S R32E

**12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA**

**TYPE OF SUBMISSION**

☒ Notice of Intent

☒ Subsequent Report

☐ Final Abandonment Notice

**TYPE OF ACTION**

☐ Abandonment

☐ Recompletion

☐ Plugging Back

☐ Casing Repair

☐ Altering Casing

☐ Other

☐ Change of Plans

☐ New Construction

☐ Non-Routine Fracturing

☐ Water Shut-Off

☒ Conversion to Injection

☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

→ date work expected to begin.

8-10-92 RU well service rig. POOH w/rods & tbg. RIH w/packer to 4900'<sup>±</sup>  
8-11-92 Establish an injection rate & squeeze Delaware formation @ 4859'<sup>±</sup>.  
8-12-92 RIH w/bit and drill out cement. Pressure test squeeze. RIH and drill out CIBP @ 8340' to open Bone Springs perfs (8343'-8515')  
8-13-92 Pump into Bone Spring establish unjection rate and run oriented seismic tools on wireline.  
8-14-92 RIH w/Otis Perma-latch packer and set @ 8250' for injection.

14. I hereby certify that the foregoing is true and correct

Signed

*Brad Hummer*

Title Engineer

Date August 7, 1992

(This space for Federal or State office use)

Approved by

*Chandra J. Shaw*

Title

PETROLEUM ENGINEER

Date

8/7/92

Conditions of approval, if any:

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

\*See Instruction on Reverse Side