Office District I  State of New Mexico Energy, Minerals and Natural Resources	Form C-103 March 4, 2004
1625 N. French Dr., Hobbs, NM 88240 District II	WELL API NO.
1301 W. Grand Ave., Artesia, NM 88210 OIL CONSERVATION DIVISION	30-025-02183 5. Indicate Type of Lease
District III 1000 Rio Brazos Rd., Aztec, NM 87410  1220 South St. Francis Dr.	STATE 7 FEE
District IV Santa Fe, NM 87505 1220 S. St. Francis Dr., Santa Fe, NM	6. State Oil & Gas Lease No.
87505	B-7998
SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH	7. Lease Name or Unit Agreement Name  West Vacuum Unit
PROPOSALS.)  1. Type of Well:	8. Well Number
Oil Well Gas Well Other Injector T&A'd	7
2. Name of Operator	9. OGRID Number
Chevron USA Inc	3. OGRID Number
3. Address of Operator	10. Pool name or Wildcat
15 Smith Rd, Midland, TX 79705 4. Well Location	Vacuum Grayburg San Andres
4. Well Location	
Unit Letter C : 990 feet from the North line and	feet from theline
Section 33 Township 17-S Range 34-E	NMPM Lea County
11. Elevation (Show whether DR, RKB, RT, GR	etc.)
Pit or Below-grade Tank Application (For pit or below-grade tank closures, a form C-144 must be a	tached)
Pit Location: UL C Sect 33 Twp 17S Rng 34E Pit type Steel Depth to Groundw	
Distance from nearest surface water Below-grade Tank Location UL Sect_	
990 feet from the North line and 2310 feet from the West line (Steel Tank)	,
12. Check Appropriate Box to Indicate Nature of Not	ing Demant on Other Dete
12. Check Appropriate Box to indicate Nature of Not	
	UBSEQUENT REPORT OF:
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK   PLUG AND ABANDON   REMEDIAL V	SUBSEQUENT REPORT OF:  WORK
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK   PLUG AND ABANDON   REMEDIAL V  TEMPORARILY ABANDON   CHANGE PLANS   COMMENCE	SUBSEQUENT REPORT OF:  WORK ALTERING CASING DEPLOYED  ABANDONMENT
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK   PLUG AND ABANDON   REMEDIAL V  TEMPORARILY ABANDON   CHANGE PLANS   COMMENCE	BUBSEQUENT REPORT OF: WORK
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK   PLUG AND ABANDON   REMEDIAL N  TEMPORARILY ABANDON   CHANGE PLANS   COMMENCE PULL OR ALTER CASING   MULTIPLE   CASING TES COMPLETION   OTHER:	BUBSEQUENT REPORT OF: WORK ALTERING CASING DESCRIPTION
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON COMMENCE  TEMPORARILY ABANDON CHANGE PLANS COMMENCE  PULL OR ALTER CASING MULTIPLE COMPLETION CASING TES CEMENT JO  OTHER:  13. Describe proposed or completed operations. (Clearly state all pertinent detail	SUBSEQUENT REPORT OF:  NORK ALTERING CASING ALTERING ALTERING CASING ALTERING ALTERI
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON COMMENCE  TEMPORARILY ABANDON CHANGE PLANS COMMENCE  PULL OR ALTER CASING MULTIPLE COMPLETION CASING TEST CEMENT JOURNAL COMPLETION  OTHER:  13. Describe proposed or completed operations. (Clearly state all pertinent details of starting any proposed work). SEE RULE 1103. For Multiple Completions	BUBSEQUENT REPORT OF:  VORK ALTERING CASING DEPLOYED AND ABANDONMENT  ST AND BE  s, and give pertinent dates, including estimated date and all the completion of the completio
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON COMMENCE  TEMPORARILY ABANDON CHANGE PLANS COMMENCE  PULL OR ALTER CASING MULTIPLE COMPLETION CEMENT JO  OTHER:  OTHER:  OTHER:  Notified OCD with P&A intent.	BUBSEQUENT REPORT OF:  VORK ALTERING CASING DEPLOY AND ABANDONMENT  ST AND BE  s, and give pertinent dates, including estimated date and the completion of proposed completion and the completion of t
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON COMMENCE  TEMPORARILY ABANDON CHANGE PLANS COMMENCE  PULL OR ALTER CASING MULTIPLE CASING TEST  COMPLETION CHANGE TEST  COMPLETION OTHER:  13. Describe proposed or completed operations. (Clearly state all pertinent details of starting any proposed work). SEE RULE 1103. For Multiple Completions or recompletion.  1. Notified OCD with P&A intent. 2. RIH Tag CIBP at 4215, spot 25sx, plug from 4215-4000 (San Andres) WOC Tag at 3964.	BUBSEQUENT REPORT OF:  VORK ALTERING CASING DEPLOY AND ABANDONMENT  ST AND BE  s, and give pertinent dates, including estimated date  Attach wellbore diagram of proposed completion
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON COMMENCE PULL OR ALTER CASING MULTIPLE COMPLETION CEMENT JO OTHER: OTHER:  13. Describe proposed or completed operations. (Clearly state all pertinent detail of starting any proposed work). SEE RULE 1103. For Multiple Completions or recompletion.  1. Notified OCD with P&A intent. 2. RIH Tag CIBP at 4215, spot 25sx, plug from 4215-4000 (San Andres) WOC Tag at 3964. 3. Displace hole w/MLF, 9.5# Brine w/12.5# gel P/BBL. 4. Spot 25sx, plug from 2600-2400 (Yates, B-Salt).	BUBSEQUENT REPORT OF:  VORK ALTERING CASING DEPLOYED AND ABANDONMENT  ST AND BE  s, and give pertinent dates, including estimated date and all the completion of the completio
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON COMMENCE PULL OR ALTER CASING MULTIPLE CASING TES COMPLETION CHANGE PLANS OTHER:  13. Describe proposed or completed operations. (Clearly state all pertinent detail of starting any proposed work). SEE RULE 1103. For Multiple Completions or recompletion.  1. Notified OCD with P&A intent. 2. RIH Tag CIBP at 4215, spot 25sx, plug from 4215-4000 (San Andres) WOC Tag at 3964. 3. Displace hole w/MLF, 9.5# Brine w/12.5# gel P/BBL. 4. Spot 25sx, plug from 2600-2400 (Yates, B-Salt). 5. Perf 4 holes at 1000, sqz 30sx, plug (8 5/8 Shoe, T-Salt) WOC Tag at 760.	BUBSEQUENT REPORT OF:  VORK ALTERING CASING DEPLOY AND ABANDONMENT  ST AND BE  s, and give pertinent dates, including estimated date and the state of proposed completion and the state of proposed
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON COMMENCE PULL OR ALTER CASING MULTIPLE COMPLETION CEMENT JO OTHER: OTHER:  13. Describe proposed or completed operations. (Clearly state all pertinent detail of starting any proposed work). SEE RULE 1103. For Multiple Completions or recompletion.  1. Notified OCD with P&A intent. 2. RIH Tag CIBP at 4215, spot 25sx, plug from 4215-4000 (San Andres) WOC Tag at 3964. 3. Displace hole w/MLF, 9.5# Brine w/12.5# gel P/BBL. 4. Spot 25sx, plug from 2600-2400 (Yates, B-Salt).	BUBSEQUENT REPORT OF: WORK ALTERING CASING DEPLOY AND ABANDONMENT  ST AND BB  s, and give pertinent dates, including estimated date  Attach wellbore diagram of proposed completion
NOTICE OF INTENTION TO:  PERFORM REMEDIAL WORK  PLUG AND ABANDON  REMEDIAL N  TEMPORARILY ABANDON  CHANGE PLANS  COMMENCE  PULL OR ALTER CASING  MULTIPLE  CASING TES  COMPLETION  CEMENT JO  OTHER:  OTHER:  13. Describe proposed or completed operations. (Clearly state all pertinent detail of starting any proposed work). SEE RULE 1103. For Multiple Completions or recompletion.  1. Notified OCD with P&A intent. 2. RIH Tag CIBP at 4215, spot 25sx, plug from 4215-4000 (San Andres) WOC Tag at 3964. 3. Displace hole w/MLF, 9.5# Brine w/12.5# gel P/BBL. 4. Spot 25sx, plug from 2600-2400 (Yates, B-Salt). 5. Perf 4 holes at 1000, sqz 30sx, plug (8 5/8 Shoe, T-Salt) WOC Tag at 760. 6. Perf 4 holes at 300, sqz 92sx, plug from 300-Surf, 5 1/2 x 8 5/8 csgs (Surf) WOC Tag at 57. Install dry hole marker 12-31-04.  I hereby certify that the information above is true and complete to the best of my know	BUBSEQUENT REPORT OF:  VORK ALTERING CASING AL
NOTICE OF INTENTION TO:  PERFORM REMEDIAL WORK □ PLUG AND ABANDON □ REMEDIAL N  TEMPORARILY ABANDON □ CHANGE PLANS □ COMMENCE  PULL OR ALTER CASING □ MULTIPLE □ CASING TES  COMPLETION □ CHANGE TES  OTHER: □ OTHER:  13. Describe proposed or completed operations. (Clearly state all pertinent detail of starting any proposed work). SEE RULE 1103. For Multiple Completions or recompletion.  1. Notified OCD with P&A intent. 2. RIH Tag CIBP at 4215, spot 25sx, plug from 4215-4000 (San Andres) WOC Tag at 3964. 3. Displace hole w/MLF, 9.5# Brine w/12.5# gel P/BBL. 4. Spot 25sx, plug from 2600-2400 (Yates, B-Salt). 5. Perf 4 holes at 1000, sqz 30sx, plug (8 5/8 Shoe, T-Salt) WOC Tag at 760. 6. Perf 4 holes at 300, sqz 92sx, plug from 300-Surf, 5 1/2 x 8 5/8 csgs (Surf) WOC Tag at 8 7. Install dry hole marker 12-31-04.  I hereby certify that the information above is true and complete to the best of my know grade tank has been/will be constructed or closed according to NMOCD guidelines □, a general perm	SUBSEQUENT REPORT OF:  VORK
PERFORM REMEDIAL WORK  PLUG AND ABANDON  REMEDIAL N  TEMPORARILY ABANDON  CHANGE PLANS  COMMENCE  PULL OR ALTER CASING  MULTIPLE  CASING TES  COMPLETION  CHANGE PLANS  COMMENCE  OTHER: OTHER:  13. Describe proposed or completed operations. (Clearly state all pertinent detail of starting any proposed work). SEE RULE 1103. For Multiple Completions or recompletion.  1. Notified OCD with P&A intent. 2. RIH Tag CIBP at 4215, spot 25sx, plug from 4215-4000 (San Andres) WOC Tag at 3964. 3. Displace hole w/MLF, 9.5# Brine w/12.5# gel P/BBL. 4. Spot 25sx, plug from 2600-2400 (Yates, B-Salt). 5. Perf 4 holes at 1000, sqz 30sx, plug (8 5/8 Shoe, T-Salt) WOC Tag at 760. 6. Perf 4 holes at 300, sqz 92sx, plug from 300-Surf, 5 1/2 x 8 5/8 csgs (Surf) WOC Tag at 57. Install dry hole marker 12-31-04.  I hereby certify that the information above is true and complete to the best of my know grade tank has been/will be constructed or closed according to NMOCD guidelines , a general perm	BUBSEQUENT REPORT OF:  VORK ALTERING CASING AL
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL N  TEMPORARILY ABANDON CHANGE PLANS COMMENCE  PULL OR ALTER CASING MULTIPLE CASING TES  COMPLETION CHANGE TES  COMPLETION CHANGE TES  OTHER:  13. Describe proposed or completed operations. (Clearly state all pertinent detail of starting any proposed work). SEE RULE 1103. For Multiple Completions or recompletion.  1. Notified OCD with P&A intent. 2. RIH Tag CIBP at 4215, spot 25sx, plug from 4215-4000 (San Andres) WOC Tag at 3964. 3. Displace hole w/MLF, 9.5# Brine w/12.5# gel P/BBL. 4. Spot 25sx, plug from 2600-2400 (Yates, B-Salt). 5. Perf 4 holes at 1000, sqz 30sx, plug (8 5/8 Shoe, T-Salt) WOC Tag at 760. 6. Perf 4 holes at 300, sqz 30sx, plug from 300-Surf, 5 1/2 x 8 5/8 csgs (Surf) WOC Tag at 57. Install dry hole marker 12-31-04.  I hereby certify that the information above is true and complete to the best of my know grade tank has been/will be constructed or closed according to NMOCD guidelines , a general perm	BUBSEQUENT REPORT OF: NORK ALTERING CASING ALTERING CASING ALTERING CASING ALTERING CASING ABANDONMENT  BE ABANDONMENT  Str AND BE ABANDONMENT  STR AN
NOTICE OF INTENTION TO:  PERFORM REMEDIAL WORK  PLUG AND ABANDON  REMEDIAL N  TEMPORARILY ABANDON  CHANGE PLANS  COMMENCE  PULL OR ALTER CASING  MULTIPLE  CASING TEST  COMPLETION  CEMENT JO  OTHER:  13. Describe proposed or completed operations. (Clearly state all pertinent detail of starting any proposed work). SEE RULE 1103. For Multiple Completions or recompletion.  1. Notified OCD with P&A intent. 2. RIH Tag CIBP at 4215, spot 25sx, plug from 4215-4000 (San Andres) WOC Tag at 3964. 3. Displace hole w/MLF, 9.5# Brine w/12.5# gel P/BBL. 4. Spot 25sx, plug from 2600-2400 (Yates, B-Salt). 5. Perf 4 holes at 1000, sqz 30sx, plug (8 5/8 Shoe, T-Salt) WOC Tag at 760. 6. Perf 4 holes at 300, sqz 92sx, plug from 300-Surf, 5 1/2 x 8 5/8 csgs (Surf) WOC Tag at 57. Install dry hole marker 12-31-04.  I hereby certify that the information above is true and complete to the best of my know grade tank has been/will be constructed or closed according to NMOCD guidelines , a general perm SIGNATURE TITLE Cons	ALTERING CASING DELIGION DATE 12-31-04
NOTICE OF INTENTION TO:  PERFORM REMEDIAL WORK  PLUG AND ABANDON  REMEDIAL N  TEMPORARILY ABANDON  CHANGE PLANS  COMMENCE  PULL OR ALTER CASING  MULTIPLE  CASING TEST  COMPLETION  CEMENT JO  OTHER:  13. Describe proposed or completed operations. (Clearly state all pertinent detail of starting any proposed work). SEE RULE 1103. For Multiple Completions or recompletion.  1. Notified OCD with P&A intent. 2. RIH Tag CIBP at 4215, spot 25sx, plug from 4215-4000 (San Andres) WOC Tag at 3964. 3. Displace hole w/MLF, 9.5# Brine w/12.5# gel P/BBL. 4. Spot 25sx, plug from 2600-2400 (Yates, B-Salt). 5. Perf 4 holes at 1000, sqz 30sx, plug (8 5/8 Shoe, T-Salt) WOC Tag at 760. 6. Perf 4 holes at 300, sqz 92sx, plug from 300-Surf, 5 1/2 x 8 5/8 csgs (Surf) WOC Tag at 57. Install dry hole marker 12-31-04.  I hereby certify that the information above is true and complete to the best of my know grade tank has been/will be constructed or closed according to NMOCD guidelines , a general perm SIGNATURE TITLE Cons	SUBSEQUENT REPORT OF:  NORK   ALTERING CASING    DRILLING OPNS   PLUG AND ABANDONMENT  ST AND   B  St, and give pertinent dates, including estimated date  Attach wellbore diagram of proposed completion  Surf.  Surf.  Ledge and belief. I further certify that any pit or belowit   or an (attached) alternative OCD-approved plan   DATE   12-31-04  Telephone No. 432-561-8600
NOTICE OF INTENTION TO:  PERFORM REMEDIAL WORK  PLUG AND ABANDON  REMEDIAL N  TEMPORARILY ABANDON  CHANGE PLANS  COMMENCE  PULL OR ALTER CASING  MULTIPLE  CASING TEST CEMENT JO  OTHER:  OTHER:  13. Describe proposed or completed operations. (Clearly state all pertinent detail of starting any proposed work). SEE RULE 1103. For Multiple Completions or recompletion.  1. Notified OCD with P&A intent. 2. RIH Tag CIBP at 4215, spot 25sx, plug from 4215-4000 (San Andres) WOC Tag at 3964. 3. Displace hole w/MLF, 9.5# Brine w/12.5# gel P/BBL. 4. Spot 25sx, plug from 2600-2400 (Yates, B-Salt). 5. Perf 4 holes at 1000, sqz 30sx, plug (8 5/8 Shoe, T-Salt) WOC Tag at 760. 6. Perf 4 holes at 300, sqz 92sx, plug from 300-Surf, 5 1/2 x 8 5/8 csgs (Surf) WOC Tag at 8. 7. Install dry hole marker 12-31-04.  I hereby certify that the information above is true and complete to the best of my know grade tank has been/will be constructed or closed according to NMOCD guidelines  a general perm  SIGNATURE  TITLE  Cons  Type or print name  TITLE  Cons  Type or print name  E-mail address:	BUBSEQUENT REPORT OF:  VORK   ALTERING CASING    DRILLING OPNS   PLUG AND ABANDONMENT  ST AND   ABANDONMENT  St, and give pertinent dates, including estimated date  Attach wellbore diagram of proposed completion  Surf.  Surf.  Ledge and belief. I further certify that any pit or belowit   or an (attached) alternative OCD-approved plan    Ultant   DATE   12-31-04  Telephone No. 432-561-8600
NOTICE OF INTENTION TO:  PERFORM REMEDIAL WORK  PLUG AND ABANDON  COMMENCE  PULL OR ALTER CASING  MULTIPLE  CASING TES  COMPLETION  COMPLETION  PLUG AND ABANDON  COMMENCE  OTHER:  OTHER:  13. Describe proposed or completed operations. (Clearly state all pertinent detail of starting any proposed work). SEE RULE 1103. For Multiple Completions or recompletion.  1. Notified OCD with P&A intent. 2. RiH Tag CIBP at 4215, spot 25sx, plug from 4215-4000 (San Andres) WOC Tag at 3964. 3. Displace hole w/MLF, 9.5# Brine w/12.5# gel P/BBL. 4. Spot 25sx, plug from 2600-2400 (Yates, B-Salt). 5. Perf 4 holes at 3000, sqz 30sx, plug (8 5/8 Shoe, T-Salt) WOC Tag at 760. 6. Perf 4 holes at 3000, sqz 92sx, plug from 300-Surf, 5 1/2 x 8 5/8 csgs (Surf) WOC Tag at 37. Install dry hole marker 12-31-04.  I hereby certify that the information above is true and complete to the best of my know grade tank has been/will be constructed or closed according to NMOCD guidelines , a general perm SIGNATURE  TITLE  Constructed or State use)  APPPROVED BY  E-mail address:  (This space for State use)	SUBSEQUENT REPORT OF:  NORK   ALTERING CASING    DRILLING OPNS   PLUG AND ABANDONMENT  ST AND   ABANDONMENT  ST, and give pertinent dates, including estimated date and give pertinent dates, including estimated date are attach wellbore diagram of proposed completion  Surf.  Ledge and belief. I further certify that any pit or belowit   or an (attached) alternative OCD-approved plan    Ultant   DATE   12-31-04  Telephone No. 432-561-8600
NOTICE OF INTENTION TO:  PERFORM REMEDIAL WORK  PLUG AND ABANDON  COMMENCE  PULL OR ALTER CASING  MULTIPLE  CASING TES  COMPLETION  COMPLETION  COMPLETION  OTHER:  13. Describe proposed or completed operations. (Clearly state all pertinent detail of starting any proposed work). SEE RULE 1103. For Multiple Completions or recompletion.  1. Notified OCD with P&A intent. 2. RIH Tag CIBP at 4215, spot 25sx, plug from 4215-4000 (San Andres) WOC Tag at 3964. 3. Displace hole w/MLF, 9.5# Brine w/12.5# gel P/BBL. 4. Spot 25sx, plug from 2600-2400 (Yates, B-Salt). 5. Perf 4 holes at 1000, sqz 30sx, plug (8 5/8 Shoe, T-Salt) WOC Tag at 760. 6. Perf 4 holes at 300, sqz 92sx, plug from 300-Surf, 5 1/2 x 8 5/8 csgs (Surf) WOC Tag at 37. Install dry hole marker 12-31-04.  I hereby certify that the information above is true and complete to the best of my know grade tank has been/will be constructed or closed according to NMOCD guidelines , a general perm SIGNA TURE TITLE Constructed or Closed according to NMOCD guidelines , a general perm SIGNA TURE TITLE Constructed or Closed according to SIGNA TURE TITLE CONSTRUCTED TITLE SIGNA TURE TITLE SIGN	SUBSEQUENT REPORT OF:  NORK