

JUL 25 2011

## New Mexico Oil Conservation Division, District I

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT  
1625 N. French Drive  
Hobbs, NM 88240FORM APPROVED  
OMB No. 1004-0137  
Expires: March 31, 2007

## SUNDRY NOTICES AND REPORTS ON WELLS

**RECEIVED**  
Do not use this form for proposals to drill or to re-enter an abandoned well. Use Form 3160-3 (APD) for such proposals.**SUBMIT IN TRIPLICATE- Other instructions on reverse side.**

|  |   |  |
|--|---|--|
| 1. Type of Well<br><input checked="" type="checkbox"/> Oil Well <input type="checkbox"/> Gas Well <input type="checkbox"/> Other |   | 5. Lease Serial No.<br>NM-046153-A                             |
| 2. Name of Operator<br>Barry D. Lee dba Barry Lee Investments  |   | 6. If Indian, Allottee or Tribe Name                           |
| 3a. Address<br>HC 65 Box 222 Crossroads, New Mexico 88114  | 3b. Phone No. (include area code)<br>575-370-8840 | 7. If Unit or CA/Agreement, Name and/or No.                    |
| 4. Location of Well (Footage, Sec., T., R., M., or Survey Description)<br>530 FNL X 990 FWL, Section 34, T07S, R31E NMPM D       |   | 8. Well Name and No.<br>Western Reserves 34 Federal # 4        |
|  |   | 9. API Well No.<br>30-005-20760                                |
|  |   | 10. Field and Pool, or Exploratory Area<br>Tom Tom; San Andres |
|  |   | 11. County or Parish, State<br>Chaves County, New Mexico       |

## 12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

| TYPE OF SUBMISSION                                   | TYPE OF ACTION                                |  |  |   |
|--|---|--|--|---|
| <input checked="" type="checkbox"/> Notice of Intent | <input type="checkbox"/> Acidize              | <input type="checkbox"/> Deepen                      | <input type="checkbox"/> Production (Start/Resume) | <input type="checkbox"/> Water Shut-Off |
| <input type="checkbox"/> Subsequent Report           | <input type="checkbox"/> Alter Casing         | <input type="checkbox"/> Fracture Treat              | <input type="checkbox"/> Reclamation               | <input type="checkbox"/> Well Integrity |
| <input type="checkbox"/> Final Abandonment Notice    | <input type="checkbox"/> Casing Repair        | <input type="checkbox"/> New Construction            | <input type="checkbox"/> Recomplete                | <input type="checkbox"/> Other          |
|  | <input type="checkbox"/> Change Plans         | <input checked="" type="checkbox"/> Plug and Abandon | <input type="checkbox"/> Temporarily Abandon       |   |
|  | <input type="checkbox"/> Convert to Injection | <input type="checkbox"/> Plug Back                   | <input type="checkbox"/> Water Disposal            |   |

13. Describe Proposed or Completed Operation (clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof. If the proposal is to deepen directionally or recompleat horizontally, give subsurface locations and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompleat in a new interval, a Form 3160-4 shall be filed once testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the site is ready for final inspection.)

Barry Lee Investments proposes to plug and abandon the Western Reserves 34 Federal # 4  
Enclosures; PA procedure, Before PA and After PA well diagram, NMOCD form C144 CLEZ, design, operation, closure plan  
8 5/8" 24# casing set at 1463 feet in 12 1/4" hole, cemented with 450 sacks Howco Lite fb 200 sacks Class "C"  
4 1/2" 10.5# casing set at 3974 feet in 7 7/8" hole, cemented with 300 sacks 50/50 Poz Mix  
Top of cement calculated at 2795 feet.  
San Andres Perforations 3877-3910 feet  
Cast Iron Bridge Plug set at 3777 feet

APPROVED FOR 3 MONTH PERIOD  
ENDING OCT 18 2011

14. I hereby certify that the foregoing is true and correct  
Name (Printed/Typed)

Barry Lee

Title Owner/ Manager

Signature

Date

06/20/2011

## THIS SPACE FOR FEDERAL OR STATE OFFICE USE

|   |                    |                         |
|---|--------------------|-------------------------|
| Approved by <u>/S/ DAVID R. GLASS</u>   | PETROLEUM ENGINEER | Date <u>JUL 18 2011</u> |
| Conditions of approval, if any, are attached. Approval of this notice does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease which would entitle the applicant to conduct operations thereon. |                    | Office                  |

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

(Instructions on page 2)

**SEE ATTACHED FOR  
CONDITIONS OF APPROVAL**

**Barry D. Lee dba Barry Lee Investments  
Western Reserves 34 Federal # 4  
API 30-005-20760  
530 FNL x 990 FWL  
Section 34, T07S, R31E, NMPM  
Chaves County, New Mexico**

**Proposed Plugging Procedure**

**Run tubing open ended x tag CIBP at 3777 feet x Spot 25 sack cement x WOC  
Tag cement plug at estimated 3400ft  
Displace well with (9.5 lb/gallon) gelled brine water  
Pull tubing  
Perforate at 1960 feet x Run packer and set at 1750 feet  
Squeeze with 40 sacks cement x WOC x Release packer  
Tag cement plug at 1860 feet  
Perforate at 1513 feet x Run packer and set at 1300 feet  
Squeeze with 40 sacks cement x WOC x Release packer  
Tag cement plug at 1413 feet  
Perforate at 350 feet  
Break circulation through 8 5/8" x 4 1/2" annulus  
Circulate cement to the surface through 4 1/2" casing. Estimated 90 sacks cement  
Leave well full of cement  
Cut off well head x install plug and abandon plate below ground level  
Clean and prepare location for release.**



