Submit 1 Copy To Appropriate District Of	fine						HOBBS	OCD- RECEIVED) 11/23/:	20	
Submit I Copy To Appropriate District Of	lice		State of	New	Mexic	0			F	⁷ orm ¹	C-103
<u>District I</u> - (575) 393-6161		Energy, Minerals and Natural Resources			Revised July 18,2013						
1625 N. French Dr., Hobbs, NM 88240					WELL API NO. 30.025.25209						
<u>District II</u> - (575) 748-1283 811 S. First St., Artesia, NM 88210		OIL C	CONSERV	VATI	ON DI	VISION	5. Indicat	e Type of Leas	25209 Se		
<u>Disrtict III - (505) 334-6178</u>		1220 South St. Francis Dr.				ATE		FEE			
1000 Rio Brazos Rd. Aztec, NM 87410										FEE	
District IV - (505) 476-3460	05	Santa Fe, NM 87505			6. State Oil & Gas Lease No.						
1220 S. St. Francis Dr., Santa Fe, NM 875						B-934-13					
		S AND REPO					7. Lease I	Name or Unit A	Agreeme	ent Nai	me
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR DEEPEN OR PLUG BACK TO A DIFFERENT RESERVIOR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)					State PA						
RESERVIOR. USE AFFLICATION FOR	TERMIT	(FORM C-101)	OK SUCH F	KUFUSP	чL3.)		8. Well N	umber			
1. Type of Well: Oil Well 🔽 Gas Well 🗌 Other					#003						
2. Name of Operator	_						9. OGRII				
	Apac	he Corporati	on					873	-		
3. Address of Operator					10. Pool Name or Wildcat						
303 Veterans Air	rpark L	ane, Ste. 300	0, Midland	d, TX 7	79705			Drink	ard		
4. Well Location		2100	C	41.	Б	1 1	(())	Court Court	N	1	
Unit Letter B		: 2100	feet from		E	line and	660	feet from t	N	line	
Section 1'		Township 1. Elevation (S	22S	Ran	0	37E	NMPM		ounty		LEA
	1	1. Elevation (5)	now whethe	3319	,	, GK, elc.)					
12. 0	Check A	Appropriate B	ox To Indi	cate N	lature o	of Notice, Re	port, or O	ther Data			
NOTICE OF I	NTENT	ION TO:				SUB	SEQUEN	REPORT O)F:		
PERFORM REMEDIAL WORK	F	LUG AND ABA	NDON	🔁 REI	MEDIAL	WORK		ALTERING	CASIN	G	
TEMPORARILY ABANDON		HANGE PLAN	s [MMENC	CE DRILLING	opns.	P AND A			
PULL OR ALTER CASING	<u> </u>	IULTIPLE COM	IPL [SING/C	EMENT JOB					
DOWNHOLE COMMINGLE											
CLOSED-LOOP SYSTEM				_							_
OTHER:			[ΟΤΙ	HER:						

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work.) SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram or proposed completion or recompletion.

4" diameter 4' tall above ground marker

Apache Corporation proposes to P&A the above mentioned well by the attached procedure. A closed loop system will be used for all fluids from this wellbore and disposed of required by OCD Rule 19.15.17.14 NMAC.

Spud Date:			Rig Release Date:	See Atta litions o	ched f Approval
I hereby certify that the in	nformation above is true an	d complete to	o the best of my knowledge and	belief.	
SIGNATURE	Guínn Burks	TITLE	Sr. Reclamation Foreman	DATE	11/19/20
Type or print name	Guinn Burks	E-mail add.	guinn.burks@apachecorp.com	PHONE:	432-556-9143
For State Use Only APPROVED BY: Yu Conditions of Approval (if a	my Fortner	TITLE	Compliance Officer A	DATE	11/30/20

		LEASE NAME	State PA
		WELL # API #	#003 30.025.25209
	Apache	COUNTY	LEA, NM
	WELL BORE INFO.		
0	WEEL DOKE IN O.		
665	11" Hole		
1330	8 5/8" 24# @ 1175' w/ 450 sx CRIC to surf		
1995			
2660			
3325	DVT @ 3904'		
3989			
4654			
5319	CIBP @ 5425' w/ no cmt	P	erfs @ 5471'-5975'
5984	CIBP @ 6400' w/ 4 sx cmt		
6649	7 7/8" Hole 5 1/2" 15.5# @ 6649' w/ 1900 sx CIRC to surf	PBTD @ 5425' TD @ 6649'	erfs @ 6460'-6533'

		LEASE NAME WELL #	State PA #003
	Apache	API # COUNTY	30.025.25209 LEA, NM
	WELL BORE INFO.		PROPOSED PROCEDURE
0			
665	11" Hole		4. PUH & spot 125 sx Class "C" cmt frm 1225' to surf,
1330	8 5/8" 24# @ 1175' w/ 450 sx CRIC to surf		Fill Up. (Surf Shoe, Top of Salt, Water Board, & Surf Plug)
1995			
2660			
3325			3. PUH & spot 90 sx Class "C" cmt from 3380'-2519', WOC/TAG (Queen, 7 Rvrs, & Yates)
3989	DVT @ 3904'		2. PUH & spot 25 sx Class "C" cmt from 3954'-3754', WOC/TAG (DVT)
4654			1. MIRU P&A rig, RIH w/ Tbg & verify CIBP @ 5425',
5319	CIBP @ 5425' w/ no cmt		CIRC w/ MLF & spot 25 sx Class "C" cmt from 5425'- 5225'. (Drinkard & Blinebry)
5984	CIBP @ 6400' w/ 4 sx cmt		
6649	7 7/8" Hole 5 1/2" 15.5# @ 6649' w/ 1900 sx CIRC to surf	PBTD @ 5425' TD @ 6649'	Perfs @ 6460'-6533'

CONDITIONS OF APPROVAL FOR PLUGGING AND ABANDONMENT OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office I (Hobbs) at (575)-263-6633 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down.

Company representative will be on location during plugging procedures.

1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.

2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.

3. Trucking companies being used to haul oilfield waste fluids to a disposal - commercial or private- shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.

4. Filing a subsequent C-103 will serve as notification that the well has been plugged.

5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can +be released.

6. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.

7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.

8. Produced water will not be used during any part of the plugging operation.

9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.

10. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.

11. Class 'C' cement will be used above 7500 feet.

12. Class 'H' cement will be used below 7500 feet.

13. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged

14. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.

16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set

17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.

18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).

19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.

20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops

- A) Fusselman
- B) Devonian
- C) Morrow
- D) Wolfcamp
- E) Bone Springs
- F) Delaware
- G) Any salt sections
- H) Abo
- I) Glorieta
- J) Yates.

K) Potash---(In the R-111-P Area (Potash Mine Area),

A solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, woe 4 hours and tag, this plug will be SO' below the bottom and 50' above the top of the Formation.

21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, woe and tagged. These plugs will be set SO' below formation bottom to 50' above formation top inside the casing.

DRY HOLE MARKER REQ.UIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least¹/₄" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

- 1. Operator name
- 2. Lease and Well Number
- 3. API Number
- 4. Unit letter
- 5. Quarter Section (feet from the North, South, East or West)
- 6. Section, Township and Range
- 7. Plugging Date
- 8. County

SPECIAL CASES -----AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)