Form 3160-5 (June 2015)

UNITED STATES

CIVILED STITLES
DED A DOWNER OF THE DITTED TOD
DEPARTMENT OF THE INTERIOR
BELLECTIVE OF THE HITEROR
BUREAU OF LAND MANAGEMENT
BUREAU OF LAND MANAGEMENT


	FORM APPROVED
	OMB NO. 1004-0137
	Expires: January 31, 2018
Longo Co	riol No

RI	UKEAU OF LAND MANA	THATHAIL				
SUNDRY	NOTICES AND REPO	RTS ON WE			Lease Serial No. NMLC060944	
Do not use thi abandoned we	is form for proposals to II. Use form 3160-3 (APL	drill or to re- D) for such p	enter an roposals.		6. If Indian, Allottee or	Tribe Name
SUBMIT IN	TRIPLICATE - Other inst	ructions on p	page 2		7. If Unit or CA/Agree NMNM87877X	ment, Name and/or No.
Type of Well ☐ Oil Well ☐ Gas Well ☑ Oth	ner: INJECTION				8. Well Name and No. SJU TR-C 160	
2. Name of Operator LEGACY RESERVES OPERA	Contact:	MELANIE RE	YES		9. API Well No. 30-025-32085-0	D-S1
3a. Address 303 W WALL SUITE 1600 MIDLAND, TX 79702			(include area code)		10. Field and Pool or E JUSTIS	xploratory Area
4. Location of Well (Footage, Sec., T	., R., M., or Survey Description,				11. County or Parish, S	State
Sec 14 T25S R37E SWNE 15	00FNL 2250FEL				LEA COUNTY, N	MM
12. CHECK THE AI	PPROPRIATE BOX(ES)	TO INDICAT	E NATURE OF	F NOTICE,	REPORT, OR OTH	ER DATA
TYPE OF SUBMISSION			TYPE OF	ACTION		
Notice of Intent	☐ Acidize	☐ Deep	en	☐ Product	ion (Start/Resume)	☐ Water Shut-Off
_	☐ Alter Casing	☐ Hydi	aulic Fracturing	☐ Reclam	ation	■ Well Integrity
☐ Subsequent Report	☐ Casing Repair	□ New	Construction	☐ Recomp	olete	☐ Other
☐ Final Abandonment Notice	□ Change Plans	☑ Plug	and Abandon	☐ Tempor	rarily Abandon	
	□ Convert to Injection	☐ Plug	Back	☐ Water I	Disposal	
13. Describe Proposed or Completed Ope If the proposal is to deepen directions Attach the Bond under which the won following completion of the involved testing has been completed. Final At determined that the site is ready for final f	ally or recomplete horizontally, rk will be performed or provide to operations. If the operation responded in the operation is pandonment Notices must be file inal inspection. Circulate hole with MLF. Provided in the operation in the inal inspection. Circulate hole with MLF. Provided in the inal inspection. To a complete horizontally, recommended in the operation responds to the inal inspection. The inspection is the individual of the inal inspection in the inal inspection. The inspection is the inspection of the inspection in the inspection	give subsurface I the Bond No. on sults in a multiple ed only after all ressure test constant (Shoe) Hole Marker.	ocations and measurable file with BLM/BIA completion or recovery construction of the completion of the	PECIAL TTACHE	AL SUBJECT T L REQUIREME STIPULATION	ent markers and zones. filed within 30 days 14 must be filed once and the operator has
	Electronic Submission # For LEGACY RES nmitted to AFMSS for proce	SERVES OPER	ATING LP, sent	to the Hobb 11/19/2020	s	
Signature (Electronic S			Date 11/19/20			
	THIS SPACE FO	OR FEDERA	L OR STATE	OFFICE U	SE	
Approved By			Title			Date
Conditions of approval, if any, are attache certify that the applicant holds legal or eq which would entitle the applicant to conditions.	uitable title to those rights in the	not warrant or subject lease	Office			

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

Author:	Abby-BCM & Associates, Inc		
Well Name	South Justis Unit	Well No.	#C160
Field/Pool	JUSTIS; BLINEBRY-TUBB-DRINKARD	API#:	30-025-32085
County	Lea	Location:	Sec G 14, T25\$ R37E
State	New Mexico	-	1500 FNL & 2250 FEL
Spud Date	11/27/1993	GL:	3124'

Description	O.D.	Grade	Weight	Depth	Hole	Cmt Sx	TOC
Surface Csg	8 5/8	J55	24#	1,012	12 1/4	770	0
Prod Csg	4 1/2	J55	10.5#	5,650	7 7/8	1,500	0



4. Spot 25 sx cmt @ 200-Surface.

8 5/8 24# CSG @ 1,012 Hole Size: 12 1/4

3. Spot 25 sx cmt @ 1062-715'. WOC & Tag (T/Salt & Shoe)

2. Spot 25 sx cmt @ 2325-1975'. WOC & TAg (Yates)

Spot 25 Sx cmt @ 4820 - 4672 (Glorieta@ 4776')
wockTAy

1. Set 4 1/2" CIBP @ 5311'. Circulate hole w/ MLF. Pressure test csg.Spot 25 sx cmt @ 5311-4960'.

Perfs @ 5149-5469'

CIBP @ 5488'

Perts @ 5495-5588'

4 1/2 10.5# CSG @ 5,650 Hole Size: 7 7/8

Printed: 11/13/2020

JUMBIL DU	ustis Unit # C160	BOLO ID: 300054.07.03 API # 3002532085
outh Justic Unit of C	C160, 11/13/2020	1500 FNL & 2250 FEL GL Elev: 3,124.00 KOP:
		Section G 14, Township 25S, Range 37E EOC:
		County, State: Lea, NM Fill Depth:
,		Aux ID: 20960 PBTD: 5,488.0
		'KB' correction: 14; All Depths Corr To: KB TD: 5,650.0
1906 2,000		
3,950		Comments / Completion Summary 12/16/1993: Original completion. Perf: 5149, 53, 59, 67, 69, 70, 79, 83, 86, 95, 5200, 04, 11, 15, 26, 29, 33, 36, 47, 58, 67, 82, 92, 5303, 05, 13, 26, 33, 67, 77, 83, 93, 5414, 15, 17, 28, 35, 59, 69, 78, 95, 5507, 19, 29, 37, 43, 58, 68, 70, 72, 84, and 5588 (52)
100		12/16/1993: Original completion. Perf: 5149, 53, 59, 67, 69, 70, 79, 83, 86, 95, 5200, 04, 11, 15, 26, 29, 33, 36, 47, 58, 67, 82, 92, 5303, 05, 13, 26, 33, 67, 77, 83, 93, 5414, 15, 17, 28, 35, 59, 69, 78, 95, 5507, 19, 29, 37, 43, 58, 68, 70, 72, 84, and 5588 (52' @ 2 SPF). Acid with 10000gal. 2/23/1994: Convert to injection with packer @ 5082. 11/30/2001: Set CIBP @ 5488. Add perfs: 5361 - 69, 89 - 5400, 5411 - 19, 32 - 38, and 55 - 69. Acid on 5361 - 5469 with 3000gal 15%. Sqz perfs 5149 - 5333 with 200sx. CO to 5488 (top of CIBP).
		12/16/1993: Original completion. Perf: 5149, 53, 59, 67, 69, 70, 79, 83, 86, 95, 5200, 04, 11, 15, 26, 29, 33, 36, 47, 58, 67, 82, 92, 5303, 05, 13, 26, 33, 67, 77, 83, 93, 5414, 15, 17, 28, 35, 59, 69, 78, 95, 5507, 19, 29, 37, 43, 58, 68, 70, 72, 84, and 5588 (52' @ 2 SPF). Acid with 10000gal. 2/23/1994: Convert to injection with packer @ 5082. 11/30/2001: Set CIBP @ 5488. Add perfs: 5361 - 69, 89 - 5400, 5411 - 19, 32 - 38, and 55 - 69. Acid on 5361 - 5469 with 3000gal 15%. Sqz perfs 5149 - 5333 with 200sx. CO to 5488 (top of CIBP).
		12/16/1993: Original completion. Perf: 5149, 53, 59, 67, 69, 70, 79, 83, 86, 95, 5200, 04, 11, 15, 26, 29, 33, 36, 47, 58, 67, 82, 92, 5303, 05, 13, 26, 33, 67, 77, 83, 93, 5414, 15, 17, 28, 35, 59, 69, 78, 95, 5507, 19, 29, 37, 43, 58, 68, 70, 72, 84, and 5588 (52' @ 2 SPF). Acid with 10000gal. 2/23/1994: Convert to injection with packer @ 5082. 11/30/2001: Set CIBP @ \$488. Add perfs: \$361 - 69, 89 - 5400, 5411 - 19, 32 - 38, and 55 - 69. Acid on 5361 - 5469 with 3000gal 15%. Sqz perfs 5149 - 5333 with 200sx. Co to 5488 (top of CIBP). Perforations
		12/16/1993: Original completion. Perf: 5149, 53, 59, 67, 69, 70, 79, 83, 86, 95, 5200, 04, 11, 15, 26, 29, 33, 36, 47, 58, 67, 82, 92, 5303, 05, 13, 26, 33, 67, 77, 83, 93, 5414, 15, 17, 28, 35, 59, 69, 78, 95, 5507, 19, 29, 37, 43, 58, 68, 70, 72, 84, and 5588 (52' @ 2 SPF). Acid with 10000gal. 2/23/1994: Convert to injection with packer @ 5082. 11/30/2001: Set CIBP @ \$488. Add perfs: \$361 - 69, 89 - 5400, 5411 - 19, 32 - 38, and 55 - 69. Acid on 5361 - 5469 with 3000gal 15%. Sqz perfs 5149 - 5333 with 200sx. CO to 5488 (top of CIBP). Perforations Top Bottom Formation Status Opened Closed #/Ft Tile
		12/16/1993: Original completion. Perf: 5149, 53, 59, 67, 69, 70, 79, 83, 86, 95, 5200, 04, 11, 15, 26, 29, 33, 36, 47, 58, 67, 82, 92, 5303, 05, 13, 26, 33, 67, 77, 83, 93, 5414, 15, 17, 28, 35, 59, 69, 78, 95, 5507, 19, 29, 37, 43, 58, 68, 70, 72, 84, and 5588 (52' @ 2 SPF). Acid with 10000gal. 2/23/1994: Convert to injection with packer @ 5082. 11/30/2001: Set CIBP @ 5488. Add perfs: 5361 - 69, 89 - 5400, 5411 - 19, 32 - 38, and 55 - 69. Acid on 5361 - 5469 with 3000gal 15%. Sqz perfs 5149 - 5333 with 200sx. Co to 5488 (top of CIBP). Perforations Top Bottom Formation Status Opened Closed #/Ft Ttl
		12/16/1993: Original completion. Perf: 5149, 53, 59, 67, 69, 70, 79, 83, 86, 95, 5200, 04, 11, 15, 26, 29, 33, 36, 47, 58, 67, 82, 92, 5303, 05, 13, 26, 33, 67, 77, 83, 93, 5414, 15, 17, 28, 35, 59, 69, 78, 95, 5507, 19, 29, 37, 43, 58, 68, 70, 72, 84, and 5588 (52' @ 2 SPF). Acid with 10000gal. 2/23/1994: Convert to injection with packer @ 5082. 11/30/2001: Set CIBP @ \$488. Add perfs: \$361 - 69, 89 - 5400, 5411 - 19, 32 - 38, and 55 - 69. Acid on 5361 - 5469 with 3000gal 15%. Sqz perfs 5149 - 5333 with 200sx. Co to 5488 (top of CIBP). Perforations Top Bottom Formation Status Opened Closed #/Ft Tile 0.00 0.00
im:		12/16/1993: Original completion. Perf: 5149, 53, 59, 67, 69, 70, 79, 83, 86, 95, 5200, 04, 11, 15, 26, 29, 33, 36, 47, 58, 67, 82, 92, 5303, 05, 13, 26, 33, 67, 77, 83, 93, 5414, 15, 17, 28, 35, 59, 69, 78, 95, 5507, 19, 29, 37, 43, 58, 68, 70, 72, 84, and 5588 (52' @ 2 SPF). Acid with 10000gal. 2/23/1994: Convert to injection with packer @ 5082. 11/30/2001: Set CIBP @ \$488. Add perfs: \$361 - 69, 89 - 5400, 5411 - 19, 32 - 38, and 55 - 69. Acid on 5361 - 5469 with 3000gal 15%. Sqz perfs 5149 - 5333 with 200sx. CO to 5488 (top of CIBP). Perforations Top Bottom Formation Status Opened Closed #/Ft Tile 0.00 0.00
im:		12/16/1993: Original completion. Perf: 5149, 53, 59, 67, 69, 70, 79, 83, 86, 95, 5200, 04, 11, 15, 26, 29, 33, 36, 47, 58, 67, 82, 92, 5303, 05, 13, 26, 33, 67, 77, 83, 93, 5414, 15, 17, 28, 35, 59, 69, 78, 95, 5507, 19, 29, 37, 43, 58, 68, 70, 72, 84, and 5588 (52' @ 2 SPF). Acid with 10000gal. 2/23/1994: Convert to injection with packer @ 5082. 11/30/2001: Set CIBP @ \$488. Add perfs: \$361 - 69, 89 - 5400, 5411 - 19, 32 - 38, and 55 - 69. Acid on 5361 - 5469 with 3000gal 15%. Sqz perfs 5149 - 5333 with 200sx. CO to 5488 (top of CIBP). Perforations Top Bottom Formation Status Opened Closed #/Ft Tile 0.00 0.00 5,149.00 5,333.00 Blinebry PA 12/16/1993 11/30/2001 2 5 Cmt Sqz 200 sxs 5,361.00 5,369.00 Blinebry A 11/19/2001 1 5,367.00 5,478.00 Blinebry A 12/16/1993 2 4 4 5,389.00 5,400.00 Blinebry A 11/19/2001 1 1
rion:		12/16/1993: Original completion. Perf: 5149, 53, 59, 67, 69, 70, 79, 83, 86, 95, 5200, 04, 11, 15, 26, 29, 33, 36, 47, 58, 67, 82, 92, 5303, 05, 13, 26, 33, 67, 77, 83, 93, 5414, 15, 17, 28, 35, 59, 69, 78, 95, 5507, 19, 29, 37, 43, 58, 68, 70, 72, 84, and 5588 (52' @ 2 SPF). Acid with 10000gal. 2/23/1994: Convert to injection with packer @ 5082. 11/30/2001: Set CIBP @ \$488. Add perfs: \$361 - 69, 89 - 5400, 5411 - 19, 32 - 38, and 55 - 69. Acid on 5361 - 5469 with 3000gal 15%. Sqz perfs 5149 - 5333 with 200sx. CO to 5488 (top of CIBP). Perforations Top Bottom Formation Status Opened Closed #/Ft Tile 0.00 0.00
im:		12/16/1993: Original completion. Perf: 5149, 53, 59, 67, 69, 70, 79, 83, 86, 95, 5200, 04, 11, 15, 26, 29, 33, 36, 47, 58, 67, 82, 92, 5303, 05, 13, 26, 33, 67, 77, 83, 93, 5414, 15, 17, 28, 35, 59, 69, 78, 95, 5507, 19, 29, 37, 43, 58, 68, 70, 72, 84, and 5588 (52' @ 2 SPF). Acid with 10000gal. 2/23/1994: Convert to injection with packer @ 5082. 11/30/2001: Set CIBP @ 5488. Add perfs: 5361 - 69, 89 - 5400, 5411 - 19, 32 - 38, and 55 - 69. Acid on 5361 - 5469 with 3000gal 15%. Sqz perfs 5149 - 5333 with 200sx. CO to 5488 (top of CIBP). Perforations Top Bottom Formation Status Opened Closed #/Ft Ttl @ 0.00
im:		12/16/1993: Original completion. Perf: 5149, 53, 59, 67, 69, 70, 79, 83, 86, 95, 5200, 04, 11, 15, 26, 29, 33, 36, 47, 58, 67, 82, 92, 5303, 05, 13, 26, 33, 67, 77, 83, 93, 5414, 15, 17, 28, 35, 59, 69, 78, 95, 5507, 19, 29, 37, 43, 58, 68, 70, 72, 84, and 5588 (52' @ 2 SPF). Acid with 10000gal. 2/23/1994: Convert to injection with packer @ 5082. 11/30/2001: Set CIBP @ \$488. Add perfs: \$361 - 69, 89 - 5400, 5411 - 19, 32 - 38, and 55 - 69. Acid on 5361 - 5469 with 3000gal 15%. Sqz perfs 5149 - 5333 with 200sx. CO to 5488 (top of CIBP). Perforations Top Bottom Formation Status Opened Closed #/Ft Tile 0.00 0.00 5,333.00 Blinebry PA 12/16/1993 11/30/2001 2 5 Cmt Sqz 200 sxs 5,361.00 5,369.00 Blinebry A 11/19/2001 1 5,367.00 5,478.00 Blinebry A 11/19/2001 1 1 5,411.00 5,419.00 Blinebry A 11/19/2001 1 1 5,432.00 5,438.00 Blinebry A 11/19/2001 1 1 5,432.00 5,438.00 Blinebry A 11/19/2001 1 1 5,432.00 5,489.00 Blinebry A 11/19/2001 1 1 5,455.00 5,489.00 Blinebry A 11/19/2001 1 1 5,495.00 5,588.00 Blinebry A 11/19/2001 1 1 5,495.00 5,588.00 Blinebry A 11/19/2001 2 2 2
1,002 5,000		12/16/1993: Original completion. Perf: 5149, 53, 59, 67, 69, 70, 79, 83, 86, 95, 5200, 04, 11, 15, 26, 29, 33, 36, 47, 58, 67, 82, 92, 5303, 05, 13, 26, 33, 67, 77, 83, 93, 5414, 15, 17, 28, 35, 59, 69, 78, 95, 5507, 19, 29, 37, 43, 58, 68, 70, 72, 84, and 5588 (52' @ 2 SPF). Acid with 10000gal. 2/23/1994: Convert to injection with packer @ 5082. 11/30/2001: Set CIBP @ \$488. Add perfs: \$361 - 69, 89 - 5400, 5411 - 19, 32 - 38, and 55 - 69. Acid on 5361 - 5469 with 3000gal 15%. Sqz perfs 5149 - 5333 with 200sx. CO to 5488 (top of CIBP). Perforations Top Bottom Formation Status Opened Closed #/Ft Tile 0.00 0.00 5,333.00 Blinebry PA 12/16/1993 11/30/2001 2 5 Cmt Sqz 200 sxs 5,361.00 5,369.00 Blinebry A 11/19/2001 1 5,367.00 5,478.00 Blinebry A 11/19/2001 1 1 5,432.00 5,438.00 Blinebry A 11/19/2001 1 1 5,432.00 5,438.00 Blinebry A 11/19/2001 1 5,432.00 5,438.00 Blinebry A 11/19/2001 1 5,432.00 5,489.00 Blinebry A 11/19/2001 1 1 5,455.00 5,469.00 Blinebry A 11/19/2001 1 1
rion:		12/16/1993: Original completion. Perf: 5149, 53, 59, 67, 69, 70, 79, 83, 86, 95, 5200, 04, 11, 15, 26, 29, 33, 36, 47, 58, 67, 82, 92, 5303, 05, 13, 26, 33, 67, 77, 83, 93, 5414, 15, 17, 28, 35, 59, 69, 78, 95, 5507, 19, 29, 37, 43, 58, 68, 70, 72, 84, and 5588 (52' @ 2 SPF). Acid with 10000gal. 2/23/1994: Convert to injection with packer @ 5082. 11/30/2001: Set CIBP @ 5488. Add perfs: 5361 - 69, 89 - 5400, 5411 - 19, 32 - 38, and 55 - 69. Acid on 5361 - 5469 with 3000gal 15%. Sqz perfs 5149 - 5333 with 2005x. CO to 5488 (top of CIBP). Perforations Top Bottom Formation Status Opened Closed #/Ft Ttl: 0.00 0.00 0.00
£005		12/16/1993: Original completion. Perf: 5149, 53, 59, 67, 69, 70, 79, 83, 86, 95, 5200, 04, 11, 15, 26, 29, 33, 36, 47, 58, 67, 82, 92, 5303, 05, 13, 26, 33, 67, 77, 83, 93, 5414, 15, 17, 28, 35, 59, 69, 78, 95, 5507, 19, 29, 37, 43, 58, 68, 70, 72, 84, and 5588 (52' @ 2 SPF). Acid with 10000gal. 2/23/1994: Convert to injection with packer @ 5082. 11/30/2001: Set CIBP @ 5488. Add perfs: 5361 - 69, 89 - 5400, 5411 - 19, 32 - 38, and 55 - 69. Acid on 5361 - 5469 with 3000gal 15%. Sqz perfs 5149 - 5333 with 200sx. C0 to 5488 (top of CIBP). Perforations Top Bottom Formation Status Opened Closed #/Ft Ttl on 0.00 0.00 5,149.00 5,333.00 Blinebry PA 12/16/1993 11/30/2001 2 5 Cmt Sqz 200 sxs 5,361.00 5,369.00 Blinebry A 11/19/2001 1 5,367.00 5,478.00 Blinebry A 12/16/1993 2 4 5,389.00 5,400.00 Blinebry A 11/19/2001 1 5,411.00 5,419.00 Blinebry A 11/19/2001 1 5,432.00 5,438.00 Blinebry A 11/19/2001 1 5,435.00 5,588.00 Blinebry A 11/19/2001 1 5,495.00 5,588.00 Blinebry A 11/19/2001 1 5,495.00 5,588.00 Blinebry TA 11/19/2001 2 2 2 Isolated below CIBP Wellbore Plugs and Junk
£002		12/16/1993: Original completion. Perf: 5149, 53, 59, 67, 69, 70, 79, 83, 86, 95, 5200, 04, 11, 15, 26, 29, 33, 36, 47, 58, 67, 82, 92, 5303, 05, 13, 26, 33, 67, 77, 83, 93, 5414, 15, 17, 28, 35, 59, 69, 78, 95, 5507, 19, 29, 37, 43, 58, 68, 70, 72, 84, and 5588 (52' @ 2 SPF). Acid with 10000gal. 2/23/1994: Convert to injection with packer @ 5082.
£002		12/16/1993: Original completion. Perf: 5149, 53, 59, 67, 69, 70, 79, 83, 86, 95, 5200, 04, 11, 15, 26, 29, 33, 36, 47, 58, 67, 82, 92, 5303, 05, 13, 26, 33, 67, 77, 83, 93, 5414, 15, 17, 28, 35, 59, 69, 78, 95, 5507, 19, 29, 37, 43, 58, 68, 70, 72, 84, and 5588 (52' @ 2 SPF). Acid with 10000gal. 2/23/1994: Convert to injection with packer @ 5082.
2000 fûde		12/16/1993: Original completion. Perf: 5149, 53, 59, 67, 69, 70, 79, 83, 86, 95, 5200, 04, 11, 15, 26, 29, 33, 36, 47, 58, 67, 82, 92, 5303, 05, 13, 26, 33, 67, 77, 83, 93, 5414, 15, 17, 28, 35, 59, 69, 78, 95, 5507, 19, 29, 37, 43, 58, 68, 70, 72, 84, and 5588 (52' @ 2 SPF). Acid with 10000gal. 2/23/1994: Convert to injection with packer @ 5082. 11/30/2001: Set CIBP @ 5488. Add perfs: 5361 - 69, 89 - 5400, 5411 - 19, 32 - 38, and 55 - 69. Acid on 5361 - 5469 with 3000gal 15%. Sqz perfs 5149 - 5333 with 200sx. Co to 5488 (top of CIBP). Perforations
2000 2000 1,000		12/16/1993: Original completion. Perf: 5149, 53, 59, 67, 69, 70, 79, 83, 86, 95, 5200, 04, 11, 15, 26, 29, 33, 36, 47, 58, 67, 82, 92, 5303, 05, 13, 26, 33, 67, 77, 83, 93, 5414, 15, 17, 28, 35, 59, 69, 78, 95, 5507, 19, 29, 37, 43, 58, 68, 70, 72, 84, and 5588 (52' @ 2 SPF). Acid with 10000gal.
£005		12/16/1993: Original completion. Perf: 5149, 53, 59, 67, 69, 70, 79, 83, 86, 95, 5200, 04, 11, 15, 26, 29, 33, 36, 47, 58, 67, 82, 92, 5303, 05, 13, 26, 33, 67, 77, 83, 93, 5414, 15, 17, 28, 35, 59, 69, 78, 95, 5507, 19, 29, 37, 43, 58, 68, 70, 72, 84, and 5588 (52' @ 2 SPF). Acid with 10000gal.

BUREAU OF LAND MANAGEMENT Carlsbad Field Office 620 East Greene Street Carlsbad, New Mexico 88220 575-234-5972

Permanent Abandonment of Federal Wells Conditions of Approval

Failure to comply with the following Conditions of Approval may result in a Notice of Incidents of Noncompliance (INC) in accordance with 43 CFR 3163.1.

1. Plugging operations shall commence within <u>ninety (90)</u> days from the approval date of this Notice of Intent to Abandon.

If you are unable to plug the well by the 90^{th} day provide this office, prior to the 90^{th} day, with the reason for not meeting the deadline and a date when we can expect the well to be plugged. Failure to do so will result in enforcement action.

The rig used for the plugging procedure cannot be released and moved off without the prior approval of the authorized officer. Failure to do so may result in enforcement action.

- 2. <u>Notification:</u> Contact the appropriate BLM office at least 24 hours prior to the commencing of any plugging operations. For wells in Chaves and Roosevelt County, call 575-627-0272; Eddy County, call 575-361-2822; Lea County, call 575-393-3612.
- 3. <u>Blowout Preventers</u>: A blowout preventer (BOP), as appropriate, shall be installed before commencing any plugging operation. The BOP must be installed and maintained as per API and manufacturer recommendations. The minimum BOP requirement is a 2M system for a well not deeper than 9,090 feet; a 3M system for a well not deeper than 13,636 feet; and a 5M system for a well not deeper than 22,727 feet.
- 4. <u>Mud Requirement:</u> Mud shall be placed between all plugs. Minimum consistency of plugging mud shall be obtained by mixing at the rate of 25 sacks (50 pounds each) of gel per 100 barrels of brine water. Minimum nine (9) pounds per gallon.
- 5. <u>Cement Requirement</u>: Sufficient cement shall be used to bring any required plug to the specified depth and length. Any given cement volumes on the proposed plugging procedure are merely estimates and are not final. Unless specific approval is received, no plug except the surface plug shall be less than 25 sacks of cement. Any plug that requires a tag will have a minimum WOC time of 4 hours.

In lieu of a cement plug across perforations in a cased hole (not for any other plugs), a bridge plug set within 50 feet to 100 feet above the perforations shall be capped with 25 sacks of cement. If a bailer is used to cap this plug, 35 feet of cement shall be sufficient. Before pumping or bailing cement on top of CIBP, tag will be required to verify depth. Based on depth, a tag of the cement may be deemed necessary.

Unless otherwise specified in the approved procedure, the cement plug shall consist of either Neat Class "C", for up to 7,500 feet of depth or Neat Class "H", for deeper than 7,500 feet plugs.

6. <u>Dry Hole Marker</u>: All casing shall be cut-off at the base of the cellar or 3 feet below final restored ground level (whichever is deeper). The BLM is to be notified a minimum of 4 hours prior to the wellhead being cut off to verify that cement is to surface in the casing and all annuluses. Wellhead cut off shall commence within ten (10) calendar days of the well being plugged. If the cut off cannot be done by the 10th day, the BLM is to be contacted with justification to receive an extension for completing the cut off.

The well bore shall then be capped with a 4-inch pipe, 10-feet in length, 4 feet above ground and embedded in cement, unless otherwise noted in COA (requirements will be attached). The following information shall be permanently inscribed on the dry hole marker: well name and number, name of the operator, lease serial number, surveyed location (quarter-quarter section, section, township and range or other authorized survey designation acceptable to the authorized officer such as metes and bounds).

- 7. <u>Subsequent Plugging Reporting:</u> Within 30 days after plugging work is completed, file one original and three copies of the Subsequent Report of Abandonment, Form 3160-5 to BLM. The report should give in detail the manner in which the plugging work was carried out, the extent (by depths) of cement plugs placed, and the size and location (by depths) of casing left in the well. <u>Show date well was plugged.</u>
- 8. <u>Trash:</u> All trash, junk and other waste material shall be contained in trash cages or bins to prevent scattering and will be removed and deposited in an approved sanitary landfill. Burial on site is not permitted.

Following the submission and approval of the Subsequent Report of Abandonment, surface restoration will be required. See attached reclamation objectives.



United States Department of the Interior

BUREAU OF LAND MANAGEMENT

Carlsbad Field Office 620 E. Greene St. Carlsbad, New Mexico 88220-6292 www.blm.gov/nm



In Reply Refer To: 1310

Reclamation Objectives and Procedures

Reclamation Objective: Oil and gas development is one of many uses of the public lands and resources. While development may have a short- or long-term effect on the land, successful reclamation can ensure the effect is not permanent. During the life of the development, all disturbed areas not needed for active support of production operations should undergo "interim" reclamation in order to minimize the environmental impacts of development on other resources and uses. At final abandonment, well locations, production facilities, and access roads must undergo "final" reclamation so that the character and productivity of the land and water are restored.

The long-term objective of final reclamation is to set the course for eventual ecosystem restoration, including the restoration of the natural vegetation community, hydrology, and wildlife habitats. In most cases this means returning the land to a condition approximating or equal to that which existed prior to the disturbance. The final goal of reclamation is to restore the character of the land and water to its predisturbance condition. The operator is generally not responsible for achieving full ecological restoration of the site. Instead, the operator must achieve the short-term stability, visual, hydrological, and productivity objectives of the surface management agency and take steps necessary to ensure that long-term objectives will be reached through natural processes.

To achieve these objectives, remove any and all contaminants, scrap/trash, equipment, pipelines and powerlines (Contact service companies, allowing plenty of time to have the risers and power lines and poles removed prior to reclamation, don't wait till the last day and try to get them to remove infrastructure). Strip and remove caliche, contour the location to blend with the surrounding landscape, re-distribute the native soils, provide erosion control as needed, rip and seed as specified in the original APD COA. This will apply to well pads, facilities, and access roads. Barricade access road at the starting point. If reserve pits have not reclaimed due to salts or other contaminants, submit a plan for approval, as to how you propose to provide adequate restoration of the pit area.

- The Application for Permit to Drill or Reenter (APD, Form 3160-3). Surface Use Plan of
 Operations must include adequate measures for stabilization and reclamation of disturbed lands.
 Oil and Gas operators must plan for reclamation, both interim and final, up front in the APD
 process as per Onshore Oil and Gas Order No. 1.
- 2. For wells and/or access roads not having an approved plan, or an inadequate plan for surface reclamation (either interim or final reclamation), the operator must submit a proposal describing the procedures for reclamation. For interim reclamation, the appropriate time for submittal would be when filing the Well Completion or Recompletion Report and Log (Form 3160-4). For final reclamation, the appropriate time for submittal would be when filing the Notice of Intent, or the Subsequent Report of Abandonment, Sundry Notices and Reports on Wells (Form 3160-5).

 Interim reclamation is to be completed within 6 months of well completion, and final reclamation is to be completed within 6 months of well abandonment.
- The operator must file a Subsequent Report Plug and Abandonment (Form 3160-5) following the plugging of a well.
- 4. Previous instruction had you waiting for a BLM specialist to inspect the location and provide you with reclamation requirements. If you have an approved Surface Use Plan of Operation and/or an approved Sundry Notice, you are free to proceed with reclamation as per approved APD. If you

have issues or concerns, contact a BLM specialist to assist you. It would be in your interest to have a BLM specialist look at the location and access road prior to the removal of reclamation equipment to ensure that it meets BLM objectives. Upon conclusion submit a Form 3160-5, Subsequent Report of Reclamation. This will prompt a specialist to inspect the location to verify work was completed as per approved plans.

- 5. The approved Subsequent Report of Reclamation will be your notice that the native soils, contour and seedbed have been reestablished. If the BLM objectives have not been met the operator will be notified and corrective actions may be required.
- 6. It is the responsibility of the operator to monitor these locations and/or access roads until such time as the operator feels that the BLM objective has been met. If after two growing seasons the location and/or access roads are not showing the potential for successful revegetation, additional actions may be needed. When you feel the BLM objectives have been met submit a Final Abandonment Notice (FAN), Form 3160-5, stating that all reclamation requirements have been achieved and the location and/or access road is ready for a final abandonment inspection.
- 7. At this time the BLM specialist will inspect the location and/or access road. If the native soils and contour have been restored, and the revegetation is successful, the FAN will be approved, releasing the operator of any further liability of the location and/or access road. If the location and/or access road have not achieved the objective, you will be notified as to additional work needed or additional time being needed to achieve the objective.

If there are any questions, please feel free to contact any of the following specialists:

Jim Amos Supervisory Petroleum Engineering Tech 575-234-5909 (Office), 575-361-2648 (Cell)

Arthur Arias Environmental Protection Specialist 575-234-6230

Crisha Morgan Environmental Protection Specialist 575-234-5987

Melissa Horn Environmental Protection Specialist 575-234-5951

Kelsey Wade Environmental Protection Specialist 575-234-2220

Trishia Bad Bear, Hobbs Field Station Natural Resource Specialist 575-393-3612