Submit 3 Copies To Appropriate District Office State of New Mexico	Form C-103
District I Energy, Minerals and Natural Resources	May 27, 2004
1625 N. French Dr , Hobbs, NM 88240	WELL API NO.
District II 1301 W. Grand Ave. Artesia, NM \$2805 (767) OIL CONSERVATION DIVISION	30-025-05798
1301 W Grand Ave, Artesia, NM889360CD OIL CONSERVATION DIVISION District III 1220 South St. Francis Dr.	5. Indicate Type of Lease
1000 Dr. Branca Rd. Artes NM 97410	STATE FEE S
District IV Santa Fe, NM 87505	6. State Oil & Gas Lease No.
District IV 1220 S St Francis Dr., Santa NONM 5 2011 Santa Fe, NM 87505	
0.000	7. I N II'4 A
SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FORM FORM FORM FORM FORM FORM FORM	7. Lease Name or Unit Agreement Name
DIFFERENT RESERVOIR USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH	North Monument Grayburg/SA Unit
PROPOSALS.)	Blk. 17 ✓
1. Type of Well: Oil Well ☐ Gas Well ☐ Other ☐	8. Well Number
	13
2. Name of Operator	9. OGRID Number
Apache Corporation	873
3. Address of Operator	10. Pool name or Wildcat
303 Veterans Airpark Lane, Ste. 3000, Midland, TX. 79705	Eunice Monument; G/SA
4. Well Location	V
Unit Letter M : 600 feet from the S line and 66	feet from the
W line	
	V
Section 33 Township 19S Range 37E NMPM	
11. Elevation (Show whether DR, RKB, RT, GR, etc.	The second secon
-3558 ft.GR	
Pit or Below-grade Tank Application or Closure	
Pit typeDepth to GroundwaterDistance from nearest fresh water well Distance	e from nearest surface water_N/A
Pit Liner Thickness: mil Below-Grade Tank: Volumebbls; Constr	uction Material
12. Check Appropriate Box to Indicate Nature of Notice,	Danast on Othan Data
12. Check Appropriate Box to indicate nature of notice,	NEDOLLOLOHIEL DAIA
** *	Treport or o mor 2 min
· · · · · · · · · · · · · · · · · · ·	•
NOTICE OF INTENTION TO:	BSEQUENT REPORT OF:
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK □ PLUG AND ABANDON / REMEDIAL WO	BSEQUENT REPORT OF:
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WO TEMPORARILY ABANDON CHANGE PLANS COMMENCE D	BSEQUENT REPORT OF: RK
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORTEMPORARILY ABANDON CHANGE PLANS COMMENCE DE PULL OR ALTER CASING MULTIPLE COMPL CASING/CEME	BSEQUENT REPORT OF: RK
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WO TEMPORARILY ABANDON CHANGE PLANS COMMENCE D	BSEQUENT REPORT OF: RK
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORTEMPORARILY ABANDON CHANGE PLANS COMMENCE DE PULL OR ALTER CASING MULTIPLE COMPL CASING/CEME OTHER:	BSEQUENT REPORT OF: RK
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORTEMPORARILY ABANDON CHANGE PLANS COMMENCE DE PULL OR ALTER CASING MULTIPLE COMPL CASING/CEME	BSEQUENT REPORT OF: RK
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORTEMPORARILY ABANDON CHANGE PLANS COMMENCE DE CASING/CEME OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, and	BSEQUENT REPORT OF: RK
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORD COMMENCE DOWN COMMENC	BSEQUENT REPORT OF: RK ALTERING CASING RILLING OPNS. PAND A MODE AND A MODE
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORTEMPORARILY ABANDON CHANGE PLANS COMMENCE DEPULL OR ALTER CASING MULTIPLE COMPL CASING/CEME OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, and of starting any proposed work). SEE RULE 1103. For Multiple Completions: And or recompletion.	BSEQUENT REPORT OF: RK ALTERING CASING RILLING OPNS. PAND A M NT JOB D d give pertinent dates, including estimated date tach wellbore diagram of proposed completion hole with 121 bbls. mud laden fluid; Spot 30
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DEPULL OR ALTER CASING MULTIPLE COMPL CASING/CEME OTHER: OTHER: OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, and of starting any proposed work). SEE RULE 1103. For Multiple Completions: And or recompletion. 11-3-2011-MIRU plugging equipment; Tag existing 6 5/8" CIBP @ 3518 ft. Circulate sacks cement from 3518 ft. WOC, Tag cement plug @ 3330 ft. Perforate 6 60 sacks cement. WOC.	BSEQUENT REPORT OF: RK ALTERING CASING RILLING OPNS. PAND A STATEMENT AND A ST
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DE PULL OR ALTER CASING MULTIPLE COMPL CASING/CEME OTHER: OTHER: OTHER: OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, and of starting any proposed work). SEE RULE 1103. For Multiple Completions: And or recompletion. 11-3-2011-MIRU plugging equipment; Tag existing 6 5/8" CIBP @ 3518 ft. Circulate sacks cement from 3518 ft. WOC, Tag cement plug @ 3330 ft. Perforate 6 60 sacks cement. WOC. 11-4-2011-Tag cement plug @ 2345 ft. Perforate @ 1442 ft. Packer @ 1072. Squeeze 60	BSEQUENT REPORT OF: RK ALTERING CASING RILLING OPNS. PAND A STATEMENT AND A S
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DE C	BSEQUENT REPORT OF: RK ALTERING CASING RILLING OPNS. PAND A STATEMENT AND A S
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DE PULL OR ALTER CASING MULTIPLE COMPL CASING/CEME OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, an of starting any proposed work). SEE RULE 1103. For Multiple Completions: As or recompletion. 11-3-2011-MIRU plugging equipment; Tag existing 6 5/8" CIBP @ 3518 ft. Circulate sacks cement from 3518 ft. WOC, Tag cement plug @ 3330 ft. Perforate 6 60 sacks cement. WOC. 11-4-2011-Tag cement plug @ 2345 ft. Perforate @ 1442 ft. Packer @ 1072. Squeeze 6 11-7-2011- Tag cement, plug @ 1305 ft. Perforate @ 340 ft. Packer @ 30 ft. Establish 8 5/8 x 12 ½ casing pressure tested. Pump 80 sacks cement down 6 5/8 x 8	BSEQUENT REPORT OF: RK ALTERING CASING RILLING OPNS. PAND A STATEMENT AND A S
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE D PULL OR ALTER CASING MULTIPLE COMPL CASING/CEME OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, an of starting any proposed work). SEE RULE 1103. For Multiple Completions: At or recompletion. 11-3-2011-MIRU plugging equipment; Tag existing 6 5/8" CIBP 3518 ft. Circulate sacks cement from 3518 ft. WOC, Tag cement plug 3330 ft. Perforate 6 60 sacks cement. WOC. 11-4-2011-Tag cement plug 2345 ft. Perforate 1442 ft. Packer 1072. Squeeze 611-7-2011-Tag cement, plug 1305 ft. Perforate 340 ft. Packer 30 ft. Establish 8 5/8 x 12 1/4 casing pressure tested. Pump 80 sacks cement down 6 5/8 x 8 Cut-off wellhead & anchors. Clean location. Install dry-hole marker.	BSEQUENT REPORT OF: RK
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DEPULL OR ALTER CASING MULTIPLE COMPL CASING/CEME OTHER: OTHER: OTHER: OTHER: The starting any proposed or completed operations. (Clearly state all pertinent details, and of starting any proposed work). SEE RULE 1103. For Multiple Completions: And or recompletion. 11-3-2011-MIRU plugging equipment; Tag existing 6 5/8" CIBP @ 3518 ft. Circulate sacks cement from 3518 ft. WOC, Tag cement plug @ 3330 ft. Perforate 6 60 sacks cement. WOC. 11-4-2011-Tag cement plug @ 2345 ft. Perforate @ 1442 ft. Packer @ 1072. Squeeze 60 11-7-2011- Tag cement, plug @ 1305 ft. Perforate @ 340 ft. Packer @ 30 ft. Establish 8 5/8 x 12 ½ casing pressure tested. Pump 80 sacks cement down 6 5/8 x 8 Cut-off wellhead & anchors. Clean location. Install dry-hole marker. RDMO plugging equipment.	BSEQUENT REPORT OF: RK
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WO TEMPORARILY ABANDON CHANGE PLANS COMMENCE D PULL OR ALTER CASING MULTIPLE COMPL CASING/CEME OTHER: OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, an of starting any proposed work). SEE RULE 1103. For Multiple Completions: As or recompletion. 11-3-2011-MIRU plugging equipment; Tag existing 6 5/8" CIBP @ 3518 ft. Circulate sacks cement from 3518 ft. WOC, Tag cement plug @ 3330 ft. Perforate 6 60 sacks cement. WOC. 11-4-2011-Tag cement plug @ 2345 ft. Perforate @ 1442 ft. Packer @ 1072. Squeeze 6 11-7-2011- Tag cement plug @ 1305 ft. Perforate @ 340 ft. Packer @ 30 ft. Establish 8 5/8 x 12 ½ casing pressure tested. Pump 80 sacks cement down 6 5/8 x 8 Cut-off wellhead & anchors. Clean location. Install dry-hole marker. RDMO plugging equipment.	BSEQUENT REPORT OF: RK ALTERING CASING RILLING OPNS. PAND A STATE PAND A PAND A STATE PAND A STATE PAND A STATE PAND A PAND A PAND A STATE PAND A
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WO TEMPORARILY ABANDON CHANGE PLANS COMMENCE D PULL OR ALTER CASING MULTIPLE COMPL CASING/CEME OTHER: OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, an of starting any proposed work). SEE RULE 1103. For Multiple Completions: At or recompletion. 11-3-2011-MIRU plugging equipment; Tag existing 6 5/8" CIBP @ 3518 ft. Circulate sacks cement from 3518 ft. WOC, Tag cement plug @ 3330 ft. Perforate 6 60 sacks cement. WOC. 11-4-2011-Tag cement plug @ 2345 ft. Perforate @ 1442 ft. Packer @ 1072. Squeeze 6 11-7-2011- Tag cement.plug @ 1305 ft. Perforate @ 340 ft. Packer @ 30 ft. Establish 8 5/8 x 12 ½ casing pressure tested. Pump 80 sacks cement down 6 5/8 x 8 Cut-off wellhead & anchors. Clean location. Install dry-hole marker. RDMO plugging equipment.	BSEQUENT REPORT OF: RK
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORTEMPORARILY ABANDON CHANGE PLANS COMMENCE DEPULL OR ALTER CASING MULTIPLE COMPL CASING/CEME OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, and of starting any proposed work). SEE RULE 1103. For Multiple Completions: An or recompletion. 11-3-2011-MIRU plugging equipment; Tag existing 6 5/8" CIBP @ 3518 ft. Circulate sacks cement from 3518 ft. WOC, Tag cement plug @ 3330 ft. Perforate 6 60 sacks cement. WOC. 11-4-2011-Tag cement plug @ 2345 ft. Perforate @ 1442 ft. Packer @ 1072. Squeeze 60 11-7-2011- Tag cement plug @ 1305 ft. Perforate @ 340 ft. Packer @ 30 ft. Establish 8 5/8 x 12 ½ casing pressure tested. Pump 80 sacks cement down 6 5/8 x 8 Cut-off wellhead & anchors. Clean location. Install dry-hole marker. RDMO plugging equipment.	BSEQUENT REPORT OF: RK
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WO TEMPORARILY ABANDON CHANGE PLANS COMMENCE D PULL OR ALTER CASING MULTIPLE COMPL CASING/CEME OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, an of starting any proposed work). SEE RULE 1103. For Multiple Completions: As or recompletion. 11-3-2011-MIRU plugging equipment; Tag existing 6 5/8" CIBP @ 3518 ft. Circulate sacks cement from 3518 ft. WOC, Tag cement plug @ 3330 ft. Perforate 6 60 sacks cement. WOC. 11-4-2011-Tag cement plug @ 2345 ft. Perforate @ 1442 ft. Packer @ 1072. Squeeze 6 11-7-2011- Tag cement plug @ 1305 ft. Perforate @ 340 ft. Packer @ 30 ft. Establish 8 5/8 x 12 ½ casing pressure tested. Pump 80 sacks cement down 6 5/8 x 8 Cut-off wellhead & anchors. Clean location. Install dry-hole marker. RDMO plugging equipment.	BSEQUENT REPORT OF: RK
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORTEMPORARILY ABANDON CHANGE PLANS COMMENCE DEPULL OR ALTER CASING MULTIPLE COMPL CASING/CEME OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, an of starting any proposed work). SEE RULE 1103. For Multiple Completions: At or recompletion. 11-3-2011-MIRU plugging equipment; Tag existing 6 5/8" CIBP @ 3518 ft. Circulate sacks cement from 3518 ft. WOC, Tag cement plug @ 3330 ft. Perforate 6 60 sacks cement. WOC. 11-4-2011-Tag cement plug @ 2345 ft. Perforate @ 1442 ft. Packer @ 1072. Squeeze 6 11-7-2011- Tag cement, plug @ 1305 ft. Perforate @ 340 ft. Packer @ 30 ft. Establish 8 5/8 x 12 ½ casing pressure tested. Pump 80 sacks cement down 6 5/8 x 8 Cut-off wellhead & anchors. Clean location. Install dry-hole marker. RDMO plugging equipment.	BSEQUENT REPORT OF: RK
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORTEMPORARILY ABANDON CHANGE PLANS COMMENCE DEPULL OR ALTER CASING MULTIPLE COMPL CASING/CEME OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, an of starting any proposed work). SEE RULE 1103. For Multiple Completions: At or recompletion. 11-3-2011-MIRU plugging equipment; Tag existing 6 5/8" CIBP @ 3518 ft. Circulate sacks cement from 3518 ft. WOC, Tag cement plug @ 3330 ft. Perforate 6 60 sacks cement. WOC. 11-4-2011-Tag cement plug @ 2345 ft. Perforate @ 1442 ft. Packer @ 1072. Squeeze 6 11-7-2011- Tag cement, plug @ 1305 ft. Perforate @ 340 ft. Packer @ 30 ft. Establish 8 5/8 x 12 ½ casing pressure tested. Pump 80 sacks cement down 6 5/8 x 8 Cut-off wellhead & anchors. Clean location. Install dry-hole marker. RDMO plugging equipment.	BSEQUENT REPORT OF: RK
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WO TEMPORARILY ABANDON CHANGE PLANS COMMENCE D PULL OR ALTER CASING MULTIPLE COMPL CASING/CEME OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, an of starting any proposed work). SEE RULE 1103. For Multiple Completions: Ar or recompletion. 11-3-2011-MIRU plugging equipment; Tag existing 6 5/8" CIBP @ 3518 ft. Circulate sacks cement from 3518 ft. WOC, Tag cement plug @ 3330 ft. Perforate 6 60 sacks cement. WOC. 11-4-2011-Tag cement plug @ 2345 ft. Perforate @ 1442 ft. Packer @ 1072. Squeeze 6 11-7-2011- Tag cement, plug @ 1305 ft. Perforate @ 340 ft. Packer @ 30 ft. Establish 8 5/8 x 12 ½ casing pressure tested. Pump 80 sacks cement down 6 5/8 x 8 Cut-off wellhead & anchors. Clean location. Install dry-hole marker. RDMO plugging equipment. I hereby certify that the information above is true and complete to the best of my knowledgerade tank has been/will be constructed or closed according to NMOCD guidelines ☑, a general permit □ SIGNATURE TITLE P & A Supervisor (Basic	BSEQUENT REPORT OF: RK
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORD TEMPORARILY ABANDON CHANGE PLANS COMMENCE DEPULL OR ALTER CASING MULTIPLE COMPL CASING/CEME OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, an of starting any proposed work). SEE RULE 1103. For Multiple Completions: At or recompletion. 11-3-2011-MIRU plugging equipment; Tag existing 6 5/8" CIBP @ 3518 ft. Circulate sacks cement from 3518 ft. WOC, Tag cement plug @ 3330 ft. Perforate 6 60 sacks cement. WOC. 11-4-2011-Tag cement plug @ 2345 ft. Perforate @ 1442 ft. Packer @ 1072. Squeeze 6 11-7-2011- Tag cement, plug @ 1305 ft. Perforate @ 340 ft. Packer @ 30 ft. Establish 8 5/8 x 12 1/2 casing pressure tested. Pump 80 sacks cement down 6 5/8 x 8 Cut-off wellhead & anchors. Clean location. Install dry-hole marker. RDMO plugging equipment. I hereby certify that the information above is true and complete to the best of my knowledgerade tank has been/will be constructed or closed according to NMOCD guidelines A general permit SIGNATURE SIGNATURE TITLE P & A Supervisor (Basic Type or print name)	BSEQUENT REPORT OF: RK
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WO TEMPORARILY ABANDON CHANGE PLANS COMMENCE D PULL OR ALTER CASING MULTIPLE COMPL CASING/CEME OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, an of starting any proposed work). SEE RULE 1103. For Multiple Completions: Ar or recompletion. 11-3-2011-MIRU plugging equipment; Tag existing 6 5/8" CIBP @ 3518 ft. Circulate sacks cement from 3518 ft. WOC, Tag cement plug @ 3330 ft. Perforate 6 60 sacks cement. WOC. 11-4-2011-Tag cement plug @ 2345 ft. Perforate @ 1442 ft. Packer @ 1072. Squeeze 6 11-7-2011- Tag cement, plug @ 1305 ft. Perforate @ 340 ft. Packer @ 30 ft. Establish 8 5/8 x 12 ½ casing pressure tested. Pump 80 sacks cement down 6 5/8 x 8 Cut-off wellhead & anchors. Clean location. Install dry-hole marker. RDMO plugging equipment. I hereby certify that the information above is true and complete to the best of my knowledgerade tank has been/will be constructed or closed according to NMOCD guidelines ☑, a general permit □ SIGNATURE TITLE P & A Supervisor (Basic	BSEQUENT REPORT OF: RK
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK PULL OR ALTER CASING MULTIPLE COMPL CASING/CEME OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, an of starting any proposed work). SEE RULE 1103. For Multiple Completions: At or recompletion. 11-3-2011-MIRU plugging equipment; Tag existing 6 5/8" CIBP @ 3518 ft. Circulate sacks cement from 3518 ft. WOC, Tag cement plug @ 3330 ft. Perforate 6 60 sacks cement. WOC. 11-4-2011-Tag cement plug @ 2345 ft. Perforate @ 1442 ft. Packer @ 1072. Squeeze 6 11-7-2011- Tag cement, plug @ 1305 ft. Perforate @ 340 ft. Packer @ 30 ft. Establish 8 5/8 x 12 ½ casing pressure tested. Pump 80 sacks cement down 6 5/8 x 8 Cut-off wellhead & anchors. Clean location. Install dry-hole marker. RDMO plugging equipment. I hereby certify that the information above is true and complete to the best of my knowledgrade tank has been/will be constructed or closed according to NMOCD guidelines \(\subseteq \), a general permit \(\subseteq \subseteq \) SIGNATURE TITLE P & A Supervisor (Basic Type or print name: E-mail address: For State Use Oxiv	BSEQUENT REPORT OF: RK
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WO TEMPORARILY ABANDON CHANGE PLANS COMMENCE D PULL OR ALTER CASING MULTIPLE COMPL CASING/CEME OTHER: OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, an of starting any proposed work). SEE RULE 1103. For Multiple Completions: At or recompletion. 11-3-2011-MIRU plugging equipment; Tag existing 6 5/8" CIBP @ 3518 ft. Circulate sacks cement from 3518 ft. WOC, Tag cement plug @ 3330 ft. Perforate 6 60 sacks cement. WOC. 11-4-2011-Tag cement plug @ 2345 ft. Perforate @ 1442 ft. Packer @ 1072. Squeeze 6 11-7-2011- Tag cement, plug @ 1305 ft. Perforate @ 340 ft. Packer @ 30 ft. Establish 8 5/8 x 12 ½ casing pressure tested. Pump 80 sacks cement down 6 5/8 x 8 Cut-off wellhead & anchors. Clean location. Install dry-hole marker. RDMO plugging equipment. I hereby certify that the information above is true and complete to the best of my knowledge grade tank has been/will be constructed or closed according to NMOCD guidelines \(\Delta \), a general permit \(\Delta \) SIGNATURE TITLE P & A Supervisor (Basic Type or print name E-mail address: For State Use Only APPROVED BY:	BSEQUENT REPORT OF: RK
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK PULL OR ALTER CASING MULTIPLE COMPL CASING/CEME OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, an of starting any proposed work). SEE RULE 1103. For Multiple Completions: At or recompletion. 11-3-2011-MIRU plugging equipment; Tag existing 6 5/8" CIBP @ 3518 ft. Circulate sacks cement from 3518 ft. WOC, Tag cement plug @ 3330 ft. Perforate 6 60 sacks cement. WOC. 11-4-2011-Tag cement plug @ 2345 ft. Perforate @ 1442 ft. Packer @ 1072. Squeeze 6 11-7-2011- Tag cement, plug @ 1305 ft. Perforate @ 340 ft. Packer @ 30 ft. Establish 8 5/8 x 12 ½ casing pressure tested. Pump 80 sacks cement down 6 5/8 x 8 Cut-off wellhead & anchors. Clean location. Install dry-hole marker. RDMO plugging equipment. I hereby certify that the information above is true and complete to the best of my knowledgrade tank has been/will be constructed or closed according to NMOCD guidelines \(\subseteq \), a general permit \(\subseteq \subseteq \) SIGNATURE TITLE P & A Supervisor (Basic Type or print name: E-mail address: For State Use Oxiv	BSEQUENT REPORT OF: RK
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WO TEMPORARILY ABANDON CHANGE PLANS COMMENCE D PULL OR ALTER CASING MULTIPLE COMPL CASING/CEME OTHER: OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, an of starting any proposed work). SEE RULE 1103. For Multiple Completions: At or recompletion. 11-3-2011-MIRU plugging equipment; Tag existing 6 5/8" CIBP @ 3518 ft. Circulate sacks cement from 3518 ft. WOC, Tag cement plug @ 3330 ft. Perforate 6 60 sacks cement. WOC. 11-4-2011-Tag cement plug @ 2345 ft. Perforate @ 1442 ft. Packer @ 1072. Squeeze 6 11-7-2011- Tag cement, plug @ 1305 ft. Perforate @ 340 ft. Packer @ 30 ft. Establish 8 5/8 x 12 ½ casing pressure tested. Pump 80 sacks cement down 6 5/8 x 8 Cut-off wellhead & anchors. Clean location. Install dry-hole marker. RDMO plugging equipment. I hereby certify that the information above is true and complete to the best of my knowledge grade tank has been/will be constructed or closed according to NMOCD guidelines \(\Delta \), a general permit \(\Delta \) SIGNATURE TITLE P & A Supervisor (Basic Type or print name E-mail address: For State Use Only APPROVED BY:	BSEQUENT REPORT OF: RK