Office	Form C-103
District I Energy, Minerals and Natural Resources	May 27, 2004
1625 N French Dr., Hobbs, NM 88240	WELL API NO.
District II 1301 W Grand Ave., Artesia, NM 88210 HOBBS OCD OIL CONSERVATION DIVISION	30-025-06379
District III 1220 South St. Francis Dr	5. Indicate Type of Lease STATE STATE FEE
1000 Rio Brazos Rd, Aztec, NM 87410 JAN 27 2012 South St. 1 Janeirs D1. District IV Santa Fe, NM 87505	6. State Oil & Gas Lease No.
1220 S. St Francis Dr, Santa Fe, NM 87505	BO-9745
SUNDRY NOTICES AND REPORTS ON WELLS	7. Lease Name or Unit Agreement Name
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH	State Section 2
PROPOSALS) 1. Type of Well: Oil Well Gas Well Other	8. Well Number 13
2. Name of Operator	9. OGRID Number
Apache Corporation 3. Address of Operator	873 10. Pool name or Wildcat
303 Veterans Airpark Lane, Ste. 3000, Midland, TX. 79705	Hare;Simpson
4. Well Location	
Unit Letter F : 2970 feet from the S line and 1650 feet from	n the <b>W</b> line
Section 2 Township 21S Range 37E NMPM	County Lea
11. Elevation (Show whether DR, RKB, RT, GR, et	
June 24 Rul DE CONTRACTOR STORE STOR	
Pit or Below-grade Tank Application or Closure	
Pit typeDepth to GroundwaterDistance from nearest fresh water well Dista	nce from nearest surface waterN/A
Pit Liner Thickness:       mil       Below-Grade Tank: Volume       bbls;       Construction Material         12.       Check Appropriate Box to Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO: S	UBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL W	
TEMPORARILY ABANDON CHANGE PLANS COMMENCE	
OTHER: OTHER:	
13. Describe proposed or completed operations. (Clearly state all pertinent details, a	nd give pertinent dates including estimated date
of starting any proposed work). SEE RULE 1103. For Multiple Completions:	and give pertinent dates, meruding estimated date
	Attach wellbore diagram of proposed completion
or recompletion.	Attach wellbore diagram of proposed completion
or recompletion. 12-11-2012 – MIRU Plugging Equipment	
or recompletion. 12-11-2012 – MIRU Plugging Equipment 1-12-2012 – Tag existing 5 ½ CIBP @ 7618 ft. Circulate hole w/ 180 barrels of mud l	aden fluid. Spot 125 sacks cement (1234 ft.)
or recompletion. 12-11-2012 – MIRU Plugging Equipment 1-12-2012 – Tag existing 5 ½ CIBP @ 7618 ft. Circulate hole w/ 180 barrels of mud l 1-13-2012 – Tag cement plug @ 6402 ft. Perforate @ 5550 ft. 5 ½ packer @ 4924 ft.	aden fluid. Spot 125 sacks cement (1234 ft.) Squeeze 60 sacks cement. WOC
or recompletion. 12-11-2012 – MIRU Plugging Equipment 1-12-2012 – Tag existing 5 ½ CIBP @ 7618 ft. Circulate hole w/ 180 barrels of mud l 1-13-2012 – Tag cement plug @ 6402 ft. Perforate @ 5550 ft. 5 ½ packer @ 4924 ft. 1-16-2012 – Tag cement plug @ 5197 ft. Spot 93 sacks from 4572 ft. WOC. Tag cement	aden fluid. Spot 125 sacks cement (1234 ft.) Squeeze 60 sacks cement. WOC
or recompletion. 12-11-2012 – MIRU Plugging Equipment 1-12-2012 – Tag existing 5 ½ CIBP @ 7618 ft. Circulate hole w/ 180 barrels of mud l 1-13-2012 – Tag cement plug @ 6402 ft. Perforate @ 5550 ft. 5 ½ packer @ 4924 ft. 1-16-2012 – Tag cement plug @ 5197 ft. Spot 93 sacks from 4572 ft. WOC. Tag cement Note: Combined plugs @ 4039 ft. & 4570 ft. into 1 plug	aden fluid. Spot 125 sacks cement (1234 ft.) Squeeze 60 sacks cement. WOC ent plug @ 3722 ft.
or recompletion. 12-11-2012 – MIRU Plugging Equipment 1-12-2012 – Tag existing 5 ½ CIBP @ 7618 ft. Circulate hole w/ 180 barrels of mud l 1-13-2012 – Tag cement plug @ 6402 ft. Perforate @ 5550 ft. 5 ½ packer @ 4924 ft. 1-16-2012 – Tag cement plug @ 5197 ft. Spot 93 sacks from 4572 ft. WOC. Tag cement Note: Combined plugs @ 4039 ft. & 4570 ft. into 1 plug 1-17-2012 – Perforate @ 3200 ft. 5 ½ packer @ 2721 ft. Pressure tested to 1500 psi. C	aden fluid. Spot 125 sacks cement (1234 ft.) Squeeze 60 sacks cement. WOC nt plug @ 3722 ft. Contact OCD, advised to spot 30 sacks from
or recompletion. 12-11-2012 – MIRU Plugging Equipment 1-12-2012 – Tag existing 5 ½ CIBP @ 7618 ft. Circulate hole w/ 180 barrels of mud l 1-13-2012 – Tag cement plug @ 6402 ft. Perforate @ 5550 ft. 5 ½ packer @ 4924 ft. 1-16-2012 – Tag cement plug @ 5197 ft. Spot 93 sacks from 4572 ft. WOC. Tag cement Note: Combined plugs @ 4039 ft. & 4570 ft. into 1 plug 1-17-2012 – Perforate @ 3200 ft. 5 ½ packer @ 2721 ft. Pressure tested to 1500 psi. C 3050 ft. Spot 30 sacks from 3250 ft. WOC. Tag cement plug 2978 ft. Per	aden fluid. Spot 125 sacks cement (1234 ft.) Squeeze 60 sacks cement. WOC ent plug @ 3722 ft. Contact OCD, advised to spot 30 sacks from forate @ 1350 ft. 5 ½ packer @ 1036 ft.
or recompletion. 12-11-2012 – MIRU Plugging Equipment 1-12-2012 – Tag existing 5 ½ CIBP @ 7618 ft. Circulate hole w/ 180 barrels of mud l 1-13-2012 – Tag cement plug @ 6402 ft. Perforate @ 5550 ft. 5 ½ packer @ 4924 ft. 1-16-2012 – Tag cement plug @ 5197 ft. Spot 93 sacks from 4572 ft. WOC. Tag cement Note: Combined plugs @ 4039 ft. & 4570 ft. into 1 plug 1-17-2012 – Perforate @ 3200 ft. 5 ½ packer @ 2721 ft. Pressure tested to 1500 psi. C 3050 ft. Spot 30 sacks from 3250 ft. WOC. Tag cement plug 2978 ft. Per Established circulation 5 ½ x 8% casing. Pump 80 sacks cement. WOC.	aden fluid. Spot 125 sacks cement (1234 ft.) Squeeze 60 sacks cement. WOC ent plug @ 3722 ft. Contact OCD, advised to spot 30 sacks from forate @ 1350 ft. 5 ½ packer @ 1036 ft.
or recompletion. 12-11-2012 – MIRU Plugging Equipment 1-12-2012 – Tag existing 5 ½ CIBP @ 7618 ft. Circulate hole w/ 180 barrels of mud l 1-13-2012 – Tag cement plug @ 6402 ft. Perforate @ 5550 ft. 5 ½ packer @ 4924 ft. 1-16-2012 – Tag cement plug @ 5197 ft. Spot 93 sacks from 4572 ft. WOC. Tag cement Note: Combined plugs @ 4039 ft. & 4570 ft. into 1 plug 1-17-2012 – Perforate @ 3200 ft. 5 ½ packer @ 2721 ft. Pressure tested to 1500 psi. C 3050 ft. Spot 30 sacks from 3250 ft. WOC. Tag cement plug 2978 ft. Per Established circulation 5 ½ x 8% casing. Pump 80 sacks cement. WOC. 1-18-2012 – Tag cement plug @ 1127 ft. Perforate @ 243 ft. Pump 60 sacks cement	aden fluid. Spot 125 sacks cement (1234 ft.) Squeeze 60 sacks cement. WOC ent plug @ 3722 ft. Contact OCD, advised to spot 30 sacks from forate @ 1350 ft. 5 ½ packer @ 1036 ft.
or recompletion. 12-11-2012 – MIRU Plugging Equipment 1-12-2012 – Tag existing 5 ½ CIBP @ 7618 ft. Circulate hole w/ 180 barrels of mud l 1-13-2012 – Tag cement plug @ 6402 ft. Perforate @ 5550 ft. 5 ½ packer @ 4924 ft. 1-16-2012 – Tag cement plug @ 5197 ft. Spot 93 sacks from 4572 ft. WOC. Tag cement Note: Combined plugs @ 4039 ft. & 4570 ft. into 1 plug 1-17-2012 – Perforate @ 3200 ft. 5 ½ packer @ 2721 ft. Pressure tested to 1500 psi. C 3050 ft. Spot 30 sacks from 3250 ft. WOC. Tag cement plug 2978 ft. Per Established circulation 5 ½ x 8% casing. Pump 80 sacks cement. WOC.	aden fluid. Spot 125 sacks cement (1234 ft.) Squeeze 60 sacks cement. WOC ent plug @ 3722 ft. Contact OCD, advised to spot 30 sacks from forate @ 1350 ft. 5 ½ packer @ 1036 ft. 4 down 5 ½ x 8 5/8 to surface. Displace to 100 ft. ks cement from 85 ft. to surface.
or recompletion. 12-11-2012 – MIRU Plugging Equipment 1-12-2012 – Tag existing 5 ½ CIBP @ 7618 ft. Circulate hole w/ 180 barrels of mud l 1-13-2012 – Tag cement plug @ 6402 ft. Perforate @ 5550 ft. 5 ½ packer @ 4924 ft. 1-16-2012 – Tag cement plug @ 5197 ft. Spot 93 sacks from 4572 ft. WOC. Tag cement Note: Combined plugs @ 4039 ft. & 4570 ft. into 1 plug 1-17-2012 – Perforate @ 3200 ft. 5 ½ packer @ 2721 ft. Pressure tested to 1500 psi. C 3050 ft. Spot 30 sacks from 3250 ft. WOC. Tag cement plug 2978 ft. Per Established circulation 5 ½ x 878 casing. Pump 80 sacks cement. WOC. 1-18-2012 – Tag cement plug @ 1127 ft. Perforate @ 243 ft. Pump 60 sacks cement 8 5/8 x 13 3/8 casing pressure tested. Tag cement plug @ 85 ft. spot 8 sack	aden fluid. Spot 125 sacks cement (1234 ft.) Squeeze 60 sacks cement. WOC ent plug @ 3722 ft. Contact OCD, advised to spot 30 sacks from forate @ 1350 ft. 5 ½ packer @ 1036 ft. 4 down 5 ½ x 8 5/8 to surface. Displace to 100 ft. ks cement from 85 ft. to surface.
or recompletion. 12-11-2012 – MIRU Plugging Equipment 1-12-2012 – Tag existing 5 ½ CIBP @ 7618 ft. Circulate hole w/ 180 barrels of mud l 1-13-2012 – Tag cement plug @ 6402 ft. Perforate @ 5550 ft. 5 ½ packer @ 4924 ft. 1-16-2012 – Tag cement plug @ 5197 ft. Spot 93 sacks from 4572 ft. WOC. Tag cement Note: Combined plugs @ 4039 ft. & 4570 ft. into 1 plug 1-17-2012 – Perforate @ 3200 ft. 5 ½ packer @ 2721 ft. Pressure tested to 1500 psi. C 3050 ft. Spot 30 sacks from 3250 ft. WOC. Tag cement plug 2978 ft. Per Established circulation 5 ½ x 878 casing. Pump 80 sacks cement. WOC. 1-18-2012 – Tag cement plug @ 1127 ft. Perforate @ 243 ft. Pump 60 sacks cement 8 5/8 x 13 3/8 casing pressure tested. Tag cement plug @ 85 ft. spot 8 sack	aden fluid. Spot 125 sacks cement (1234 ft.) Squeeze 60 sacks cement. WOC ent plug @ 3722 ft. Contact OCD, advised to spot 30 sacks from forate @ 1350 ft. 5 ½ packer @ 1036 ft. 4 down 5 ½ x 8 5/8 to surface. Displace to 100 ft. ks cement from 85 ft. to surface.
or recompletion. 12-11-2012 – MIRU Plugging Equipment 1-12-2012 – Tag existing 5 ½ CIBP @ 7618 ft. Circulate hole w/ 180 barrels of mud I 1-13-2012 – Tag cement plug @ 6402 ft. Perforate @ 5550 ft. 5 ½ packer @ 4924 ft. 1-16-2012 – Tag cement plug @ 5197 ft. Spot 93 sacks from 4572 ft. WOC. Tag cement Note: Combined plugs @ 4039 ft. & 4570 ft. into 1 plug 1-17-2012 – Perforate @ 3200 ft. 5 ½ packer @ 2721 ft. Pressure tested to 1500 psi. C 3050 ft. Spot 30 sacks from 3250 ft. WOC. Tag cement plug 2978 ft. Per Established circulation 5 ½ x 878 casing. Pump 80 sacks cement. WOC. 1-18-2012 – Tag cement plug @ 1127 ft. Perforate @ 243 ft. Pump 60 sacks cement # 8 5/8 x 13 3/8 casing pressure tested. Tag cement plug @ 85 ft. spot 8 sack Cut-off well-head and anchors. Clean location. Install dry-hole marker.	aden fluid. Spot 125 sacks cement (1234 ft.) Squeeze 60 sacks cement. WOC Int plug @ 3722 ft. Contact OCD, advised to spot 30 sacks from forate @ 1350 ft. 5 $\frac{1}{2}$ packer @ 1036 ft. $\frac{1}{2}$ down 5 $\frac{1}{2}$ x 8 5/8 to surface. Displace to 100 ft. ks cement from 85 ft. to surface. RDMO plugging equipment.
or recompletion. 12-11-2012 – MIRU Plugging Equipment 1-12-2012 – Tag existing 5 ½ CIBP @ 7618 ft. Circulate hole w/ 180 barrels of mud I 1-13-2012 – Tag cement plug @ 6402 ft. Perforate @ 5550 ft. 5 ½ packer @ 4924 ft. 1-16-2012 – Tag cement plug @ 5197 ft. Spot 93 sacks from 4572 ft. WOC. Tag cement Note: Combined plugs @ 4039 ft. & 4570 ft. into 1 plug 1-17-2012 – Perforate @ 3200 ft. 5 ½ packer @ 2721 ft. Pressure tested to 1500 psi. C 3050 ft. Spot 30 sacks from 3250 ft. WOC. Tag cement plug 2978 ft. Per Established circulation 5 ½ x 878 casing. Pump 80 sacks cement. WOC. 1-18-2012 – Tag cement plug @ 1127 ft. Perforate @ 243 ft. Pump 60 sacks cement # 8 5/8 x 13 3/8 casing pressure tested. Tag cement plug @ 85 ft. spot 8 sack Cut-off well-head and anchors. Clean location. Install dry-hole marker.	aden fluid. Spot 125 sacks cement (1234 ft.) Squeeze 60 sacks cement. WOC Int plug @ 3722 ft. Contact OCD, advised to spot 30 sacks from forate @ 1350 ft. 5 $\frac{1}{2}$ packer @ 1036 ft. $\frac{1}{2}$ down 5 $\frac{1}{2}$ x 8 5/8 to surface. Displace to 100 ft. ks cement from 85 ft. to surface. RDMO plugging equipment.
or recompletion. 12-11-2012 – MIRU Plugging Equipment 1-12-2012 – Tag existing 5 ½ CIBP @ 7618 ft. Circulate hole w/ 180 barrels of mud l 1-13-2012 – Tag cement plug @ 6402 ft. Perforate @ 5550 ft. 5 ½ packer @ 4924 ft. 1-16-2012 – Tag cement plug @ 5197 ft. Spot 93 sacks from 4572 ft. WOC. Tag cement Note: Combined plugs @ 4039 ft. & 4570 ft. into 1 plug 1-17-2012 – Perforate @ 3200 ft. 5 ½ packer @ 2721 ft. Pressure tested to 1500 psi. C 3050 ft. Spot 30 sacks from 3250 ft. WOC. Tag cement plug 2978 ft. Per Established circulation 5 ½ x 878 casing. Pump 80 sacks cement. WOC. 1-18-2012 – Tag cement plug @ 1127 ft. Perforate @ 243 ft. Pump 60 sacks cement 8 5/8 x 13 3/8 casing pressure tested. Tag cement plug @ 85 ft. spot 8 sack	aden fluid. Spot 125 sacks cement (1234 ft.) Squeeze 60 sacks cement. WOC Int plug @ 3722 ft. Contact OCD, advised to spot 30 sacks from forate @ 1350 ft. 5 $\frac{1}{2}$ packer @ 1036 ft. $\frac{1}{2}$ down 5 $\frac{1}{2}$ x 8 5/8 to surface. Displace to 100 ft. ks cement from 85 ft. to surface. RDMO plugging equipment.
or recompletion. 12-11-2012 – MIRU Plugging Equipment 1-12-2012 – Tag existing 5 ½ CIBP @ 7618 ft. Circulate hole w/ 180 barrels of mud I 1-13-2012 – Tag cement plug @ 6402 ft. Perforate @ 5550 ft. 5 ½ packer @ 4924 ft. 1-16-2012 – Tag cement plug @ 5197 ft. Spot 93 sacks from 4572 ft. WOC. Tag cement Note: Combined plugs @ 4039 ft. & 4570 ft. into 1 plug 1-17-2012 – Perforate @ 3200 ft. 5 ½ packer @ 2721 ft. Pressure tested to 1500 psi. C 3050 ft. Spot 30 sacks from 3250 ft. WOC. Tag cement plug 2978 ft. Per Established circulation 5 ½ x 878 casing. Pump 80 sacks cement. WOC. 1-18-2012 – Tag cement plug @ 1127 ft. Perforate @ 243 ft. Pump 60 sacks cement # 8 5/8 x 13 3/8 casing pressure tested. Tag cement plug @ 85 ft. spot 8 sack Cut-off well-head and anchors. Clean location. Install dry-hole marker.	aden fluid. Spot 125 sacks cement (1234 ft.) Squeeze 60 sacks cement. WOC Int plug @ 3722 ft. Contact OCD, advised to spot 30 sacks from forate @ 1350 ft. 5 $\frac{1}{2}$ packer @ 1036 ft. $\frac{1}{2}$ down 5 $\frac{1}{2}$ x 8 5/8 to surface. Displace to 100 ft. ks cement from 85 ft. to surface. RDMO plugging equipment.
or recompletion. 12-11-2012 – MIRU Plugging Equipment 1-12-2012 – Tag existing 5 ½ CIBP @ 7618 ft. Circulate hole w/ 180 barrels of mud I 1-13-2012 – Tag cement plug @ 6402 ft. Perforate @ 5550 ft. 5 ½ packer @ 4924 ft. 1-16-2012 – Tag cement plug @ 5197 ft. Spot 93 sacks from 4572 ft. WOC. Tag cement Note: Combined plugs @ 4039 ft. & 4570 ft. into 1 plug 1-17-2012 – Perforate @ 3200 ft. 5 ½ packer @ 2721 ft. Pressure tested to 1500 psi. C 3050 ft. Spot 30 sacks from 3250 ft. WOC. Tag cement plug 2978 ft. Per Established circulation 5 ½ x 878 casing. Pump 80 sacks cement. WOC. 1-18-2012 – Tag cement plug @ 1127 ft. Perforate @ 243 ft. Pump 60 sacks cement wocc. 1-18-2012 – Tag cement plug @ 1127 ft. Perforate @ 243 ft. spot 8 sac Cut-off well-head and anchors. Clean location. Install dry-hole marker. I hereby certify that the information above is true and complete to the best of my knowled grade tank has been/will be completed or closed according to MOCD guidelines ⊠, a general permit [ SIGNATURE	aden fluid. Spot 125 sacks cement (1234 ft.) Squeeze 60 sacks cement. WOC ent plug @ 3722 ft. Contact OCD, advised to spot 30 sacks from forate @ 1350 ft. 5 ½ packer @ 1036 ft. (c 4) down 5 ½ x 8 5/8 to surface. Displace to 100 ft. ks cement from 85 ft. to surface. RDMO plugging equipment. ge and belief. I further certify that any pit or below- ] or an (attached) alternative OCD-approved plan ].
or recompletion. 12-11-2012 – MIRU Plugging Equipment 1-12-2012 – Tag existing 5 ½ CIBP @ 7618 ft. Circulate hole w/ 180 barrels of mud I 1-13-2012 – Tag cement plug @ 6402 ft. Perforate @ 5550 ft. 5 ½ packer @ 4924 ft. 1-16-2012 – Tag cement plug @ 5197 ft. Spot 93 sacks from 4572 ft. WOC. Tag cement Note: Combined plugs @ 4039 ft. & 4570 ft. into 1 plug 1-17-2012 – Perforate @ 3200 ft. 5 ½ packer @ 2721 ft. Pressure tested to 1500 psi. C 3050 ft. Spot 30 sacks from 3250 ft. WOC. Tag cement plug 2978 ft. Per Established circulation 5 ½ x 8/8 casing. Pump 80 sacks cement. WOC. 1-18-2012 – Tag cement plug @ 1127 ft. Perforate @ 243 ft. Pump 60 sacks cement wOC. 1-18-2012 – Tag cement plug @ 1127 ft. Perforate @ 243 ft. Pump 60 sacks cement & 8 5/8 x 13 3/8 casing pressure tested. Tag cement plug @ 85 ft. spot 8 sac Cut-off well-head and anchors. Clean location. Install dry-hole marker. SIGNATURE	aden fluid. Spot 125 sacks cement (1234 ft.) Squeeze 60 sacks cement. WOC ent plug @ 3722 ft. Contact OCD, advised to spot 30 sacks from forate @ 1350 ft. 5 ½ packer @ 1036 ft. (c 4) down 5 ½ x 8 5/8 to surface. Displace to 100 ft. ks cement from 85 ft. to surface. RDMO plugging equipment. ge and belief. I further certify that any pit or below- ] or an (attached) alternative OCD-approved plan ].
or recompletion. 12-11-2012 – MIRU Plugging Equipment 1-12-2012 – Tag existing 5 ½ CIBP @ 7618 ft. Circulate hole w/ 180 barrels of mud I 1-13-2012 – Tag cement plug @ 6402 ft. Perforate @ 5550 ft. 5 ½ packer @ 4924 ft. 1-16-2012 – Tag cement plug @ 5197 ft. Spot 93 sacks from 4572 ft. WOC. Tag cement Note: Combined plugs @ 4039 ft. & 4570 ft. into 1 plug 1-17-2012 – Perforate @ 3200 ft. 5 ½ packer @ 2721 ft. Pressure tested to 1500 psi. C 3050 ft. Spot 30 sacks from 3250 ft. WOC. Tag cement plug 2978 ft. Per Established circulation 5 ½ x 878 casing. Pump 80 sacks cement. WOC. 1-18-2012 – Tag cement plug @ 1127 ft. Perforate @ 243 ft. Pump 60 sacks cement wocc. 1-18-2012 – Tag cement plug @ 1127 ft. Perforate @ 243 ft. spot 8 sac Cut-off well-head and anchors. Clean location. Install dry-hole marker. I hereby certify that the information above is true and complete to the best of my knowled grade tank has been/will be completed or closed according to MOCD guidelines ⊠, a general permit [ SIGNATURE	aden fluid. Spot 125 sacks cement (1234 ft.) Squeeze 60 sacks cement. WOC ent plug @ 3722 ft. Contact OCD, advised to spot 30 sacks from forate @ 1350 ft. 5 ½ packer @ 1036 ft. 4 4 down 5 ½ x 8 5/8 to surface. Displace to 100 ft. ks cement from 85 ft. to surface. RDMO plugging equipment. ge and belief. I further certify that any pit or below- ] or an (attached) alternative OCD-approved plan []. (Basic Energy Services) DATE
or recompletion. 12-11-2012 – MIRU Plugging Equipment 1-12-2012 – Tag existing 5 ½ CIBP @ 7618 ft. Circulate hole w/ 180 barrels of mud I 1-13-2012 – Tag cement plug @ 6402 ft. Perforate @ 5550 ft. 5 ½ packer @ 4924 ft. 1-16-2012 – Tag cement plug @ 5197 ft. Spot 93 sacks from 4572 ft. WOC. Tag cement Note: Combined plugs @ 4039 ft. & 4570 ft. into 1 plug 1-17-2012 – Perforate @ 3200 ft. 5 ½ packer @ 2721 ft. Pressure tested to 1500 psi. C 3050 ft. Spot 30 sacks from 3250 ft. WOC. Tag cement plug 2978 ft. Per Established circulation 5 ½ x 878 casing. Pump 80 sacks cement. WOC. 1-18-2012 – Tag cement plug @ 1127 ft. Perforate @ 243 ft. Pump 60 sacks cement work. 8 5/8 x 13 3/8 casing pressure tested. Tag cement plug @ 85 ft. spot 8 sack Cut-off well-head and anchors. Clean location. Install dry-hole marker. I hereby certify that the information above is true and complete to the best of my knowled grade tank has been/will be computed or closed according to KMOCD guidelines ⊠, a general permit [ SIGNATURE	aden fluid. Spot 125 sacks cement (1234 ft.) Squeeze 60 sacks cement. WOC nt plug @ 3722 ft. Contact OCD, advised to spot 30 sacks from forate @ 1350 ft. 5 ½ packer @ 1036 ft. 4 down 5 ½ x 8 5/8 to surface. Displace to 100 ft. ks cement from 85 ft. to surface. RDMO plugging equipment. ge and belief. I further certify that any pit or below- ] or an (attached) alternative OCD-approved plan []. (Basic Energy Services) DATE Telephone No. 432-563-3355
or recompletion. 12-11-2012 – MIRU Plugging Equipment 1-12-2012 – Tag existing 5 ½ CIBP @ 7618 ft. Circulate hole w/ 180 barrels of mud I 1-13-2012 – Tag cement plug @ 6402 ft. Perforate @ 5550 ft. 5 ½ packer @ 4924 ft. 1-16-2012 – Tag cement plug @ 5197 ft. Spot 93 sacks from 4572 ft. WOC. Tag cement Note: Combined plugs @ 4039 ft. & 4570 ft. into 1 plug 1-17-2012 – Perforate @ 3200 ft. 5 ½ packer @ 2721 ft. Pressure tested to 1500 psi. C 3050 ft. Spot 30 sacks from 3250 ft. WOC. Tag cement plug 2978 ft. Per Established circulation 5 ½ x 878 casing. Pump 80 sacks cement. WOC. 1-18-2012 – Tag cement plug @ 1127 ft. Perforate @ 243 ft. Pump 60 sacks cement is 8 5/8 x 13 3/8 casing pressure tested. Tag cement plug @ 85 ft. spot 8 sac Cut-off well-head and anchors. Clean location. Install dry-hole marker. I hereby certify that the information above is true and complete to the best of my knowled grade tank has been/will be conflucted or closed according to tMOCD guidelines 🖾, a general permit SIGNATURE	aden fluid. Spot 125 sacks cement (1234 ft.) Squeeze 60 sacks cement. WOC ent plug @ 3722 ft. Contact OCD, advised to spot 30 sacks from forate @ 1350 ft. 5 ½ packer @ 1036 ft. 4 4 down 5 ½ x 8 5/8 to surface. Displace to 100 ft. ks cement from 85 ft. to surface. RDMO plugging equipment. ge and belief. I further certify that any pit or below- ] or an (attached) alternative OCD-approved plan []. (Basic Energy Services) DATE
or recompletion. 12-11-2012 – MIRU Plugging Equipment 1-12-2012 – Tag existing 5 ½ CIBP @ 7618 ft. Circulate hole w/ 180 barrels of mud I 1-13-2012 – Tag cement plug @ 6402 ft. Perforate @ 5550 ft. 5 ½ packer @ 4924 ft. 1-16-2012 – Tag cement plug @ 5197 ft. Spot 93 sacks from 4572 ft. WOC. Tag cement Note: Combined plugs @ 4039 ft. & 4570 ft. into 1 plug 1-17-2012 – Perforate @ 3200 ft. 5 ½ packer @ 2721 ft. Pressure tested to 1500 psi. C 3050 ft. Spot 30 sacks from 3250 ft. WOC. Tag cement plug 2978 ft. Per Established circulation 5 ½ x 878 casing. Pump 80 sacks cement. WOC. 1-18-2012 – Tag cement plug @ 1127 ft. Perforate @ 243 ft. Pump 60 sacks cement s 8 5/8 x 13 3/8 casing pressure tested. Tag cement plug @ 85 ft. spot 8 sac Cut-off well-head and anchors. Clean location. Install dry-hole marker. I hereby certify that the information above is true and complete to the best of my knowled grade tank has been/will be completed or closed according to KMOCD guidelines 🔄, a general permit [ SIGNATURE	aden fluid. Spot 125 sacks cement (1234 ft.) Squeeze 60 sacks cement. WOC nt plug @ 3722 ft. Contact OCD, advised to spot 30 sacks from forate @ 1350 ft. 5 ½ packer @ 1036 ft. 4 down 5 ½ x 8 5/8 to surface. Displace to 100 ft. ks cement from 85 ft. to surface. RDMO plugging equipment. ge and belief. I further certify that any pit or below- ] or an (attached) alternative OCD-approved plan []. (Basic Energy Services) DATE Telephone No. 432-563-3355
or recompletion. 12-11-2012 - MIRU Plugging Equipment 1-12-2012 - Tag existing 5 ½ CIBP @ 7618 ft. Circulate hole w/ 180 barrels of mud I 1-13-2012 - Tag cement plug @ 6402 ft. Perforate @ 5550 ft. 5 ½ packer @ 4924 ft. 1-16-2012 - Tag cement plug @ 5197 ft. Spot 93 sacks from 4572 ft. WOC. Tag cemen Note: Combined plugs @ 4039 ft. & 4570 ft. into 1 plug 1-17-2012 - Perforate @ 3200 ft. 5 ½ packer @ 2721 ft. Pressure tested to 1500 psi. C 3050 ft. Spot 30 sacks from 3250 ft. WOC. Tag cement plug 2978 ft. Per Established circulation 5 ½ x 878 casing. Pump 80 sacks cement. WOC. 1-18-2012 - Tag cement plug @ 1127 ft. Perforate @ 243 ft. Pump 60 sacks cement. WOC. 1-18-2012 - Tag cement plug @ 1127 ft. Perforate @ 243 ft. Pump 60 sacks cement % 5/8 x 13 3/8 casing pressure tested. Tag cement plug @ 85 ft. spot 8 sac Cut-off well-head and anchors. Clean location. Install dry-hole marker. I hereby certify that the information above is true and complete to the best of my knowled grade tank has been/will be completed or closed according to MOCD guidelines ⊠, a general permit [ SIGNATURE	aden fluid. Spot 125 sacks cement (1234 ft.) Squeeze 60 sacks cement. WOC nt plug @ 3722 ft. Contact OCD, advised to spot 30 sacks from forate @ 1350 ft. 5 ½ packer @ 1036 ft. 4 down 5 ½ x 8 5/8 to surface. Displace to 100 ft. ks cement from 85 ft. to surface. RDMO plugging equipment. ge and belief. I further certify that any pit or below- ] or an (attached) alternative OCD-approved plan []. (Basic Energy Services) DATE Telephone No. 432-563-3355
or recompletion. 12-11-2012 – MIRU Plugging Equipment 1-12-2012 – Tag existing 5 ½ CIBP @ 7618 ft. Circulate hole w/ 180 barrels of mud I 1-13-2012 – Tag cement plug @ 6402 ft. Perforate @ 5550 ft. 5 ½ packer @ 4924 ft. 1-16-2012 – Tag cement plug @ 5197 ft. Spot 93 sacks from 4572 ft. WOC. Tag cement Note: Combined plugs @ 4039 ft. & 4570 ft. into 1 plug 1-17-2012 – Perforate @ 3200 ft. 5 ½ packer @ 2721 ft. Pressure tested to 1500 psi. C 3050 ft. Spot 30 sacks from 3250 ft. WOC. Tag cement plug 2978 ft. Per Established circulation 5 ½ x 878 casing. Pump 80 sacks cement. WOC. 1-18-2012 – Tag cement plug @ 1127 ft. Perforate @ 243 ft. Pump 60 sacks cement s 8 5/8 x 13 3/8 casing pressure tested. Tag cement plug @ 85 ft. spot 8 sac Cut-off well-head and anchors. Clean location. Install dry-hole marker. I hereby certify that the information above is true and complete to the best of my knowled grade tank has been/will be completed or closed according to KMOCD guidelines 🔄, a general permit [ SIGNATURE	aden fluid. Spot 125 sacks cement (1234 ft.) Squeeze 60 sacks cement. WOC nt plug @ 3722 ft. Contact OCD, advised to spot 30 sacks from forate @ 1350 ft. 5 ½ packer @ 1036 ft. 4 down 5 ½ x 8 5/8 to surface. Displace to 100 ft. ks cement from 85 ft. to surface. RDMO plugging equipment. ge and belief. I further certify that any pit or below- ] or an (attached) alternative OCD-approved plan []. (Basic Energy Services) DATE Telephone No. 432-563-3355