

Submit 1 Copy To Appropriate District  
Office  
District I - (575) 393-6161  
1625 N French Dr, Hobbs, NM 88240  
District II - (575) 748-1283  
811 S First St, Artesia, NM 88210  
District III - (505) 334-6178  
1000 Rio Brazos Rd, Aztec, NM 87410  
District IV - (505) 476-3460  
1220 S St Francis Dr, Santa Fe, NM  
87505

State of New Mexico  
Energy, Minerals and Natural Resources

Form C-103  
Revised August 1, 2011

HOBBS OCD

OIL CONSERVATION DIVISION

1220 South St. Francis Dr.  
Santa Fe, NM 87505

APR 09 2012

RECEIVED

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH  
PROPOSALS)

1. Type of Well: Oil Well ☒ Gas Well ☐ Other ☐

2. Name of Operator  
Occidental Permian Ltd.

3. Address of Operator  
HCR 1 Box 90 Denver City, TX 79323

4. Well Location

Unit Letter D : 843 feet from the North line and 540 feet from the West line

Section 24 Township 18S Range 37E NMPM Lea County

11. Elevation (Show whether DR, RKB, RT, GR, etc)  
3642' KB

WELL API NO.

30-025-34567 35467

5. Indicate Type of Lease  
STATE ☒ FEE ☐

6. State Oil & Gas Lease No.

7. Lease Name or Unit Agreement Name  
North Hobbs (G/SA) Unit ☒  
Section 24

8. Well Number 611 ☒

9. OGRID Number: 157984 ☒

10. Pool name or Wildcat Hobbs (G/SA)

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☒ PLUG AND ABANDON ☐  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐  
DOWNHOLE COMMINGLE ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ P AND A ☐  
CASING/CEMENT JOB ☐

OTHER: ☐

OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

- 1) POOH with prod equip.
- 2) Clean out to 4378'
- 3) Run pkr. Set at 4100'
- 4) Run prod flow log. Identify high GOR layers
- 5) POOH with pkr
- 6) Sqz high GOR layers
- 7) Do cmt sqz.
- 8) Return well to production

Spud Date:

Rig Release Date:

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

Steve Snead

TITLE Lift Specialist

DATE 4/2/2012

Type or print name Steve Snead

E-mail address: steve\_snead@Oxy.com

PHONE: 806-592-6312

For State Use Only

APPROVED BY

Steve Snead

TITLE

Staff Manager

DATE

4-9-2012

2012 10 2012