

Office:

District I - (575) 393-6161

1625 N French Dr., Hobbs, NM

District II - (575) 748-1283

811 S First St., Artesia, NM 88210

District III - (505) 334-6178

1000 Rio Brazos Rd., Aztec, NM 87410

District IV - (505) 476-3460

1220 S St Francis Dr., Santa Fe, NM

87505

Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION

1220 South St. Francis Dr.

Santa Fe, NM 87505

HOBBBS OGD
JUN 18 2012
RECEIVED

WELL API NO. 30-025-07653	✓
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>	✓
6. State Oil & Gas Lease No.	
7. Lease Name or Unit Agreement Name South Hobbs (G/SA) Unit	✓
8. Well Number 119	✓
9. OGRID Number: 157984	✓
10. Pool name or Wildcat Hobbs (G/SA)	✓

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS)

1. Type of Well: Oil Well ☐ Gas Well ☐ Other Injector ☐2. Name of Operator
Occidental Permian Ltd.3. Address of Operator
HCR 1 Box 90 Denver City, TX 79323

4. Well Location

Unit Letter C : 330 feet from the North line and 2310 feet from the West lineSection 8 Township 19S Range 38E NMPM Lea County11. Elevation (Show whether DR, RKB, RT, GR, etc.)
3623' KB

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
 TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
 PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐
 DOWNHOLE COMMINGLE ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
 COMMENCE DRILLING OPNS. ☐ P AND A ☐
 CASING/CEMENT JOB ☐

OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

1. POOH with tbg and pkr.
2. TIH w/ bit and clean out to 4010'. TOH w/ bit.
3. RIH w/ 5 1/2" CIBP and set at 3960'. Cap with 35' of cmt.
4. Circulate 10# MLF.
5. Spot 30 sx of cmt from 2933-3053'. WOC. Tag.
6. Spot 50 sx of cmt from 1550-1750'. WOC. Tag.
7. Perforate at 400'. Sqz well and circulate to surface. Top well-off as necessary.
8. Cut off wellhead and install dry hole marker with labeling.
9. Clean up location, remove anchors.

Spud Date:

Rig Release:

The Oil Conservation Division Must be notified
24 hours prior to the beginning of plugging operations.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

Mendy A. Johnson
MENDY A. JOHNSON

TITLE

ADMIN ASST

DATE

6/15/12

Type or print name

E-mail address

MENDY-JOHNSON@OXY.COM

For State Use Only

APPROVED BY:

TITLE

STATE MGR

DATE

6-27-2012

Conditions of Approval (if any):

JUN 28 2012

8 5/8" 28# @ 281'
Cmt w/ 250 sx Circulated

Perforate at 400' and sqz

Perf #50
50 sx of cmt from 1550-1750'

30 sx of cmt from 2953 -3053

5 1/2" 15 5# @ 4010' w/ 350 sx
TOC 2852' (CBL-7/1984)

CIBP at 3960' Capped with 35' of cmt

Open Hole Completion, Grayburg/San Andres

4010-4110'

TD 4110'