Submit 3 Copies To Appropriate District Office				Form C-103 June 19, 2008		
District 1 1625 N. French Dr., Hobbs, NM 87240			WELL API NO.			
District II 1301 W. Grand Ave. Actoria NM 88310 HOBBS DOCONSERVATION DIVISION			30-025-11538			
1501 W. Glalid Ave., Altesia, WW 60210			5. Indicate Type of Lease STATE FEE			
District III 1000 Rio Brazos Rd., Aztec, NM 87410 District IV JUL 3 0 2012 Santa Fe, NM 87505 Santa Fe, NM 87505			STATE kx FEE 6. State Oil & Gas Lease No.			
1220 S St. Francis Dr , Santa Fe, NM 87505			0. State Off	& Gas Lease No.		
SUNDRY NOT REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)			7. Lease Name or Unit Agreement Name: Stuart Langlie Mattix Unit			
1. Type of Well: Oil Well Gas Well Other			8. Well Number			
2. Name of Operator			9. OGRID Number			
Energen Resources Corporation 3. Address of Operator			162928 10. Pool name or Wildcat			
3300 N. "A" St., Bldg 4, Ste. 100, Midland, TX 79705			Langlie Mattix 7 RVRS Queen Grayburg			
4. Well Location						
Unit Letter : 6	feet from the No.	rth line and	660 fe	eet from the Wes	tline	
Section 11		Range 37E	NMPM	County	Lea	
	11. Elevation (Show whether 313)	DR, RKB, RT, GR, et 34' GR	c.)			
12. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data						
12. Check App	ropriate Box to indicate	rature of rottee,	report, or e	ther Bata		
NOTICE OF INTENTION TO:			SSEQUENT REPORT OF:			
PERFORM REMEDIAL WORK PLUG AND ABANDON X REMEDI				ALTERING	CASING 🔲	
TEMPORARILY ABANDON 🔲 CHANGE PLANS 🔲 COMMENCE DRILI		ING OPNS. [P AND A			
PULL OR ALTER CASING	CASING/CEMENT J	ов []			
DOWNHOLE COMMINGLE						
OTHER.		OTHER.				
OTHER:	magations (Clearly state all me	OTHER:				
13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.						
•						
See attached Procedure						
THE OIL CONSERVATION DIV BE NOTIFIED 24 HOURS PRICE BEGINNING OF PLUGGING O	OR TO THE					
BEGINNING S. 1200 S. 1		-				
Spud Date:	Rig Relea	ase Date:				
I hereby certify that the information abo	ove is true and complete to the	best of my knowledg	e and belief.			
SIGNATURE - O	Lu TIT		ry Analyst	DATE 7	/25/12	
		Jenifer.sorley@	_			
Type or print name <u>Jenifer Sorley</u> E-mail address: PHONE <u>432-818-1732</u>						
For State Use Only						
APPROVED BY	TIT	LE LUST N	4/2	DATE &-/ -	-2012	
Conditions of Approval (if any):				A	UG 0-1 2012	

Sec 11, T25S, R37E **Energen Resources** 660' FNL & 660' FWL **SLMU #110** 7/9/2012 Lea County, NM Completion Date: 2/27/1939 TD: 3,484' **Current Wellbore** 10 3/4" Casing @ 259' (250 sxs, circulated to surface) TOC 2,181' 5/26/2012 Tagged up with 4.968" gauge ring and junk basket @ 3,138'

6" 16# @ 3,292' w/ 350 sxs

TD 3,484

4-1/2" FJ Liner (BTM 1.5 Joints Slotted) @ 3,260'-3,484'

Energen Resources SLMU #110 7/9/2012 TD: 3,484' Sec 11, T25S, R37E 660' FNL & 660' FWL Lea County, NM Completion Date: 2/27/1939

Completion Date: 2/27/1939 **Proposed Wellbore** 10 3/4" Casing @ 259' (250 sxs, circulated to surface) Perf @ 315', squeeze and circulate cmt to surface 311' to surface 50 sxs Perf @ 1,125' and squeeze 25 sxs, WOC and tag TOC 2,181' Perf @ 2,425' and squeeze 25 sxs, WOC and tag-6" 16# @ 3,292' w/ 350 sxs _ 3345 Set cement plug at 3,310 with 35 sxs, WOC and tag 4-1/2" FJ Liner (BTM 1.5 Joints Slotted) @ 3,260'-3,484'

TD 3,484

SLMU 110 Stuart Langlie Mattix Unit Lea County, NM

660' FNL & 660' FWL Sec 11, T25S, R37E API — 300251153800 Completion Date: 2/27/1939

Plug & Abandon Procedure

- 3 RIH to 3,310. Spot 35 sxs cement. WOC & tag
 4 Perforate at 2,425' and squeeze with 25
 5 Perforate
- 5 Perforate at 1,125' and squeeze with 25 sxs cement, WOC & tag.
- 6 Perforate at 315'. Squeeze and circulate cement to surface.
- 7 Cut off all casing strings at base of cellar or 3' below restored ground level.
- 8 Cover wellbore with metal plate welded in place or with cement cap.
- 9 Erect capped abandonment marker inscribed with well information.
- 10 Cut off dead man anchors and fill in cellar.
- 11 Clean and restore location to natural condition and fulfill any and all regulatory

Prepared by: Brian Hillger 7/10/2012