Form 3160-5	UNITED STATES	ر د رو داناه دسو یل ا	n Conser 1625 N. Fr	ation Divisi each Drive	• •••••••• وللال - 	ORM APPROVED DMB No. 1004-0137
01	IDEALLOP LAND MANA		Home, P	IN OCTO	EN	spires: October 31, 2014
SUNDRY Do not use thi abandoned well	NOTICES AND REPOR s form for proposals to a l. Use Form 3160-3 (APL	TS ON WE drill or to re D) for such	LLS HOB e-enter an proposets	6 1f Ind	ian, Allottee o	r Tribe Name
SUB	MIT IN TRIPLICATE Other ins		age 2.	7. If Un	it of CA/Agree	ment, Name and/or No.
Type of Well Oil Well Ga	s Well Other	/	R	ECEIVED 8 Well	Name and No	/
2 Name of Operator Ridgeway Arizona Oil Corp.				9. API V	I 23 #10 Well No. -10536	
3a Address 200 N Loraine STE 1440		Phone No. (in	clude area code) 10. Fiel		Exploratory Area
Midland, TX 79701 4 Location of Well <i>Arootage, Sec.,</i> 1980 FNL 1980 FEL Sec 23, T-7S, R-33E	4	32-687-0303		11 Cou	nty or Parish, Svelt County	·····
12 CH	ECK THE APPROPRIATE BOX	ES) TO INDIC/	ATE NATURE	OF NOTICE, REPO	ORT OR OTHI	ER DATA
TYPE OF SUBMISSION			TYP	E OF ACTION		
Notice of Intent	Acidize	Deepen Fracture		Production (St	art/Resume)	Water Shut-Off Well Integrity
Subsequent Report	Casing Repair	Plug and	Istruction Abandon	Recomplete Temporarity A		Other Workover
Final Abandonment Notice	Convert to Injection	Plug Bac	k	Water Disposa	1	
testing has been completed Fir determined that the site is ready MIRU PU/RU/WS	nal Abandonment Notices must be f for final inspection)					a Form 3160-4 must be filed once completed and the operator has
testing has been completed Fir determined that the site is ready MIRU PU/RU/WS 1. POOH w/rods, down hole purr 2. NDWH/NUBOP, POOH w/tubi 3. Pick up 2 3/8 WS from rack, p 4. If casing checks good, Notify E 5. RIH w/ 2 3/8 x 4 1/2 CIBP/Pac 6. If tests good, POOH w/WS to 7. Set pkr/shut in backside and p 8. If MIT is successful - get BLM 9. If MIT is unsuccessful - releas and proceed with reactiviation or 10. If casing has intergrity, releas 11. RIH w/bit/bit sub/WS, rig up re 12. POOH w/WS/bit, lay down bit 13. MIRU acid truck and purp 15 14. Haul new tubing string/rod str	nal Abandonment Notices must be f of final inspection) ing - laying down ing - laying down ick up bit sub, 2 3/8 x 3 7/8 bit - BLM/RFO Field Tech that MIT w cker to within 100ft. of top perf, s 50 ft. from surface - Rig up Rerv pressure casing to 500 psi for 30 Field Tech to sign chart and ser ie packer and spot casing leak a initiate P & A process. se packer, RIH and retrieve CIBF everse unit and circulate any fill c, pick up packer, RIH to within 14 50 gal 15% HCL - record pressure	RIN w/WS to c ill occur within et CIBP, Pull u rerse unit and I minutes. Ind chart to Mid nd establish ra P, POOH w/W out to TD 00ft. of top per re and rate - R	Il requirements, 24 hours. up 1 stand, set load hole w/FV land Office. nte - Contact M S/pkr/CIBP - la f - set packer ug down acid t	or recompletion in including reclamat pr - tallin in pkr, test CIBP V - work out air- R lidland Office - pla aying down CIBP/ and prepare for ac ruck, POOH w/WS	tig up chart re ans will be ma PKR cid job S/Bit - laying o	completed and the operator has
testing has been completed Fir determined that the site is ready MIRU PU/RU/WS 1. POOH w/rods, down hole purr 2. NDWH/NUBOP, POOH w/tubi 3. Pick up 2 3/8 WS from rack, p 4. If casing checks good, Notify B 5. RIH w/ 2 3/8 x 4 1/2 CIBP/Pac 6. If tests good, POOH w/WS to 7. Set pkr/shut in backside and p 8. If MIT is successful - get BLM 9. If MIT is unsuccessful - get BLM 9. If MIT is unsuccessful - releas and proceed with reactiviation or 10. If casing has intergrity, releas 11. RIH w/bit/bit sub/WS, rig up re 12. POOH w/WS/bit, lay down bit 13. MIRU acid truck and pump 15 14. Haul new tubing string/rod str 15. RDMO PU	hal Abandonment Notices must be f of final inspection) hp, laying down ing - laying down ick up bit sub, 2 3/8 x 3 7/8 bit - BLM/RFO Field Tech that MIT w cker to within 100ft. of top perf, s 50 ft. from surface - Rig up Rerv pressure casing to 500 psi for 30 Field Tech to sign chart and ser te packer and spot casing leak at initiate P & A process. se packer, RIH and retrieve CIBF everse unit and circulate any fill of t, pick up packer, RIH to within 11 50 gal 15% HCL - record pressur ing/rod pump to location - RIH w	RIN w/WS to c ill occur within et CIBP, Pull u erse unit and I minutes. nd chart to Mid nd establish ra P, POOH w/WS out to TD 00ft. of top per re and rate - R //Downhole eq	Il requirements, 24 hours. up 1 stand, set load hole w/FV land Office. nte - Contact M S/pkr/CIBP - la f - set packer ig down acid t	or recompletion in including reclamat pr - tallin in pkr, test CIBP V - work out air- R lidland Office - pla aying down CIBP/ and prepare for ac ruck, POOH w/WS	tig up chart re ans will be ma PKR cid job S/Bit - laying o	completed and the operator has
testing has been completed. Fin determined that the site is ready MIRU PU/RU/WS 1. POOH w/rods, down hole purn 2. NDWH/NUBOP, POOH w/tubi 3. Pick up 2 3/8 WS from rack, p 4. If casing checks good, Notify E 5. RIH w/ 2 3/8 x 4 1/2 CIBP/Pac 6. If tests good, POOH w/WS to 7. Set pkr/shut in backside and p 8. If MIT is successful - get BLM 9. If MIT is unsuccessful - get BLM 9. If MIT is unsuccessful - releas and proceed with reactiviation or 10. If casing has intergrity, releas 11. RIH w/bit/bit sub/WS, rig up re 12. POOH w/WS/bit, lay down bit 13. MIRU acid truck and pump 15 14. Haul new tubing string/rod str 15. RDMO PU	hal Abandonment Notices must be f of final inspection) hp, laying down ing - laying down ick up bit sub, 2 3/8 x 3 7/8 bit - BLM/RFO Field Tech that MIT w cker to within 100ft. of top perf, s 50 ft. from surface - Rig up Rerv pressure casing to 500 psi for 30 Field Tech to sign chart and ser te packer and spot casing leak at initiate P & A process. se packer, RIH and retrieve CIBF everse unit and circulate any fill of t, pick up packer, RIH to within 11 50 gal 15% HCL - record pressur ing/rod pump to location - RIH w	RIN w/WS to c ill occur within et CIBP, Pull u rerse unit and I minutes. nd chart to Mid nd establish ra P, POOH w/W3 out to TD 00ft. of top per re and rate - R //Downhole eq	Il requirements, 24 hours. up 1 stand, set load hole w/FV land Office. nte - Contact M S/pkr/CIBP - la f - set packer ig down acid t	or recompletion in including reclamat pkr, test CIBP V - work out air- R lidland Office - pla aying down CIBP/ and prepare for ac ruck, POOH w/WS well on, load tubi	tig up chart re ans will be ma PKR cid job S/Bit - laying o	completed and the operator has
testing has been completed. Fin determined that the site is ready MIRU PU/RU/WS 1. POOH w/rods, down hole purn 2. NDWH/NUBOP, POOH w/tubi 3. Pick up 2 3/8 WS from rack, p 4. If casing checks good, Notify E 5. RIH w/ 2 3/8 x 4 1/2 CIBP/Pac 6. If tests good, POOH w/WS to 7. Set pkr/shut in backside and p 8. If MIT is successful - get BLM 9. If MIT is successful - get BLM 9. If MIT is unsuccessful - releas and proceed with reactiviation or 10. If casing has intergrity, releas 11. RIH w/bit/bit sub/WS, rig up re 12. POOH w/WS/bit, lay down bit 13. MIRU acid truck and pump 15 14. Haul new tubing string/rod str 15. RDMO PU	hal Abandonment Notices must be f of final inspection) hp, laying down ing - laying down ick up bit sub, 2 3/8 x 3 7/8 bit - BLM/RFO Field Tech that MIT w cker to within 100ft. of top perf, s 50 ft. from surface - Rig up Rerv pressure casing to 500 psi for 30 Field Tech to sign chart and ser te packer and spot casing leak at initiate P & A process. se packer, RIH and retrieve CIBF everse unit and circulate any fill of t, pick up packer, RIH to within 11 50 gal 15% HCL - record pressur ing/rod pump to location - RIH w	RIN w/WS to c ill occur within et CIBP, Pull u rerse unit and I minutes. nd chart to Mid nd establish ra P, POOH w/W out to TD 00ft. of top per re and rate - R //Downhole eq	II requirements, 24 hours. up 1 stand, set load hole w/FV land Office. tte - Contact M S/pkr/CIBP - la f - set packer ig down acid t uipment, hang	or recompletion in including reclamat pr - tallin in pkr, test CIBP V - work out air- R lidland Office - pla aying down CIBP/ and prepare for a ruck, POOH w/WS well on, load tubi	tig up chart re ans will be ma PKR cid job S/Bit - laying o	completed and the operator has
testing has been completed Fir determined that the site is ready MIRU PU/RU/WS 1. POOH w/rods, down hole purr 2. NDWH/NUBOP, POOH w/tubil 3. Pick up 2 3/8 WS from rack, p 4. If casing checks good, Notify E 5. RIH w/ 2 3/8 x 4 1/2 CIBP/Pac 6. If tests good, POOH w/WS to 7. Set pkr/shut in backside and p 8. If MIT is successful - get BLM 9. If MIT is unsuccessful - releas and proceed with reactiviation or 10. If casing has intergrity, releas 11. RIH w/bit/bit sub/WS, rig up re 12. POOH w/WS/bit, lay down bit 13. MIRU acid truck and pump 15 14. Haul new tubing string/rod str 15. RDMO PU	hal Abandonment Notices must be f of final inspection) hp, laying down ing - laying down ick up bit sub, 2 3/8 x 3 7/8 bit - BLM/RFO Field Tech that MIT w cker to within 100ft. of top perf, s 50 ft. from surface - Rig up Rerv pressure casing to 500 psi for 30 Field Tech to sign chart and ser te packer and spot casing leak at initiate P & A process. se packer, RIH and retrieve CIBF everse unit and circulate any fill of t, pick up packer, RIH to within 11 50 gal 15% HCL - record pressur ing/rod pump to location - RIH w	RIN w/WS to c ill occur within et CIBP, Pull u rerse unit and I minutes. nd chart to Mid nd establish ra P, POOH w/Ws out to TD 00ft. of top per re and rate - R //Downhole eq	It requirements, 24 hours. 24 hours. 29 1 stand, set load hole w/FV land Office. tte - Contact M S/pkr/CIBP - la f - set packer 1g down acid t uipment, hang tte Regulatory ate 07/23/201	or recompletion in including reclamat pr - tallin in pkr, test CIBP V - work out air- R lidland Office - pla aying down CIBP/ and prepare for ac ruck, POOH w/WS well on, load tubi	tig up chart re ans will be ma PKR cid job S/Bit - laying o ng, wait for p	completed and the operator has
testing has been completed Fir determined that the site is ready MIRU PU/RU/WS 1. POOH w/rods, down hole purr 2. NDWH/NUBOP, POOH w/tubil 3. Pick up 2 3/8 WS from rack, p 4. If casing checks good, Notify E 5. RIH w/ 2 3/8 x 4 1/2 CIBP/Pac 6. If tests good, POOH w/WS to 7. Set pkr/shut in backside and p 8. If MIT is successful - get BLM 9. If MIT is unsuccessful - releas and proceed with reactiviation or 10. If casing has intergrity, releas 11. RIH w/bit/bit sub/WS, rig up re 12. POOH w/WS/bit, lay down bit 13. MIRU acid truck and pump 15 14. Haul new tubing string/rod str 15. RDMO PU	nal Abandonment Notices must be f y for final inspection) np, laying down ing - laying down ick up bit sub, 2 3/8 x 3 7/8 bit - BLM/RFO Field Tech that MIT w cker to within 100ft. of top perf, s 50 ft. from surface - Rig up Rerv oressure casing to 500 psi for 30 Field Tech to sign chart and ser initiate P & A process. se packer and spot casing leak al initiate P & A process. se packer, RIH and retrieve CIBF everse unit and circulate any fill i t, pick up packer, RIH to within 11 50 gal 15% HCL - record pressur- ing/rod pump to location - RIH w Is true and correct Name (<i>Printed/Ty</i>) THIS SPACE FO	RIN w/WS to c ill occur within et CIBP, Pull u rerse unit and I minutes. Ind chart to Mid and establish ra P, POOH w/W3 out to TD 00ft. of top per re and rate - R //Downhole eq //Downhole eq ped) Tri	Il requirements, 24 hours. 24 hours. 24 hours. 29 1 stand, set load hole w/FV land Office. 35 contact M S/pkr/CIBP - la f - set packer 19 down acid t uipment, hang 41 contact M 10 contact	or recompletion in including reclamat pr - tallin in pkr, test CIBP V - work out air- R lidland Office - pla aying down CIBP/ and prepare for ac ruck, POOH w/WS well on, load tubi	tig up chart re ans will be ma PKR cid job S/Bit - laying o ing, wait for p	completed and the operator has
testing has been completed Fir determined that the site is ready MIRU PU/RU/WS 1. POOH w/rods, down hole pur 2. NDWH/NUBOP, POOH w/tub 3. Pick up 2 3/8 WS from rack, p 4. If casing checks good, Notify E 5. RIH w/ 2 3/8 x 4 1/2 CIBP/Pac 6. If tests good, POOH w/WS to 7. Set pkr/shut in backside and p 8. If MIT is successful - get BLM 9. If MIT is unsuccessful - get BLM 9. If MIT is unsucc	nal Abandonment Notices must be f of or final inspection) np, laying down ing - laying down inck up bit sub, 2 3/8 x 3 7/8 bit - BLM/RFO Field Tech that MIT w cker to within 100ft. of top perf, s 50 ft. from surface - Rig up Rerv pressure casing to 500 psi for 30 Field Tech to sign chart and ser initiate P & A process. se packer and spot casing leak al initiate P & A process. se packer, RIH and retrieve CIBF everse unit and circulate any fill i to gal 15% HCL - record pressur- ing/rod pump to location - RIH w Is true and correct Name (Printed/Ty- THIS SPACE FO /ID R. GLASS hed_Approval of this notice does not pired 11-30-2010, The	RIN w/WS to c ill occur within et CIBP, Pull u rerse unit and I minutes. nd chart to Mid nd establish ra P, POOH w/Ws out to TD 00ft. of top per re and rate - R //Downhole eq	Il requirements, ck casing/tag u 24 hours. up 1 stand, set load hole w/FV land Office. te - Contact M S/pkr/CIBP - la f - set packer ig down acid t uipment, hang tle Regulatory te 07/23/201 NL OR STA	or recompletion in including reclamat pr - tallin in pkr, test CIBP V - work out air- R lidland Office - pla aying down CIBP/ and prepare for ac ruck, POOH w/WS well on, load tubi v Assistant	tig up chart re ans will be ma PKR cid job S/Bit - laying o ing, wait for p	completed and the operator has Completed and the operator has
testing has been completed Fir determined that the site is ready MIRU PU/RU/WS 1. POOH w/rods, down hole pur 2. NDWH/NUBOP, POOH w/tub 3. Pick up 2 3/8 WS from rack, p 4. If casing checks good, Notify E 5. RiH w/ 2 3/8 x 4 1/2 CIBP/Pac 6. If tests good, POOH w/WS to 7. Set pkr/shut in backside and p 8. If MIT is successful - get BLM 9. If MIT is unsuccessful - get BLM 9. If All the get BLM 9. If MIT is unsuccessful - get BLM 13. MIRU acid truck and pump 15 14. Haul new tubing string/rod str 15. RDMO PU 14. Thereby certify that the foregoing is Kelly Cox Signature ////////////////////////////////////	nal Abandonment Notices must be f of or final inspection) np, laying down ing - laying down ick up bit sub, 2 3/8 x 3 7/8 bit - BLM/RFO Field Tech that MIT w cker to within 100ft. of top perf, s 50 ft. from surface - Rig up Rerv pressure casing to 500 psi for 30 Field Tech to sign chart and ser are packer and spot casing leak a initiate P & A process. se packer, RIH and retrieve CIBF everse unit and circulate any fill of the packer, RIH and retrieve CIBF everse unit and circulate any fill of the packer, RIH to within 11 50 gal 15% HCL - record pressur- ing/rod pump to location - RIH w is true and correct Name (Printed/Tw THIS SPACE FO /ID R. GLASS hed_Annroval of this nature does not pired 11-30-2010, The Ig WhichThe Production / BLM-NMSO Decision	RIN w/WS to c ill occur within et CIBP, Pull u rerse unit and I minutes. Ind chart to Mid and establish ra P, POOH w/W3 out to TD 00ft. of top per re and rate - R //Downhole eq //Downhole eq //Downhole eq //Downhole eq //Downhole eq //Downhole eq	il requirements, ck casing/tag u 24 hours. up 1 stand, set load hole w/FV land Office. te - Contact M S/pkr/CIBP - la f - set packer ig down acid t uipment, hang uie Regulatory te 07/23/201 NL OR STA y Office hold the PETI	or recompletion in including reclamat pr - tallin in pkr, test CIBP V - work out air- R lidland Office - pla aying down CIBP/ and prepare for ar ruck, POOH w/WS well on, load tubi r Assistant 2 TE OFFICE U	tig up chart re ans will be ma PKR cid job S/Bit - laying o ing, wait for p SE INEER D	completed and the operator has Completed and the operator has

7 .	Form 3160-9 (December 1989)	
	(19604111061 1967)	

by

Certified Mail - Return

Receipt Requested 70081830000260366145

Hand Delivered Received

-	-184 AT	CONT	Number	12KSB26
BI	M	COPY	Page	of

ΡA

UNITED STATES					
DEPARTMENT OF THE INTERIOR					
BUREAU OF LAND MANAGEMENT					

Identification NMNM83197*OEI IID NMNM83197 Lease ĊA Unit

NOTICE OF INCIDENTS OF NONCOMPLIANCE

Bureau of Land Management Office				Operate	ог				
ROSWELL FIELD OFFICE				RIDGEWAY ARIZONA OIL CORP					
Address 2909 W. SECOND ST. ROSWELL NM 88201				Address ONE RIVERWAY SUITE 610 HOUSTON TX 77056					
Telephone 505-627-0229				Attention					
Inspector BUSSELL				Attn Addr					
Site Name	Well or Facility	1/4 1/4 Section		-	Range	Meridian	County	State	
FEDERAL 23	10	SWNE 23	7	S	33E	NMP	ROÓSEVELT	NM	
Site Name	Well or Facility	cll or Facility 1/4 1/4 Section Townsh		ip	Range	Meridian	County	State	
THE FOLLOWING VIOLATION	WAS FOUND BY BU	REAU OF LAN	D MANA	GEME	NT INSPECTOR	RS ON THE DAT	FE AND AT THE SITE LISTEI	DABOVE	
Date Time (24 - hour clock)			Violation			Gravity of Viol	Gravity of Violation		
07/12/2012	0	09:32			43 CFR 316	2.3-4(c)	MINOR	MINOR	
Corrective Action To Be Completed By	Date Corrected		Assessment for Noncompliance			Assessment Reference			
08/21/2012						43 CFR 316	3.1()		
Remarks									

THE ABOVE REFERENCED WELL IS TEMPORARY ABANDONED / SHUT-IN WITHOUT PRIOR APPROVAL. 43 CFR 3162.3-4 (c) REQUIRES THAT WELL(S) INCAPABLE OF PRODUCTION IN PAYING QUANTITIES BE PROMPTLY PLUGGED AND ABANDONED AND REQUIRES APPROVAL FOR ANY WELL TEMPORARILY ABANDONED/ SHUT-IN FOR MORE THAN 30 DAYS. THEREFORE YOU ARE ORDERED TO DO ONE OF THE FOLLOWING: (Remarks continued on following page(s).)

When violation is corrected, sign this notice and return to above address.	\sim /		
Company Representative Title Regulator, Mor.	Signature Alling July	Date	7/23/12
Company Comments Sundry Notice of 1	ntent attached		

WARNING

Incidents of Noncompliance correction and reporting timeframes begin upon receipt of this Notice or 7 business days after the date it is mailed, whichever is earlier. Each violation must be corrected within the prescribed time from receipt of this Notice and reported to the Bureau of Land Management office at the adress shown above. Please note that you already may have been assessed for noncompliance (see amount under "Assessment for Noncompliance"). If you do not comply as noted above under "Corrective Action To Be Completed By" you may incur an additional assessment under (43 CFR 3163.1) and may also incur Civil Penalties (43 CFR 3163.2). All self-certified corrections must be postmarked no later than the next business day after the prescribed time for correction.

Section 109(d)(1) of the Federal Oil and Gas Royalty Management Act of 1982, as implemented by the applicable provisions of the operating regulations at Title 43 CFR 3163.2(f)(1), provides that any person who "knowingly or willfully" prepares, maintains, or submits, false, inaccurate, or misleading reports, notices, affidavits, record, data, or other written information required by this part shall be liable for a civil penalty of up to \$25,000 per violation for each day such violation continues, not to exceed a maximum of 20 days.

REVIEW AND APPEAL RIGHTS

A person contesting a violation shall request a State Director review of the Incidents of Noncompliance. This request must be filed within 20 working days of receipt of the Incidents of Noncompliance with the appropriate State Director (see 43 CFR 3165.3). The State Director review decision may be appealed to the Interior Board of Lands Appeals, 801 North Quincy Street, Suite 300, Arlington VA 22203 (see 43 CFR 3165.4). Contact the above listed Bureau of Land Management office for further information.

Signature of Bureau of Land Manager	nent Authorized Officer		73. Date 7/17	/12 09:35
		FOR OFFICE USE ONLY	and the same as a surger of the same distance of the same set	
Number	Date	Assessment	Penalty	Termination
53				
Type of Inspection				
P!				

BLM Remarks, continued

1. IF YOU DECIDE TO RETURN THE WELL TO PRODUCTION, SUBMIT A SUNDRY NOTICE (FORM 3160-5, ORIGINAL AND 5 COPIES) OF INTENT WITHIN 30 DAYS OF RECEIPT OF THIS LETTER. INCLUDE THE DATE YOU ANTICIPATED THE WELL BEING PLACED BACK IN SERVICE. 43 CFR 3162.4-1(c) ALSO REQUIRES YOU TO NOTIFY THE AUTHORIZED OFFICER, NOT LATER THAN THE FIFTH BUSINESS DAY AFTER PRODUCTION IS RESUMED FOR ANY WELL WHICH HAS BEEN OFF PRODUCTION FOR MORE THAN 90 DAYS, THE DATE ON WHICH SUCH PRODUCTION WAS RESUMED. NOTIFICATION MAY BE BY LETTER OR SUNDRY NOTICE, OR ORALLY FOLLOWED BY LETTER OR SUNDRY NOTICE.

2. IF THE WELL IS TO BE USED FOR BENEFICIAL PURPOSES, SUBMIT A SUNDRY NOTICE (FORM 3160-5, ORIGINAL AND 5 COPIES) WITHIN 30 DAYS OF RECEIPT OF THIS LETTER AND INCLUDE INFORMATION CONCERNING FUTURE USE. A BRIEF DESCRIPTION OF YOUR PROPOSED PLANS AND ECONOMIC FEASIBILITY AND AN ANTICIPATED DATE FOR PLACING THE WELL IN BENEFICIAL USE WILL SUFFICE.

3. IF YOU DECIDE TO PLUG AND ABANDON THE WELL, SUBMIT A SUNDRY NOTICE FORM 3160-5, ORIGINAL AND 5 COPIES) WITHIN 30 DAYS OF RECEIPT OF THIS LETTER AND DESCRIBE THE PROPOSED PLUGGING PROGRAM. FOR MONITORING AND TRACKING PURPOSES; SUBMIT APPROPRIATE PAPERWORK TO THIS OFFICE ATTENTION: ROBERT E. HOSKINSON Sr. IF YOU HAVE ANY QUESTIONS, CONTACT: Kevin Bussell Petroleum Engineering Technician 2909 West Second Street Roswell, NM 88201 Office: (575) 361-0106 E-Mail: kbussell@bim.gov