

Submit 3 Copies To Appropriate District Office
District I
1625 N. French Dr., Hobbs, NM 88240
District II
1301 W. Grand Ave., Artesia, NM 88210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
May 27, 2004

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO. 30-025-28526
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name Mescalero Ridge
8. Well Number 8
9. OGRID Number
10. Pool name or Wildcat Scharb Bone Spring

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well ☒ Gas Well ☐ Other

2. Name of Operator
The Wiser Oil Company

3. Address of Operator
707 17th Street, Suite 3600, Denver, Co 80202

4. Well Location
Unit Letter M : 660 feet from the South line and 660 feet from the West line
Section 17 Township 19S Range 35E

11. Elevation (Show whether DR, RKB, RT, GR, etc.)
3864.8' GR

Pit or Below-grade Tank Application ☐ or Closure ☐

Pit type Depth to Groundwater Distance from nearest fresh water well Distance from nearest surface water

Pit Liner Thickness: mil Below-Grade Tank: Volume bbls; Construction Material

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ P AND A ☐
CASING/CEMENT JOB ☐

OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

Wiser requests approval to plug and abandon the well by the procedure listed below.

Surface Casing: 13-3/8" set @ 400' w/cmt circ. Int. Casing: 8 5/8" set @ 4100' cmt. Circ. Prod casing: 5 1/2" set @ 10,200' cmt circ. Perfs: 5103-5370', 8416-8438', 9366'-9400', 10,024'-9842'. CIBP's @ 8350', 9300', 9800'.

1. Set CIBP @ 5050'. Spot 50' cement plug on CIBP
2. Spot 25 sks cement on CIBP
3. Circulate abandonment mud.
4. Spot 100' cement plug @ 4110'. Tag plug. — 4150'-4050'
5. Spot 100' cement plug @ 3150'-3050'. Tag plug.
6. Spot 100' plug 1900-1800'. Tag plug.
7. Spot 100' cement plug @ 443-343' 13 3/8" casing shoe. Tag plug.
8. Spot 60' cement plug @ surface.
9. Install dry hole marker.
10. Clean location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or below-grade tank has been/will be constructed or closed according to NMOCD guidelines ☐, a general permit ☐ or an (attached) alternative OCD-approved plan ☐.

SIGNATURE Cindy Bush TITLE Sr. Regulatory Tech. DATE 7-28-05
Type or print name Cindy Bush E-mail address: cabush@forestoil.com Telephone No. 303-812-1554

For State Use Only

APPROVED BY: Harry W. Wink FIELD REPRESENTATIVE II/STAFF MANAGER
Conditions of Approval (if any): ADG 10 2 2005