Submit 3 Copies To Appropriate District	State of New N			Form C-103
Office District I	Energy, Minerals and Nat	tural Resources		May 27, 2004
1625 N. French Dr., Hobbs, NM 87240			WELL API NO.	
District II 1301 W. Grand Ave., Artesia, NM 88210	OIL CONSERVATION	ON DIVISION	30-025-051	
District III	1220 South St. F	Francis Dr.	5. Indicate Type of Lea	
1000 Rio Brazos Rd., Aztec, NM 87410 District IV	Santa Fe, NM	87505	STATE	FEE X
1220 S. St. Francis Dr., Santa Fe, NM 87505			6. State Oil & Gas Lea	se No.
SUNDRY NOTICE	S AND REPORTS ON W	FILS	7. Lease Name or Unit	Agreement Name:
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH			Denton North Wolfe	
PROPOSALS.)	ATION FOR PERMIT" (FORM C-	101) FOR SUCH	Agree #8910087370	
1. Type of Well:			8. Well Number	
Oil Well X Gas Well Other			Tract 5, Wel	1 #7
2. Name of Operator		· · · · · · · · · · · · · · · · · · ·	9. OGRID Number	*
Stephens & Johnson Operatir	ig Co.		019958	
3. Address of Operator			10. Pool name or Wildcat	
P.O. Box 2249, Wichita Falls, TX 76307-2249			Denton Wolfcamp	
4. Well Location				
Unit Letter N:	get from the S	outh line and	2310 feet from the	e West line
Section 35	Townshin 14S	Range 37E	NMPM C	ounty Lea
	11. Elevation (Show whether			ounty Lea
		3817 KB	/	
Pit or Below-grade Tank Application	or Closure			
Pit type Depth to Groundwater _	Distance from nearest fr	esh water well Dis	tance from nearest surface w	ater
Pit Liner Thickness: mil				
10 (1 1 1				
	ppropriate Box to Indica	te Nature of Notice,	Report, or Other Da	ta .
NOTICE OF INTE		SUB	SEQUENT REPOR	RT OF:
PERFORM REMEDIAL WORK	PLUG AND ABANDON X	REMEDIAL WORK	☐ AI	LTERING CASING
TEMPORARILY ABANDON	CHANGE PLANS	COMMENCE DRILLI		LUG AND
PULL OR ALTER CASING	MULTIPLE \square	CASING TEST AND	A	BANDONMENT
TOLE ON ALTEN CASING	COMPLETION	CEMENT JOB		
OTHER:		OTUED.		
17		OTHER:		
13. Describe proposed or completed	operations. (Clearly state all p	pertinent details, and give	e pertinent dates, includin	g estimated date
of starting any proposed work).	SEE RULE 1103. For Multip	ole Completions: Attach	wellbore diagram of pro	posed completion
or recompletion.	ANAENIATION DIVI	CION MIICT		
THE OIL C	ONSERVATION DIVIS	PIOIA INDO i		
				St. Jak
DE NOTIF	TED 24 HOURS PRIO	R TO THE	·	Sept 1
BEGINNIN	7IED 24 HOURS PRIC G OF PLUGGING OP	R TO THE	7	Section 1
BEGINNIN	G OF PLUGGING OP	R TO THE ERATIONS.	his 7	200
BEGINNIN	FIED 24 HOURS PRIOG OF PLUGGING OP See Atta	R TO THE ERATIONS.	yic mere	ved 2
BEGINNIN	G OF PLUGGING OP	R TO THE ERATIONS.		ved 2
BEGINNIN	G OF PLUGGING OP	R TO THE ERATIONS.	- N - N - N - N - N - N - N - N - N - N	ived 2
BEGINNIN	G OF PLUGGING OP See Atta	OR TO THE ERATIONS.	\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	wed &
I hereby certify that the information abo	See Atta	PR TO THE ERATIONS. achment	and belief. I further certif	y that any pit or below-
I hereby certify that the information aboursed tank has been/will be constructed at clo	See Atta	PR TO THE ERATIONS. achment e best of my knowledge nes , a general permit [or an (attached) alternativ	ve OCD-approved plan
I hereby certify that the information abo	See Atta	PR TO THE ERATIONS. achment e best of my knowledge nes, a general permit [TLE	or an (attached) alternative DAT	V.that any pit or below- re OCD-approved plan 8-15-05
I hereby certify that the information aboursed tank has been/will be constructed at clo	See Atta	PR TO THE ERATIONS. achment e best of my knowledge nes , a general permit [or an (attached) alternatives Engineer DAT pcarnes@sjoc.net	re OCD-approved plan
I hereby certify that the information abordance tank has been/will be constructed at close SIGNATURE. Type or print name Peyton S. Carne	See Atta	e best of my knowledge nes , a general permit [TLE Petroleum-mail address:	or an (attached) alternatives Engineer DAT pcarnes@sjoc.net	ve OCD-approved plan
I hereby certify that the information about grade tank has been/will be constructed at close SIGNATURE. Type or print name Peyton S. Carne For State Use Only	See Atta Ove is true and complete to the seed according to NMOCD guideling Ess. Jr. ORIGINAL GARY W	PR TO THE ERATIONS. achment e best of my knowledge nes, a general permit [TLEPetroleum -mail address: AL SIGNED BY 7. WINK	or an (attached) alternative in Engineer DAT pcarnes@sjoc.net Telephone	e OCD-approved plan
I hereby certify that the information about grade tank has been/will be constructed at close SIGNATURE. Type or print name Peyton S. Carne For State Use Only APPROVED BY	See Atta Ove is true and complete to the seed according to NMOCD guideling Ess. Jr. ORIGINAL GARY W	PR TO THE ERATIONS. achment e best of my knowledge nes, a general permit [TLEPetroleum -mail address: AL SIGNED BY	or an (attached) alternative in Engineer DAT pcarnes@sjoc.net Telephone	re OCD-approved plan
I hereby certify that the information about grade tank has been/will be constructed at close SIGNATURE. Type or print name Peyton S. Carne For State Use Only	See Atta Ove is true and complete to the seed according to NMOCD guideling Ess. Jr. ORIGINAL GARY W	PR TO THE ERATIONS. achment e best of my knowledge nes, a general permit [TLEPetroleum -mail address: AL SIGNED BY 7. WINK	or an (attached) alternative in Engineer DAT pcarnes@sjoc.net Telephone	e OCD-approved plan

PLUG & ABANDONMENT PROCEDURE

Well Data:

Total Depth: 9212'

Elevation: 3805' GR, 3817' KB

Casing Record: 13 3/8" 48# @ 336 w/400 sks. Circ.

8 5/8" 32# @ 4742' w/2,500 sks. Circ.

5 1/2" 20# liner from 4376' to 9161' w/600 sks. TOC @ 5500' Est.

- 1. Run 7 3/4" bit, scraper and 8-3" (+/-) collars on 2 7/8" tubing to top of liner @ 4376'. Circulate clean. Pull bit, scraper and tubing.
- 2. Run 4 3/4" bit, scraper and 8-3" (+/-) collars on 2 7/8" tubing to 9150'. Circulate clean. Pull bit, scraper and tubing.
- 3. Set 5 1/2" CIBP @ 9100' with 35' cement on plug.
- 4. Run tubing to 9065', tag plug and load hole with 9.5# mud laden salt water.
- 5. Spot 25 sack plug @ 6300' in 5 1/2" casing.
- 6. Spot 75 sack plug inside of 5 1/2" liner 50' below base of 8 5/8" (4742') from 4792' to 4276' inside of 8 5/8" casing. Tag plug.
- 7. Spot 30 sack plug at 3150' in 8 5/8" casing.
- 8. Spot 30 sack plug at 2200' in 8 5/8" casing.
- 9. Spot 120 sack plug 50' below surface casing to surface in 8 5/8" casing.
- 10. Cut off casing 3' below ground and install permanent marker.

PERFY SQZ.



