Submit 1 Copy To Appropriate District HOBBS OCD Office	Form C-103
District 1 – (575) 393-6161 1625 N. French Dr., Hobbs, NM 88240 APR 2 9 2013	Revised August 1, 2011 WELL API NO.
District II – (575) 748-1283 811 S. First St., Artesia, NM 88210 OIL CONSERVATION DIVISION	30-005-00820
	5. Indicate Type of Lease STATE X FEE
$\frac{District III}{1000 \text{ Rio Brazos Rd., Aztec, NM 8741}}$ $\frac{1220 \text{ South St. Francis Dr.}}{\text{Santa Fe, NM 87505}}$	6. State Oil & Gas Lease No.
1220 S. St. Francis Dr., Santa Fe, NM	
87505 SUNDRY NOTICES AND REPORTS ON WELLS	7. Lease Name or Unit Agreement Name
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR, USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH	Rock Queen Unit
PROPOSALS.) 1. Type of Well: Oil Well Gas Well Qther Injection	8. Well Number 19
2. Name of Operator Celero Energy II, LP	9, OGRID Number 247128
3. Address of Operator 400 W. Illinois, Ste. 1601	10. Pool name or Wildcat
Midland, TX 79701	Caprock; Queen
4. Well Location	
Unit Letter J : 1980 feet from the S line and 198	
Section 23 Township 13S Range 31E	NMPM County Chaves
11. Elevation (Show whether DR, RKB, RT, GR, etc.)	
12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF: PERFORM REMEDIAL WORK DUID AND ABANDON DUID REMEDIAL WORK DUID ALTERING CASING	
PULL OR ALTER CASING	
OTHER: Sidetrack	
13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date	
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of	
proposed completion or recompletion.	
1. Set CICR @ 2870' & sqz w/ 100 sx Class C w/2% CaCl2.	
2. Set whipstock on CICR w/out orienting Mill window in csg. 3. RIH w/ 4 7/8" bit, 1.8 degree mtr & DC's. Slide drill 100-125'. POOH, RBIH 4 7/8" bit, straight mtr & 10-12 DC's. Continue drlg	
new hole to TD (a) 3080'.	
4. PU duplex shoe & 10 jts 4", 11#, L-80 UFJ csg & RIH w/ 2 3/8" x 2 7/8" tapered workstring. Cmt w/ min 150 sx Class C w/ 2%.	
5. RIH w/ bit to TOL. RIH w/pkr & pressure test TOL. Sqz cmt TOL if necessary.	
6. Make bit run to shoe. RU WL & run a GR/CCL/CNL. Perf Queen Sand w/ min 15' gun loaded @ 4 SPF. 7. Run pkr & acdz perfs w/ 1500 gals inh 7 1/2% NEFE HCL using ball sealers for diversion.	
8. RIH w/ inj pkr & IPC tbg to w/ in 50' of perfs. Circ w/ inhibited FW pkr fluid. Set pkr & test.	
9. Schedule MIT & RWTI.	
Could Data	····
Spud Date: Rig Release Date:	
I hereby certify that the information above is true and complete to the best of my knowledge and belief.	
SIGNATURE Lisa Aunt TITLE Regulatory Analyst	DATE 04/16/2013
Type or print name Lisa Hunt E-mail address: lhunt@celeroen	ergy.com PHONE: (432)686-1883
For State Use Only	
APPROVED BY THE DE ME	DATE -30-201
Conditions of Approval (if any):	DATE /- JU COL

APR 30 2013