Submit 1 Copy To Appropriate District Office District I State of New Mexico Energy, Minerals and Natural Resources	Form C-103 October 13, 2009
1625 N. French Dr., Hobbs, NM 88240	WELL API NO.
District !! 1301 W. Grand Ave., Artesia, NM 88210 OIL CONSERVATION DIVISION	30-025-10539 5. Indicate Type of Lease
District III 1220 South DBs OCD r. 1000 Rio Brazos Rd., Aztec, NM 87410	STATE STATE
District IV Santa Fe, NM 8/505	6. State Oil & Gas Lease No.
1220 S. St. Francis Dr., Santa Fe, NM 87505 OCT 2 0 2014	307841
SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM TO BE USE TO BE USE) PROPOSALS Y	7. Lease Name or Unit Agreement Name
TROTOSALS.)	SKELLY PENROSE B UNIT 8. Well Number 014
Type of Well: Oil Well ☐ Gas Well ☒ Other TA'd Injection Name of Operator	9. OGRID Number 012444
PROVIDENCE ENERGY SERVICES, INC. dba KELTON OPERATING	
3. Address of Operator P.O. BOX 928, ANDREWS, TEXAS 79714-0928	10. Pool name or Wildcat LANGLIE MATTIX (37240)
4. Well Location	
Unit Letter N : 990 feet from the SOUTH line and 2310 feet from the WEST line	
Section 32 Township 22S Range 37E 11. Elevation (Show whether DR, RKB, RT, GR, etc.,	NMPM LEA County
11. Elevation (Snow whether DR, RAB, RT; UR, etc.)	
12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO: E-PERMITTING	
PERFORM REMEDIAL WORK PLUG AND ABANDON P&A NR P&A R	
TEMPORARILY ABANDON CHANGE PLANS INT TO P&	(
DOWNHOLE COMMINGLE	CHG Loc
TA	RBDMS CHART
OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, and	d give pertinent dates, including estimated date
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.	
1. MIRU plugging equipment 2. Tag CIBP at 3583' 3. Circulate hole with mud laden fluid. 4. Spot 25 sxs cement @ 3583' on top of CIBP. 5. Spot Cement from 2675' to 1260'. WOC and Tag. 6. Perf @ 1160' and Squeeze with 25 sxs. WOC and Tag.	
2. Tag CIBP at 3583'	
3. Circulate hole with mud laden fluid. A Second 25 and compared @ 25832 on top of CIRP.	
4. Spot 25 sxs cement @ 3583' on top of CIBP. 5. Spot Cement from 2675' to 1260'. WOC and Tag.	
6. Perf @ 1160' and Squeeze with 25 sxs. WOC and Tag.	
7. Perf @ 395'. Circulate cement to surface.	
8. Cut off well head and weld on dry hole marker.	
** THIS WELL IN R5003 AREA. CEMENT REQUIRED ACROSS ENTIRE SALT SECTION	
Spud Date: Rig Release Date:	
I hereby certify that the information above is true and complete to the best of my knowledge and belief.	
SIGNATURE	
Type or print name C. Dale Kelton E-mail address: providenceenergy@suddenlink.net PHONE: 432-661-1364	
For State Use Only	
APPROVED BY: Mach Whiteh TITLE Compliance Officer DATE 10/20/2014	
Conditions of Approval (if any):	

