Submit 3 Copies To Appropriate District State of New Mexico	Form C-103
Office Energy, Minerals and Natural Resources	May 27, 2004
1625 N. French Dr., Hobbs, NM 87240	WELL API NO. 30-025-31380
District II 1301 W. Grand Ave., Artesia, NM 88210 OIL CONSERVATION DIVISION	5. Indicate Type of Lease
District III 1220 South St. Francis Dr.	
1000 Rio Brazos Rd., Aztec, NM 87410 Santa Fe, NM 87505 District IV	STATE X FEE
1220 S. St. Francis Dr., Santa Fe, NM 87505	6. State Oil & Gas Lease No.
SUNDRY NOTICES AND REPORTS ON WELLS	7. Lease Name or Unit Agreement Name:
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH	A
PROPOSALS.)	Percha 15 State
1. Type of Well:	8. Well Number
Oil Well Gas Well Other	2Y
2. Name of Operator	9. OGRID Number
EOG Resources Inc.	7377
3. Address of Operator	10. Pool name or Wildcat
P.O. Box 2267 Midland, Texas 79702 4. Well Location	Corbin; Bone Spring, South
4. Well Location	
Unit Letter N: 660 feet from the South line and	1830 feet from the West line
Section 15 Township 18S Range 33E	
11. Elevation (Show whether DR, RKB, RT, G	R, etc.)
3875' GR	
Pit or Below-grade Tank Application or Closure	
Pit type Depth to Groundwater Distance from nearest fresh water well	_ Distance from nearest surface water
Pit Liner Thickness: mil Below-Grade Tank: Volumebbls: Consti	ruction Material
The Thickness below-Grade Tank. Volume bols, Consu	
The Ziner Timerices	
	in Provide Oil Provide District Control of the Cont
12. Check Appropriate Box to Indicate Nature of Not	•
12. Check Appropriate Box to Indicate Nature of Not NOTICE OF INTENTION TO: S	UBSEQUENT REPORT OF:
12. Check Appropriate Box to Indicate Nature of Not NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WOR	UBSEQUENT REPORT OF: RK ALTERING CASING
12. Check Appropriate Box to Indicate Nature of Not NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WOR	UBSEQUENT REPORT OF: RK
12. Check Appropriate Box to Indicate Nature of Not NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORT COMMENCE DE	UBSEQUENT REPORT OF: RK
12. Check Appropriate Box to Indicate Nature of Not NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORTEMPORARILY ABANDON CHANGE PLANS COMMENCE DE PULLOR ALTER CASING DE LA MUNICIPAL DE LA CASING TEST A	UBSEQUENT REPORT OF: RK ALTERING CASING ALTERING OPNS. PLUG AND ABANDONMENT
12. Check Appropriate Box to Indicate Nature of Not NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORTEMPORARILY ABANDON CHANGE PLANS COMMENCE DE PULLOR ALTER CASING DE LA MUNICIPAL DE LA CASING TEST A	UBSEQUENT REPORT OF: RK ALTERING CASING ALTERING CASING ABANDONMENT AND ABANDONMENT
12. Check Appropriate Box to Indicate Nature of Not NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORD TEMPORARILY ABANDON CHANGE PLANS COMMENCE DE CASING TEST A CEMENT JOB BE NOTIFIED 24 HOURS PRIOR TO THE OTHER CINNING OF PLUGGING OPERATIONS OTHER CINNING OF PLUGGING OPERATIONS OTHER CONSTRUCTIONS	UBSEQUENT REPORT OF: RILLING OPNS. PLUG AND ABANDONMENT AND ABANDONMENT
12. Check Appropriate Box to Indicate Nature of Not NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DE PULL OBANTER CONSERVATION PLUGING OF CASING TEST A CEMENT JOB BE NOTIFIED 24 HOURS PRIOR TO THE OTHER CONSERVATION OF PLUGGING OPERATIONS OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, and	UBSEQUENT REPORT OF: RK ALTERING CASING ALLING OPNS. PLUG AND ABANDONMENT AND
12. Check Appropriate Box to Indicate Nature of Not NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DE CASING TEST A CEMENT JOB PULL THE OIL CONSERVATION DIVISION MUST CEMENT JOB BE NOTIFIED 24 HOURS PRIOR TO THE OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, and of starting any proposed work). SEE RULE 1103. For Multiple Completions: At	UBSEQUENT REPORT OF: RK ALTERING CASING ALLING OPNS. PLUG AND ABANDONMENT AND
12. Check Appropriate Box to Indicate Nature of Not NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DE PULL OBANTER CONSERVATION PLUGING OF CASING TEST A CEMENT JOB BE NOTIFIED 24 HOURS PRIOR TO THE OTHER CONSERVATION OF PLUGGING OPERATIONS OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, and	UBSEQUENT REPORT OF: RILLING OPNS. PLUG AND ABANDONMENT AND Sive pertinent dates, including estimated date stach wellbore diagram of proposed completion
12. Check Appropriate Box to Indicate Nature of Not NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DE CASING TEST A CEMENT JOB BE NOTIFIED 24 HOURS PRIOR TO THE OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, and of starting any proposed work). SEE RULE 1103. For Multiple Completions: At or recompletion.	UBSEQUENT REPORT OF: RK ALTERING CASING ALTERING CASING ABANDONMENT ABANDONMENT ABOUT
12. Check Appropriate Box to Indicate Nature of Not NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DE PULL OR AUTER CONSERVATION DIVISION MUST CEMENT JOB BE NOTIFIED 24 HOURS PRIOR TO THE OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, and of starting any proposed work). SEE RULE 1103. For Multiple Completions: At or recompletion. Proposed P&A Procedure:	UBSEQUENT REPORT OF: RK ALTERING CASING ABANDONMENT ABANDONMENT AND give pertinent dates, including estimated date tach wellbore diagram of proposed completion SNOILVHE OD ONIO ONIO ONIO ONIO ONIO ONIO ONIO O
12. Check Appropriate Box to Indicate Nature of Not NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DE CASING TEST A CEMENT JOB BE NOTIFIED 24 HOURS PRIOR TO THE OTHER CONSERVATION OPERATIONS OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, and of starting any proposed work). SEE RULE 1103. For Multiple Completions: At or recompletion. Proposed P&A Procedure: 1. Tag existing CIBP @ 10870'. Dump bail 35' cement on top	UBSEQUENT REPORT OF: RILLING OPNS. PLUG AND ABANDONMENT AND ABANDONMENT Sive pertinent dates, including estimated date tach wellbore diagram of proposed completion SNOITHEOUNG ONIDENTAL ONING AND ABANDON ABANDO
12. Check Appropriate Box to Indicate Nature of Not NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DE CASING TEST A CEMENT JOB BE NOTIFIED 24 HOURS PRIOR TO THE OTHER CONSERVATION OF PLUGGING OPERATIONS OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, and of starting any proposed work). SEE RULE 1103. For Multiple Completions: An or recompletion. Proposed PEA Procedure: 1. Tag existing CIBP @ 10870'. Dump bail 35' cement on top 2. Set CIBP @ 9862' + 35' cement cap	UBSEQUENT REPORT OF: RILLING OPNS. PLUG AND ABANDON MENT AND PLUG AND BUTCHISTON Give pertinent dates, including estimated date tach wellbore diagram of proposed completion THE CONSERVATION DIVISION (1993)
12. Check Appropriate Box to Indicate Nature of Not NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DE PULL OR ALTER CONSERVATION PLUGION MUST CASING TEST A CEMENT JOB BE NOTIFIED 24 HOURS PRIOR TO THE OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, and of starting any proposed work). SEE RULE 1103. For Multiple Completions: At or recompletion. Proposed PAA Procedure: 1. Tag excisting CIEP @ 10870'. Dump bail 35' cement on top 2. Set CIEP @ 9862' + 35' cement cap 3. Spot 200' (40 sx) plug from 7050'-7250' 8. Spot	UBSEQUENT REPORT OF: RILLING OPNS. PLUG AND ABANDONMENT AND ABANDONMENT Sive pertinent dates, including estimated date tach wellbore diagram of proposed completion SNOITHEOUNG ONIDENTAL ONING AND ABANDON ABANDO
12. Check Appropriate Box to Indicate Nature of Not NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DE PULL CRASTER CASING TEST A CEMENT JOB BE NOTIFIED 24 HOURS PRIOR TO THE OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, and of starting any proposed work). SEE RULE 1103. For Multiple Completions: At or recompletion. Proposed PEA Procedure: 1. Tag existing CIBP @ 10870'. Dump bail 35' cement on top 2. Set CIBP @ 9862' + 35' cement cap 3. Spot 200' (40 sx) plug from 7050'-7250' 8. Spot 4. Spot 200' (40 sx) plug from 7050'-7250' 9. Spot	UBSEQUENT REPORT OF: RILLING OPNS. PLUG AND DIAMOND (38) (38) (30) (32) (30) (32) (30) (32) (30) (32) (32) (32) (32) (32) (32) (32) (32
12. Check Appropriate Box to Indicate Nature of Not NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DE PULL OR ALTER CONSERVATION MUST CEMENT JOB BE NOTIFIED 24 HOURS PRIOR TO THE OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, and of starting any proposed work). SEE RULE 1103. For Multiple Completions: At or recompletion. Proposed PAA Procedure: 1. Tag existing CIBP @ 10870'. Dump bail 35' cement on top 2. Set CIBP @ 9862' + 35' cement cap 3. Spot 200' (40 sx) plug from 7050'-7250' 4. Spot 200' (40 sx) plug from 4998'-5198' 9. Spot 5. Cut and pull 5 1/2" casing @ +/- 3245' 10. Spot 10. Spot 10. Spot 11. Weld	UBSEQUENT REPORT OF: RILLING OPINS. PLUG AND DIA DEPUT OF LOCAL
12. Check Appropriate Box to Indicate Nature of Not NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DE CASING TEST A CEMENT JOB BE NOTIFIED 24 HOURS PRIOR TO THE OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, and of starting any proposed work). SEE RULE 1103. For Multiple Completions: At or recompletion. Proposed PEA Procedure: 1. Tag existing CIBP @ 10870'. Dump bail 35' cement on top 2. Set CIBP @ 9862' + 35' cement cap 3. Spot 200' (40 sx) plug from 7050'-7250' 8. Spot 4. Spot 200' (40 sx) plug from 4998'-5198' 9. Spot 5. Cut and pull 5 1/2" casing @ +/- 3245' 10. Spot	UBSEQUENT REPORT OF: RILLING OPNS. PLUG AND ABANDONMENT AND PLUG AND BANDONMENT ABOUT COMPAND AND AND AND AND AND AND AND AND AND
12. Check Appropriate Box to Indicate Nature of Not NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DE PULL OR ATTENTION OF PLUG INTENTION OF CASING TEST ACEMENT JOB BE NOTIFIED 24 HOURS PRIOR TO THE OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, and of starting any proposed work). SEE RULE 1103. For Multiple Completions: At or recompletion. Proposed PEA Procedure: 1. Tag existing CIBP @ 10870'. Dump bail 35' cement on top 2. Set CIBP @ 9862' + 35' cement cap 3. Spot 200' (40 sx) plug from 7050'-7250' 4. Spot 200' (40 sx) plug from 4998'-5198' 5. Cut and pull 5 1/2" casing @ +/- 3245' 6. Spot 100' (30 sx) plug +/- from 3195'-3295' Tag 11. Weld 7. Spot 100' (30 sx) plug from 2854'-2954' Tag I hereby certify that the information above is true and complete to the best of my knowledge.	UBSEQUENT REPORT OF: RILLING OPNS. PLUG AND ABANDONMENT AND ABANDONMENT give pertinent dates, including estimated date tach wellbore diagram of proposed completion SNOILVE ON BOTH ABOUT A STATE OF THE CONSERVATION DIVISION (30 SX) plug from 1454'-1554' 100' (30 SX) plug from 1454'-1554' 100' (30 SX) plug from 386'-486' Tag 50' (15 SX) surface plug from 50'-0' con P&A marker, clean & restore location edge and belief. I further certify that any pit or belowed.
12. Check Appropriate Box to Indicate Nature of Not NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DE CASING TEST A CEMENT JOB BE NOTIFIED 24 HOURS PRIOR TO THE OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, and of starting any proposed work). SEE RULE 1103. For Multiple Completions: At or recompletion. Proposed P&A Procedure: 1. Tag existing CIBP @ 10870'. Dump bail 35' cement on top 2. Set CIBP @ 9862' + 35' cement cap 3. Spot 200' (40 sx) plug from 7050'-7250' 8. Spot 4. Spot 200' (40 sx) plug from 4998'-5198' 9. Spot 5. Cut and pull 5 1/2" casing @ +/- 3245' 10. Spot 6. Spot 100' (30 sx) plug from 2854'-2954' Tag I hereby certify that the information above is true and complete to the best of my knowle grade tank has been/will of constructed or closed according to NMOCD guidelines , a general per	UBSEQUENT REPORT OF: RILLING OPNS. PLUG AND ABANDONMENT AND ABANDONMENT By the pertinent dates, including estimated date tach wellbore diagram of proposed completion SNOILVED ST HONES BY TO LIFE ON CONSELIATION DIAISON (30 SX) plug from 1454'-1554' 100' (30 sx) plug from 386'-486' Tag 100' (30 sx) plug from 386'-486' Tag 50' (15 sx) surface plug from 50'-0' on P&A marker, clean & restore location edge and belief. I further certify that any pit or belowers or an (attached) alternative OCD-approved I amit or an (attached) alternative OCD-approved I amit or an (attached) alternative OCD-approved III
12. Check Appropriate Box to Indicate Nature of Not NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DE CASING TEST A CEMENT JOB BE NOTIFIED 24 HOURS PRIOR TO THE OTHER CONSERVATION OF PLUGGING OPERATIONS OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, and of starting any proposed work). SEE RULE 1103. For Multiple Completions: At or recompletion. Proposed P&A Procedure: 1. Tag existing CIBP @ 10870'. Dump bail 35' cement on top 2. Set CIBP @ 9862' + 35' cement cap 3. Spot 200' (40 sx) plug from 7050'-7250' 8. Spot 4. Spot 200' (40 sx) plug from 4998'-5198' 9. Spot 5. Cut and pull 5 1/2" casing @ +/- 3245' 10. Spot 6. Spot 100' (30 sx) plug from 2854'-2954' Tag I hereby certify that the information above is true and complete to the best of my knowle grade tank has been/will foonstructed or closed according to NMOCD guidelines , a general per SIGNATURE TITLE Recrul	UBSEQUENT REPORT OF: RILLING OPNS. PLUG AND ABANDONMENT AND ABANDONMENT give pertinent dates, including estimated date tach wellbore diagram of proposed completion SNOILVE ON BOTH ABOUT A STATE OF THE CONSERVATION DIVISION (30 SX) plug from 1454'-1554' 100' (30 SX) plug from 1454'-1554' 100' (30 SX) plug from 386'-486' Tag 50' (15 SX) surface plug from 50'-0' con P&A marker, clean & restore location edge and belief. I further certify that any pit or belowed.
12. Check Appropriate Box to Indicate Nature of Not NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DE CASING TEST A CEMENT JOB BE NOTIFIED 24 HOURS PRIOR TO THE OTHER: DECINNING OF PLUGGING OPERATIONS OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, and of starting any proposed work). SEE RULE 1103. For Multiple Completions: At or recompletion. Proposed PEA Procedure: 1. Tag existing CIBP @ 10870'. Dump bail 35' cement on top 2. Set CIBP @ 9862' + 35' cement cap 3. Spot 200' (40 sx) plug from 7050'-7250' 8. Spot 4. Spot 200' (40 sx) plug from 4998'-5198' 9. Spot 5. Cut and pull 5 1/2" casing @ +/- 3245' 10. Spot 6. Spot 100' (30 sx) plug +/- from 3195'-3295' Tag 11. Weld 7. Spot 100' (30 sx) plug from 2854'-2954' Tag I hereby certify that the information above is true and complete to the best of my knowle grade tank has been/wills constructed or closed according to NMOCD guidelines , a general per SIGNATURE TITLE Regul E-mail address:	UBSEQUENT REPORT OF: RK
12. Check Appropriate Box to Indicate Nature of Not NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DE CASING TEST A CEMENT JOB BE NOTIFIED 24 HOURS PRIOR TO THE OTHER CONSERVATION OF PLUGGING OPERATIONS OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, and of starting any proposed work). SEE RULE 1103. For Multiple Completions: At or recompletion. Proposed P&A Procedure: 1. Tag existing CIBP @ 10870'. Dump bail 35' cement on top 2. Set CIBP @ 9862' + 35' cement cap 3. Spot 200' (40 sx) plug from 7050'-7250' 8. Spot 4. Spot 200' (40 sx) plug from 4998'-5198' 9. Spot 5. Cut and pull 5 1/2" casing @ +/- 3245' 10. Spot 6. Spot 100' (30 sx) plug +/- from 3195'-3295' Tag 11. Weld 7. Spot 100' (30 sx) plug from 2854'-2954' Tag Thereby certify that the information above is true and complete to the best of my knowlegrade tank has been/will a constructed or closed according to NMOCD guidelines , a general per SIGNATURE TITLE Regul E-mail address:	UBSEQUENT REPORT OF: RILLING OPNS. PLUG AND ABANDONMENT AND ABANDONMENT By the pertinent dates, including estimated date stach wellbore diagram of proposed completion SNOILVED ST HONES BUILDED THOUSE AND ADDITIONS AND ADDI
12. Check Appropriate Box to Indicate Nature of Not NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DE CASING TEST A CEMENT JOB CASING TEST A CEMENT JOB CHANGE PLUGGING OPERATIONS OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, and of starting any proposed work). SEE RULE 1103. For Multiple Completions: At or recompletion. Proposed P&A Procedure: 1. Tag existing CIBP @ 10870'. Dump bail 35' cement on top 2. Set CIBP @ 9862' + 35' cement cap 3. Spot 200' (40 sx) plug from 7050'-7250' 8. Spot 4. Spot 200' (40 sx) plug from 4998'-5198' 9. Spot 5. Cut and pull 5 1/2" casing @ +/- 3245' 10. Spot 5. Cut and pull 5 1/2" casing @ +/- 3245' 10. Spot 6. Spot 100' (30 sx) plug from 2854'-2954' Tag 11. Weld 7. Spot 100' (30 sx) plug from 2854'-2954' Tag 11. Weld 7. Spot 100' (30 sx) plug from 2854'-2954' Tag 15. Spot 100' (30 sx) plug from 2854'-2954' Tag 15. Spot 100' (30 sx) plug from 2854'-2954' Tag 15. Spot 100' (30 sx) plug from 2854'-2954' Tag 15. Spot 15. Sp	UBSEQUENT REPORT OF: RK
12. Check Appropriate Box to Indicate Nature of Not NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK TEMPORARILY ABANDON CHANGE PLANS COMMENCE DE CASING TEST A CEMENT JOB BE NOTIFIED 24 HOURS PRIOR TO THE OTHER CONSERVATION OF PLUGGING OPERATIONS OTHER: 13. Describe proposed or completed operations. (Clearly state all pertinent details, and of starting any proposed work). SEE RULE 1103. For Multiple Completions: At or recompletion. Proposed P&A Procedure: 1. Tag existing CIBP @ 10870'. Dump bail 35' cement on top 2. Set CIBP @ 9862' + 35' cement cap 3. Spot 200' (40 sx) plug from 7050'-7250' 8. Spot 4. Spot 200' (40 sx) plug from 4998'-5198' 9. Spot 5. Cut and pull 5 1/2" casing @ +/- 3245' 10. Spot 6. Spot 100' (30 sx) plug +/- from 3195'-3295' Tag 11. Weld 7. Spot 100' (30 sx) plug from 2854'-2954' Tag Thereby certify that the information above is true and complete to the best of my knowlegrade tank has been/will a constructed or closed according to NMOCD guidelines , a general per SIGNATURE TITLE Regul E-mail address:	UBSEQUENT REPORT OF: RK

Percha 15 State 24

	155K 0-50'	
	30sx 100' plug 380	
	30sx 100' plug ?	
	85/8 @ 2904	_
	cu+51/2 ± 3	12 45
	TOC @ 3245	100 3195- 329
	30 sk	Tag
	200' plug from	~ 4998 - 5198
		Deloware
	200' plug from	7050 - 7250
	40sx	TOP BS
	CIBP@ 9862 + 3	s' em+
	9912 - 9940	2nd BS
une	RINg tag CIBP@ 1087	
	CIBP@ 10870	
	10918 - 11474	Wolfcamp