Energy, Minerals and Natural Resources	Submit 3 Copies To Appropriate District State of New Mexico	Form C-103
District	Office District I Energy, Minerals and Natural Resources	
DUR LOWNS WAT IN STONE	District II	
1220 South St. Francis Dr. Santa Fe, NM 87010 Santa Fe, NM 87050 SunDry Notices And Reports of Departs of Part South St. Francis Dr. Santa Fe, NM 87050 SunDry Notices And Reports of Departs of Part South St. Part St. Pa	1301 W. Grand Ave., Artesia, NM 88210 OIL CONSERVATION DIVISION	
Samue Fr. No. 8 / 505	1000 P. D. D. L. A. L. NB (07410	
SUNDRY NOTICES AND REPORTS ON WELLS COO NOT USE THIS FORM FOR PROPOSALS TO DAILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM-CID) FOR SUCH RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM-CID) FOR SUCH 1. Type of Well: Oil Well Gas Well Other 9. OGRID Number 1. Type of Well: Oil Well Gas Well Other 9. OGRID Number 1. Type of Well: Oil Well Oil Well Gas Well Other 9. OGRID Number 1. Type of Well: Oil Well Oil Well	District IV Santa Fe, INIVI 8/303	1 1
SINDRY NOTICES AND REPORTS ON WELLS The proposal of the pr		LG-814
DIPPERENT RESERVOR, USE "APPLICATION FOR PIRMIT" (FORM C-10) FOR SUCH Woodpecker SY State	SUNDRY NOTICES AND REPORTS ON WELLS	7. Lease Name or Unit Agreement Name
ROPOGALS) Type of Well: Oil Well		W. 1 1 0V.C.
1. 1ype of Well: Oil Well 2	PROPOSALS.)	
Yates Petroleum Corporation 025575	1. Type of Well: Oil Well Gas Well Other	8. Well Number
Vales Petroleum Corporation 025575	2. Name of Operator	9. OGRID Number
10.5 S. 4 Street, Artesia, NM 88210 Saunders Permo Upper Penn	Yates Petroleum Corporation	
Well Location Unit Letter A : 660 feet from the North line and 660 feet from the East line Section 21 Township 14S Range 33E NMPM Lea County		1
Unit Letter A : 660 feet from the North line and 660 feet from the East line Section 21 Township 148 Range 33E NMPM Lea County 11. Elevation (Show whether DR, RKB, RT, GR, etc.)		Saunders Fermo Opper Ferm
Section 21 Township 14S Range 33E NMPM Lea County Tit or Rebow-trade Tank Application or Closure A211.2 'GR Fit or Rebow-trade Tank Application or Closure A211.2 'GR Pit type_Steel Depth to Groundwater N/A Distance from nearest fresh water well N/A Distance from nearest surface water N/A		660 feet from the Fast line
Pit or Below_grade Tank Application Or Closure Pit type Steel Depth to Groundwater N/A Distance from nearest fresh water well N/A Distance from nearest surface water N/A Dista		
High Below-grade Tank Application Or Closure Pit type Steel Depth to Groundwater NA Distance from nearest fresh water well N/A Distance from nearest surface water N/A Distance		
Pit type Sitet Depth to Groundwater N/A Distance from nearest fresh water well N/A Distance from nearest surface water N/A Pit Liner Thickness: N/A mit Relow-Grade Tank: Volume N/A Distance from nearest surface water N/A		
12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF: ALTERING CASING PLUG AND ABANDON REMEDIAL WORK PLUG AND ABANDON P. & ALTERING CASING PULL OR ALTER CASING PULL OR ALTER CASING PULL OR ALTER CASING PULL OR ALTER CASING PLUG AND ABANDON BE NOTIFIED 24 HOURS FRICK TO THE P. & ALTERING CASING P. & ALTERING CAS		Province incomment of the last of the state
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF: PERFORM REMEDIAL WORK PLUG AND ABANDON PLUG AND ABANDON ALTERING CASING P&A	Pit type <u>Steel</u> Depth to Groundwater <u>N/A</u> Distance from nearest fresh water well <u>N/A</u>	Distance from nearest surface water N/A
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK PLUG AND ABANDON CHANGIE OF CONSERVATION DUBLISHED ALTERING CASING P& A P &	Pit Liner Thickness: N/A mil Below-Grade Tank: Volume N/A bbls;	Construction Material N/A
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK PLUG AND ABANDON CHANGIE OF CONSERVATION DUBLISHED ALTERING CASING P& A P &	12. Check Appropriate Box to Indicate Nature of Notice,	Report or Other Data
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK ALTERING CASING PULL OR ALTER CASING PULL OR ALTER CASING DIVIDING CONSERVATION DIVISION MUSTS P& A DIVIDING ALTER CASING P& A DIVIDING ALTER CASING DIVIDING ALTER CASING ALTER CASIN	** *	
TEMPORARILY ABANDON CHANGLE ON CONSERVATION DIVISION MUST P&A DTHER: BEGINNING OFPLUGGING OPERATIONS. 13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion. Yates Petroleum Corporation proposes to Plug and Abandon well as follows: 1) Set 5-1/2" CIBP @ 9774' and dump 35' cement on plug. 2) RIH w/tubing, circulate plugging mud and spot 100' plug (25 sx) in casing 7702-7602'. 3) RIH w/wireline and shoot squeeze holes @ 616'. 4) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 4250-4100'. Tag plug. 7) RIH w/wireline and shoot squeeze holes @ 3494'. 8) RIH w/wireline and shoot squeeze holes @ 3494'. 8) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 3494-3394'. TAG 9) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 2724-2624'. TAG 11) RIH w/wireline and shoot squeeze holes @ 495'. 12) RIH w/wireline and shoot squeeze holes @ 60'. 13) RIH w/wireline and shoot squeeze holes @ 60'. 14) Circulare 15 sx cement in and out of casing from surface to 60'. 15) Cut off wellhead. Install marker. Clean location. (Proposed Schematic Attached) Thereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or belowgrade tank has been/will be constructed of loosed according to NMOCD guidelines a general permit or an (attached) alternative OCD-approved plan SIGNATURE TITLE Regulatory Compliance Technician DATE 2-13-06 Type or print name Stormi Davis E-mail address: stormid@ypcnm.com Telephone No. 505-748-1471 For State Use Only TITLE Regulatory Compliance Technician DATE 2-13-06 Total Regulatory Compliance Technician DATE 2-13-06 TITLE TITLE TITLE TITLE TITLE TITLE TITLE TITLE TITLE TITLE		,
OTHER: BEGINNING OF PLUGGING OPERATIONS. 13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion. Yates Petroleum Corporation proposes to Plug and Abandon well as follows: 1) Set 5-1/2" CIBP @ 9774' and dump 35' cement on plug. 2) RIH withing, circulate plugging mud and spot 100' plug (25 sx) in casing 7702-7602'. 3) RIH withing and packer and set 100' plug (30 sx) in and out of casing 5616-5516'. 5) RIH withing and packer and set 150' plug (30 sx) in and out of casing 4250-4100'. Tag plug. 7) RIH withing and packer and set 150' plug (30 sx) in and out of casing 3494-3394'. — TAG 9) RIH withing and packer and set 100' plug (30 sx) in and out of casing 2724-2624'. TAG 11) RIH withing and packer and set 100' plug (30 sx) in and out of casing 495-395'. TAG 12) RIH withing and packer and set 100' plug (30 sx) in and out of casing 495-395'. TAG 13) RIH withing and packer and set 100' plug (30 sx) in and out of casing 495-395'. TAG 14) Circulare 15 sx cement in and out of casing from surface to 60'. 15) Cut off wellhead. Install marker. Clean location. (Proposed Schematic Attached) Thereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or belowgrade tank has been/will be constructed of closed according to NMOCD guidelines \(\), a general permit \(\) or an (attached) alternative OCD-approved plan \(\). SIGNATURE TITLE Regulatory Compliance Technician DATE 2-13-06 Type or print name Stormi Davis E-mail address: stormid@ypcnm.com Telephone No. 505-748-1471 For State Use Only APPROVED BY:	_	_
13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion. Yates Petroleum Corporation proposes to Plug and Abandon well as follows: 1) Set 5-1/2" CIBP @ 9774' and dump 35' cement on plug. 2) RIH w/tubing, circulate plugging mud and spot 100' plug (25 sx) in casing 7702-7602'. 3) RIH w/wireline and shoot squeeze holes @ 5616'. 4) RIH w/fubing and packer and spot 100' plug (30 sx) in and out of casing 5616-5516'. 5) RIH w/wireline and shoot squeeze holes @ 4250'. 6) RIH w/fubing and packer and set 150' plug (30 sx) in and out of casing 4250-4100'. Tag plug. 7) RIH w/wireline and shoot squeeze holes @ 3724'. 10) RIH w/wireline and shoot squeeze holes @ 495'. 12) RIH w/wireline and shoot squeeze holes @ 60'. 13) RIH w/wireline and shoot squeeze holes @ 60'. 14) Circulate 15 sx cement in and out of casing from surface to 60'. 15) Cut off wellhead. Install marker. Clean location. Proposed Schematic Attached) Thereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or belowgrade tank has been/will be constructed of closed according to NMOCD guidelines, a general permit or an (attached) alternative OCD-approved plan SIGNATURE	PULL OR ALTER CASING MULTIPLE COMPL	
13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion. Yates Petroleum Corporation proposes to Plug and Abandon well as follows: 1) Set 5-1/2" CIBP @ 9774' and dump 35' cement on plug. 2) RIH w/tubing, circulate plugging mud and spot 100' plug (25 sx) in casing 7702-7602'. 3) RIH w/tubing and packer and spot 100' plug (30 sx) in and out of casing 5616-5516'. 4) RIH w/tubing and packer and set 150' plug (50 sx) in and out of casing 4250-4100'. Tag plug. 7) RIH w/tubing and packer and set 150' plug (30 sx) in and out of casing 3494-3394'. → 7A6 9) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 2724-2624'. → 7A6 11) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 2724-2624'. → 7A6 13) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 495-395'. → 7A6 13) RIH w/wireline and shoot squeeze holes @ 60'. 15) Cut off wellhead. Install marker. Clean location. (Proposed Schematic Attached) Thereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or belowered tank has been/will be constructed of closed according to NMOCD guidelines □, a general permit □ or an (attached) alternative OCD-approved plan □. SIGNATURE TITLE Regulatory Compliance Technician DATE 2-13-06 Type or print name Stormi Davis E-mail address: stormid@ypcnm.com Telephone No. 505-748-1471 For State Use Only APPROVED BY: TITLE Regulatory Compliance Technician DATE 2-13-06	BE NOTIFIED 24 HOURS PRIOR	IUINE —
of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion. Yates Petroleum Corporation proposes to Plug and Abandon well as follows: 1) Set 5-1/2" CIBP @ 9774' and dump 35' cement on plug. 2) RIH w/tubing, circulate plugging mud and spot 100' plug (25 sx) in casing 7702-7602'. 3) RIH w/wireline and shoot squeeze holes @ 5616'. 4) RIH w/tubing and packer and spot 100' plug (30 sx) in and out of casing 5616-5516'. 5) RIH w/wireline and shoot squeeze holes @ 4250'. 6) RIH w/tubing and packer and set 150' plug (30 sx) in and out of casing 4250-4100'. Tag plug. 7) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 3494-3394'. TAG 9) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 2724-2624'. TAG 11) RIH w/wireline and shoot squeeze holes @ 495'. 12) RIH w/wireline and shoot squeeze holes @ 60'. 13) RIH w/wireline and shoot squeeze holes @ 60'. 14) Circulate 15 sx cement in and out of casing from surface to 60'. 15) Cut off wellhead. Install marker. Clean location. (Proposed Schematic Attached) Thereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or belowgrade tank has been/will be constructed of closed according to NMOCD guidelines , a general permit or an (attached) alternative OCD-approved plan . SIGNATURE TITLE Regulatory Compliance Technician DATE 2-13-06 Tope or print name Stormi Davis E-mail address: stormid@ypcnm.com Telephone No. 505-748-1471	OTHER: BEGINNING OF PLUGGING OPE	RATIONS.
Yates Petroleum Corporation proposes to Plug and Abandon well as follows: 1) Set 5-1/2" CIBP @ 9774' and dump 35' cement on plug. 2) RIH w/tubing, circulate plugging mud and spot 100' plug (25 sx) in casing 7702-7602'. 3) RIH w/tubing and packer and spot 100' plug (30 sx) in and out of casing 5616-5516'. 4) RIH w/tubing and packer and spot 100' plug (30 sx) in and out of casing 5616-5516'. 5) RIH w/wireline and shoot squeeze holes @ 4250'. 6) RIH w/tubing and packer and set 150' plug (50 sx) in and out of casing 4250-4100'. Tag plug. 7) RIH w/wireline and shoot squeeze holes @ 3724'. 8) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 3494-3394'. TAG 9) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 2724-2624'. TAG 11) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 495-395'. TAG 12) RIH w/wireline and shoot squeeze holes @ 495'. 13) RIH w/wireline and shoot squeeze holes @ 60'. 14) Circulate 15 sx cement in and out of casing from surface to 60'. 15) Cut off wellhead. Install marker. Clean location. (Proposed Schematic Attached) Thereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or belowgrade tank has been/will be constructed of closed according to NMOCD guidelines, a general permit or an (attached) alternative OCD-approved plan SIGNATURE	13. Describe proposed or completed operations. (Clearly state all pertinent details, at	ttach wellhore diagram of proposed completion
Yates Petroleum Corporation proposes to Plug and Abandon well as follows: 1) Set 5-1/2" CIBP @ 9774' and dump 35' cement on plug. 2) RIH w/tubing, circulate plugging mud and spot 100' plug (25 sx) in casing 7702-7602'. 3) RIH w/tubing and packer and spot 100' plug (30 sx) in and out of casing 5616-5516'. 5) RIH w/tubing and packer and set 150' plug (30 sx) in and out of casing 4250-4100'. Tag plug. 7) RIH w/tubing and packer and set 150' plug (30 sx) in and out of casing 3494-3394'. 8) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 3494-3394'. 7) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 2724-2624'. 10) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 495-395'. 12) RIH w/wireline and shoot squeeze holes @ 495'. 13) RIH w/wireline and shoot squeeze holes @ 60'. 14) Circulate 15 sx cement in and out of casing from surface to 60'. 15) Cut off wellhead. Install marker. Clean location. (Proposed Schematic Attached) I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or belowgrade tank has been/will be constructed of closed according to NMOCD guidelines \(\), a general permit \(\) or an (attached) alternative OCD-approved plan \(\). SIGNATURE TITLE Regulatory Compliance Technician DATE 2-13-06 Tope or print name Stormi Davis E-mail address: stormid@ypcnm.com Telephone No. 505-748-1471 For State Use Only APPROVED BY:	- · · · · · · · · · · · · · · · · · · ·	
1) Set 5-1/2" CIBP @ 9774' and dump 35' cement on plug. 2) RIH w/tubing, circulate plugging mud and spot 100' plug (25 sx) in casing 7702-7602'. 3) RIH w/wireline and shoot squeeze holes @ 5616'. 4) RIH w/tubing and packer and spot 100' plug (30 sx) in and out of casing 5616-5516'. 5) RIH w/tubing and packer and set 150' plug (50 sx) in and out of casing 4250-4100'. Tag plug. 7) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 3494-3394'. TAG 9) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 2724-2624'. TAG 10) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 2724-2624'. TAG 11) RIH w/wireline and shoot squeeze holes @ 495'. 12) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 495-395'. TAG 13) RIH w/wireline and shoot squeeze holes @ 60'. 14) Circulate 15 sx cement in and out of casing from surface to 60'. 15) Cut off wellhead. Install marker. Clean location. (Proposed Schematic Attached) I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or belowgrade tank has been/will be constructed of closed according to NMOCD guidelines \(\), a general permit \(\) or an (attached) alternative OCD-approved plan \(\). SIGNATURE TITLE Regulatory Compliance Technician DATE 2-13-06 Type or print name Stormi Davis E-mail address: stormid@ypcnm.com Telephone No. 505-748-1471 For State Use Only APPROVED BY: TITLE Regulatory Compliance Technician DATE 2-13-06	· · · · · · · · · · · · · · · · · · ·	
2) RIH w/tubing, circulate plugging mud and spot 100' plug (25 sx) in casing 7702-7602'. 3) RIH w/wireline and shoot squeeze holes @ 5616'. 4) RIH w/tubing and packer and spot 100' plug (30 sx) in and out of casing 5616-5516'. 5) RIH w/tubing and packer and set 150' plug (50 sx) in and out of casing 4250-4100'. Tag plug. 7) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 3494-3394'. TAG 8) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 3494-3394'. TAG 9) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 2724-2624'. TAG 10) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 495-395'. TAG 11) RIH w/wireline and shoot squeeze holes @ 495'. 12) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 495-395'. TAG 13) RIH w/wireline and shoot squeeze holes @ 60'. 14) Circulate 15 sx cement in and out of casing from surface to 60'. 15) Cut off wellhead. Install marker. Clean location. (Proposed Schematic Attached) 1 hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or below-grade tank has been/will be constructed of closed according to NMOCD guidelines \(\bar{\bar{\bar{\bar{\bar{\bar{\bar{		
3) RIH w/wireline and shoot squeeze holes @ 5616'. 4) RIH w/tubing and packer and spot 100' plug (30 sx) in and out of casing 5616-5516'. 5) RIH w/wireline and shoot squeeze holes @ 4250'. 6) RIH w/tubing and packer and set 150' plug (50 sx) in and out of casing 4250-4100'. Tag plug. 7) RIH w/wireline and shoot squeeze holes @ 3494'. 8) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 3494-3394'. TAG 9) RIH w/wireline and shoot squeeze holes @ 2724'. 10) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 2724-2624'. TAG 11) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 495-395'. TAG 12) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 495-395'. TAG 13) RIH w/wireline and shoot squeeze holes @ 60'. 14) Circulate 15 sx cement in and out of casing from surface to 60'. 15) Cut off wellhead. Install marker. Clean location. (Proposed Schematic Attached) I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or below-grade tank has been/will be constructed of closed according to NMOCD guidelines \(\sigma_a \) general permit \(\sigma_{a} \) or an (attached) alternative OCD-approved plan \(\sigma_{a} \). SIGNATURE TITLE Regulatory Compliance Technician DATE 2-13-06 Type or print name Stormi Davis E-mail address: stormid@ypcnm.com Telephone No. 505-748-1471 For State Use Only APPROVED BY:		. (2 1 Miles 22)
5) RIH w/wireline and shoot squeeze holes @ 4250'. 6) RIH w/tubing and packer and set 150' plug (50 sx) in and out of casing 4250-4100'. Tag plug. 7) RIH w/wireline and shoot squeeze holes @ 3494'. 8) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 3494-3394'. TAG 9) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 2724-2624'. TAG 11) RIH w/wireline and shoot squeeze holes @ 495'. 12) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 495-395'. TAG 13) RIH w/wireline and shoot squeeze holes @ 60'. 14) Circulate 15 sx cement in and out of casing from surface to 60'. 15) Cut off wellhead. Install marker. Clean location. (Proposed Schematic Attached) I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or belowgrade tank has been/will be constructed of closed according to NMOCD guidelines , a general permit or an (attached) alternative OCD-approved plan . SIGNATURE TITLE Regulatory Compliance Technician DATE 2-13-06 Type or print name Stormi Davis E-mail address: stormid@ypcnm.com Telephone No. 505-748-1471 For State Use Only APPROVED BY: TITLE	3) RIH w/wireline and shoot squeeze holes @ 5616'.	32
6) RIH w/tubing and packer and set 150' plug (50 sx) in and out of casing 4250-4100'. Tag plug. 7) RIH w/wireline and shoot squeeze holes @ 3494'. 8) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 3494-3394'. TAG 9) RIH w/wireline and shoot squeeze holes @ 2724'. 10) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 2724-2624'. TAG 11) RIH w/wireline and shoot squeeze holes @ 495'. 12) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 495-395'. TAG 13) RIH w/wireline and shoot squeeze holes @ 60'. 14) Circulate 15 sx cement in and out of casing from surface to 60'. 15) Cut off wellhead. Install marker. Clean location. (Proposed Schematic Attached) I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or below-grade tank has been/will be constructed of closed according to NMOCD guidelines , a general permit or an (attached) alternative OCD-approved plan . SIGNATURE TITLE Regulatory Compliance Technician DATE 2-13-06 Type or print name Stormi Davis E-mail address: stormid@ypcnm.com Telephone No. 505-748-1471 For State Use Only APPROVED BY: TITLE REGULATIVE II/STAPE MAN DATE		
7) RIH w/wireline and shoot squeeze holes @ 3494'. 8) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 3494-3394'. — TAG 9) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 2724-2624'. TAG 10) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 2724-2624'. TAG 11) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 495-395'. TAG 12) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 495-395'. TAG 13) RIH w/wireline and shoot squeeze holes @ 60'. 14) Circulate 15 sx cement in and out of casing from surface to 60'. 15) Cut off wellhead. Install marker. Clean location. (Proposed Schematic Attached) I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or below-grade tank has been/will be constructed of closed according to NMOCD guidelines \(\preceq \), a general permit \(\preceq \) or an (attached) alternative OCD-approved plan \(\preceq \). SIGNATURE TITLE Regulatory Compliance Technician DATE 2-13-06 Type or print name Stormi Davis E-mail address: stormid@ypcnm.com Telephone No. 505-748-1471 For State Use Only APPROVED BY: TITLE REGULATIVE NOTABLE MANIDATE		No Color
8) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 3494-3394'. — 7AG 9) RIH w/wireline and shoot squeeze holes @ 2724'. 10) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 2724-2624'. — 7AG 11) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 2724-2624'. — 7AG 11) RIH w/wireline and shoot squeeze holes @ 495'. 12) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 495-395'. — 7AG 13) RIH w/wireline and shoot squeeze holes @ 60'. 14) Circulate 15 sx cement in and out of casing from surface to 60'. 15) Cut off wellhead. Install marker. Clean location. (Proposed Schematic Attached) I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or below-grade tank has been/will be constructed of closed according to NMOCD guidelines —, a general permit — or an (attached) alternative OCD-approved plan —. SIGNATURE — TITLE Regulatory Compliance Technician — DATE 2-13-06 Type or print name — Stormi Davis — E-mail address: stormid@ypcnm.com — Telephone No. 505-748-1471 For State Use Only APPROVED BY: — TITLE — REPUBLIATIVE ILATAPE MADIDATE	OF KIH W/IIIDIDG AND DACKEFAND SEFFOU DIDE COUSSEIL AND OULD CASIDE 42.30-41.00 . T	ag plug.
10) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 2724-2624'. TA 6 11) RIH w/wireline and shoot squeeze holes @ 495'. 12) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 495-395'. TA 6 13) RIH w/wireline and shoot squeeze holes @ 60'. 14) Circulate 15 sx cement in and out of casing from surface to 60'. 15) Cut off wellhead. Install marker. Clean location. (Proposed Schematic Attached) I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or belowgrade tank has been/will be constructed of closed according to NMOCD guidelines , a general permit or an (attached) alternative OCD-approved plan. SIGNATURE TITLE Regulatory Compliance Technician DATE 2-13-06 Type or print name Stormi Davis E-mail address: stormid@ypcnm.com Telephone No. 505-748-1471 For State Use Only APPROVED BY: TITLE REPUSENTATIVE II/STAPP MANIDATE	7) RIH w/wireline and shoot squeeze holes @ 3494'.	a dile
11) RIH w/wireline and shoot squeeze holes @ 495'. 12) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 495-395'. TAGE 13) RIH w/wireline and shoot squeeze holes @ 60'. 14) Circulate 15 sx cement in and out of casing from surface to 60'. 15) Cut off wellhead. Install marker. Clean location. (Proposed Schematic Attached) I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or below-grade tank has been/will be constructed of closed according to NMOCD guidelines , a general permit or an (attached) alternative OCD-approved plan . SIGNATURE TITLE Regulatory Compliance Technician DATE 2-13-06 Type or print name Stormi Davis E-mail address: stormid@ypcnm.com Telephone No. 505-748-1471 For State Use Only APPROVED BY: TITLE REPRESENTATIVE BASE MAN DATE	 7) RIH w/wireline and shoot squeeze holes @ 3494'. 8) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 3494-3394'. 	a dile
12) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 495-395'. TA 13) RIH w/wireline and shoot squeeze holes @ 60'. 14) Circulate 15 sx cement in and out of casing from surface to 60'. 15) Cut off wellhead. Install marker. Clean location. (Proposed Schematic Attached) I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or below-grade tank has been/will be constructed of closed according to NMOCD guidelines, a general permit or an (attached) alternative OCD-approved plan SIGNATURE	 7) RIH w/wireline and shoot squeeze holes @ 3494'. 8) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 3494-3394'. 9) RIH w/wireline and shoot squeeze holes @ 2724'. 	TAG
13) RIH w/wireline and shoot squeeze holes @ 60'. 14) Circulate 15 sx cement in and out of casing from surface to 60'. 15) Cut off wellhead. Install marker. Clean location. (Proposed Schematic Attached) I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or belowgrade tank has been/will be constructed of closed according to NMOCD guidelines, a general permit or an (attached) alternative OCD-approved plan SIGNATURE	 7) RIH w/wireline and shoot squeeze holes @ 3494'. 8) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 3494-3394'. 9) RIH w/wireline and shoot squeeze holes @ 2724'. 10) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 2724-2624'. 	TAG
Type or print name Stormi Davis E-mail address: stormid@ypcnm.com Telephone No. 505-748-1471 For State Use Only APPROVED BY: TITLE Regulatory Compliance Title No. 505-748-1471	7) RIH w/wireline and shoot squeeze holes @ 3494'. 8) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 3494-3394'. 9) RIH w/wireline and shoot squeeze holes @ 2724'. 10) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 2724-2624'. 11) RIH w/wireline and shoot squeeze holes @ 495'.	TAG TAG
I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or below-grade tank has been/will be constructed of closed according to NMOCD guidelines □, a general permit □ or an (attached) alternative OCD-approved plan □. SIGNATURE TITLE Regulatory Compliance Technician DATE 2-13-06 Type or print name Stormi Davis □ E-mail address: stormid@ypcnm.com □ Telephone No. 505-748-1471 For State Use Only APPROVED BY: □ TITLE □ REPRESENTATIVE BYSTAFF MADIDATE	7) RIH w/wireline and shoot squeeze holes @ 3494'. 8) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 3494-3394'. — 9) RIH w/wireline and shoot squeeze holes @ 2724'. 10) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 2724-2624'. " 11) RIH w/wireline and shoot squeeze holes @ 495'. 12) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 495-395'. " 13) RIH w/wireline and shoot squeeze holes @ 60'.	TAG TAG
TITLE Regulatory Compliance Technician DATE 2-13-06 Type or print name Stormi Davis E-mail address: stormid@ypcnm.com Telephone No. 505-748-1471 For State Use Only APPROVED BY: TITLE REGULATIVE N/STAFF MADIDATE	7) RIH w/wireline and shoot squeeze holes @ 3494'. 8) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 3494-3394'. — 9) RIH w/wireline and shoot squeeze holes @ 2724'. 10) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 2724-2624'. " 11) RIH w/wireline and shoot squeeze holes @ 495'. 12) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 495-395'. " 13) RIH w/wireline and shoot squeeze holes @ 60'. 14) Circulate 15 sx cement in and out of casing from surface to 60'.	TAG TAG
TITLE Regulatory Compliance Technician DATE 2-13-06 Type or print name Stormi Davis E-mail address: stormid@ypcnm.com Telephone No. 505-748-1471 For State Use Only APPROVED BY: TITLE REGULATIVE BYSTAFF MADIDATE	7) RIH w/wireline and shoot squeeze holes @ 3494'. 8) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 3494-3394'. 9) RIH w/wireline and shoot squeeze holes @ 2724'. 10) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 2724-2624'. 11) RIH w/wireline and shoot squeeze holes @ 495'. 12) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 495-395'. 13) RIH w/wireline and shoot squeeze holes @ 60'. 14) Circulate 15 sx cement in and out of casing from surface to 60'. 15) Cut off wellhead. Install marker. Clean location.	TAG TAG TAG (Proposed Schematic Attached)
Type or print name Stormi Davis E-mail address: stormid@ypcnm.com Telephone No. 505-748-1471 For State Use Only APPROVED BY: TITLE FEELD REPRESENTATIVE N/STAFF MADIDATE	7) RIH w/wireline and shoot squeeze holes @ 3494'. 8) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 3494-3394'.— 9) RIH w/wireline and shoot squeeze holes @ 2724'. 10) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 2724-2624'. " 11) RIH w/wireline and shoot squeeze holes @ 495'. 12) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 495-395'. 13) RIH w/wireline and shoot squeeze holes @ 60'. 14) Circulate 15 sx cement in and out of casing from surface to 60'. 15) Cut off wellhead. Install marker. Clean location. I hereby certify that the information above is true and complete to the best of my knowled.	TAG TAG (Proposed Schematic Attached) ge and belief. I further certify that any pit or below-
Type or print name Stormi Davis E-mail address: stormid@ypcnm.com Telephone No. 505-748-1471 For State Use Only APPROVED BY: TITLE FEELD REPRESENTATIVE IVSTAFF MADIDATE	7) RIH w/wireline and shoot squeeze holes @ 3494'. 8) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 3494-3394'.— 9) RIH w/wireline and shoot squeeze holes @ 2724'. 10) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 2724-2624'. " 11) RIH w/wireline and shoot squeeze holes @ 495'. 12) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 495-395'. 13) RIH w/wireline and shoot squeeze holes @ 60'. 14) Circulate 15 sx cement in and out of casing from surface to 60'. 15) Cut off wellhead. Install marker. Clean location. I hereby certify that the information above is true and complete to the best of my knowled.	TAG TAG (Proposed Schematic Attached) ge and belief. I further certify that any pit or below-
APPROVED BY: TITLE FELD REPRESENTATIVE NISTAME MADIDATE	7) RIH w/wireline and shoot squeeze holes @ 3494'. 8) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 3494-3394'.— 9) RIH w/wireline and shoot squeeze holes @ 2724'. 10) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 2724-2624'. " 11) RIH w/wireline and shoot squeeze holes @ 495'. 12) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 495-395'. " 13) RIH w/wireline and shoot squeeze holes @ 60'. 14) Circulate 15 sx cement in and out of casing from surface to 60'. 15) Cut off wellhead. Install marker. Clean location. I hereby certify that the information above is true and complete to the best of my knowled grade tank has been/will be constructed offclosed according to NMOCD guidelines \(\preceq \), a general permit \(\preceq \)	TAG TAG (Proposed Schematic Attached) ge and belief. I further certify that any pit or below- or an (attached) alternative OCD-approved plan
	7) RIH w/wireline and shoot squeeze holes @ 3494'. 8) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 3494-3394'. 9) RIH w/wireline and shoot squeeze holes @ 2724'. 10) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 2724-2624'. 11) RIH w/wireline and shoot squeeze holes @ 495'. 12) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 495-395'. 13) RIH w/wireline and shoot squeeze holes @ 60'. 14) Circulate 15 sx cement in and out of casing from surface to 60'. 15) Cut off wellhead. Install marker. Clean location. I hereby certify that the information above is true and complete to the best of my knowled grade tank has been/will be constructed of closed according to NMOCD guidelines \(\preceq \), a general permit \(\preceq \) SIGNATURE TITLE Regulatory Compliance.	TAG TAG (Proposed Schematic Attached) ge and belief. I further certify that any pit or below- l or an (attached) alternative OCD-approved plan ance Technician DATE 2-13-06
	7) RIH w/wireline and shoot squeeze holes @ 3494'. 8) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 3494-3394'. 9) RIH w/wireline and shoot squeeze holes @ 2724'. 10) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 2724-2624'. 11) RIH w/wireline and shoot squeeze holes @ 495'. 12) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 495-395'. 13) RIH w/wireline and shoot squeeze holes @ 60'. 14) Circulate 15 sx cement in and out of casing from surface to 60'. 15) Cut off wellhead. Install marker. Clean location. I hereby certify that the information above is true and complete to the best of my knowled grade tank has been/will be constructed of closed according to NMOCD guidelines \(\text{\	TAG TAG (Proposed Schematic Attached) ge and belief. I further certify that any pit or below- l or an (attached) alternative OCD-approved plan □. ance Technician DATE 2-13-06 n.com Telephone No. 505-748-1471
	7) RIH w/wireline and shoot squeeze holes @ 3494'. 8) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 3494-3394'. 9) RIH w/wireline and shoot squeeze holes @ 2724'. 10) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 2724-2624'. 11) RIH w/wireline and shoot squeeze holes @ 495'. 12) RIH w/tubing and packer and set 100' plug (30 sx) in and out of casing 495-395'. 13) RIH w/wireline and shoot squeeze holes @ 60'. 14) Circulate 15 sx cement in and out of casing from surface to 60'. 15) Cut off wellhead. Install marker. Clean location. I hereby certify that the information above is true and complete to the best of my knowled grade tank has been/will be constructed of closed according to NMOCD guidelines, a general permit	TAG TAG (Proposed Schematic Attached) ge and belief. I further certify that any pit or below- l or an (attached) alternative OCD-approved plan □. ance Technician DATE 2-13-06 n.com Telephone No. 505-748-1471

