

Submit 1 Copy To Appropriate District Office
 District I - (575) 393-6161
 1625 N. French Dr., Hobbs, NM 88240
 District II - (575) 748-1283
 811 S. First St., Artesia, NM 88210
 District III - (505) 334-6178
 1000 Rio Brazos Rd., Aztec, NM 87410
 District IV - (505) 476-3460
 1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
 Energy, Minerals and Natural Resources

Form C-103
 Revised August 1, 2011

OIL CONSERVATION DIVISION
 1220 South St. Francis Dr.
 Santa Fe, NM 87505

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)		WELL API NO. 30-015-05592
1. Type of Well: Oil Well <input checked="" type="checkbox"/> Gas Well <input type="checkbox"/> Other <input type="checkbox"/>		5. Indicate Type of Lease FEDERAL STATE FEE
2. Name of Operator State of New Mexico formerly Tom R. Cone		6. State Oil & Gas Lease No.
3. Address of Operator 1625 N. French Drive Hobbs, NM 88240		7. Lease Name or Unit Agreement Name North Shugart Queen Unit
4. Well Location Unit Letter <u>D</u> ; <u>990</u> feet from the <u>North</u> line and <u>330</u> feet from the <u>West</u> line Section <u>21</u> Township <u>18S</u> Range <u>31E</u> NMPM <u>Eddy</u> County		8. Well Number <u>002</u>
11. Elevation (Show whether DR, RKB, RT, GR, etc.)		9. OGRID Number 188152
10. Pool name or Wildcat Shugart; Yates-7RVS-QU-GB		10. Pool name or Wildcat Shugart; Yates-7RVS-QU-GB

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK <input type="checkbox"/> PLUG AND ABANDON <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> CHANGE PLANS <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> MULTIPLE COMPL <input type="checkbox"/> DOWNHOLE COMMINGLE <input type="checkbox"/>		SUBSEQUENT REPORT OF: REMEDIAL WORK <input type="checkbox"/> ALTERING CASING <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> P AND A <input type="checkbox"/> CASING/CEMENT JOB <input type="checkbox"/>	
OTHER: <input type="checkbox"/>		OTHER: <input type="checkbox"/>	

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

HOBBS OCD

JAN 02 2019

SEE ATTACHED

RECEIVED

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE _____ TITLE _____ DATE _____

Type or print name _____ E-mail address: _____ PHONE: _____

For State Use Only

APPROVED BY: Mah Whitman TITLE P.E.S. DATE 01/02/2019

Conditions of Approval (if any):

Plugging Report
NSQU #2
API 30-015-05592

12/20/2018 Repair entry to location off of the county road. Cleared location and moved in the rig. Laid down 125 ¾" rods. SION

12/21/2018 Dug out cellar and replace connections on the surface head. Installed BOP and worked the tubing free. Laid down 101 jts 2 3/8" tubing. Made gauge ring run and could not get past 556'. Moved in work string. Picked up scraper and RIH to 3120'. POOH and shut down for the Christmas holiday.

12/26/2018 Set CIBP at 3102'. Circulated MLF and spotted 25 sx cement on top of CIBP. POOH and pick up packer and set at 125'. Pressured up to 500# below the packer. Test good. Perforated casing at 1950'. Well started flowing water. RIH with packer to squeeze. Packer would not set. POOH with packer. There was metal trash in the packer that was preventing it from setting. The rubber was also cut. RIH with another packer and set at 1560'. Squeezed perfs with 45 sx cement. 1350# ISP. Shut in and shut down to WOC.

~~12/27/2018~~ Opened tubing and bled off pressure. Released packer and tagged cement at 1797'. Perforated at 813'. Established circulation and pumped cement down the 4 ½" casing to the perfs at 813' and up the annulus to surface. Took 210 sx. Rigged down and cut off wellhead. Filled up both strings of casing to surface with 5 sx cement. Installed below ground marker. Cut of anchors, cleaned the pit and cleared location.