Cubmit 1 Comu To Annonanista District				-	G 100	
Submit 1 Copy To Appropriate District Office	State of New Mexic	Form C-103				
. District I – (575) 393-6161	Energy, Minerals and Natural	Revised August 1, 2011				
1625 N. French Dr., Hobbs, NM <b>882</b> 40	8		WELL API NO.	•		
District II – (575) 748-1283						
811 S. First St., Artesia, NM 88210	OIL CONSERVATION D	30-025-20228				
District III – (505) 334-6178	1220 South St. Francis	5. Indicate Type of Lease				
1000 Rio Brazos Rd., Aztec NM 874 6 District IV - (505) 476-3460	Santa Fe, NM 8750	STATE XX FEE				
1220 S. St. Francis Dr., Sama Fe, NY 87505	S S	6. State Oil & Gas Lease No.				
87505						
	B-3196					
SUNDRY NOTE	7. Lease Name or Unit Agreement Name					
(DO NOT USE THIS FORM FOR PROPOS						
DIFFERENT RESERVOIR. USE "ARECIC	State 35 H					
PROPOSALS.) 1. Type of Well: Oil Well XX Gas Well Other			8. Well Number 009			
1. Type of Well: Oil Well XX	8. Well Nulliber 007					
2. Name of Operator		9. OGRID Number				
McGowan Working Partners, Inc.	220397					
3. Address of Operator	10. Pool name or Wildcat					
PO Box 55809, Jackson, MS 392	Vacuum; Abo North					
	.90-3809					
4. Well Location						
Unit Letter H:	_1980feet from theNorth	line and	_460feet fro	om theEast	_line	
Section 35	Township 17S Rat	nge 34E	NMPM	Lea County		
	11. Elevation (Show whether DR, RK	(B. RT. GR. etc.)				
				an San tanàna amin'ny faritr'ora dia mampi	ere a constru	
		· · · · · ·	Television		in a second distriction of the second second	
12. Check A	ppropriate Box to Indicate Natu	re of Notice, I	Report or Othe	er Data	1 m	
			-		1 8:	
NOTICE OF IN	TENTION TO:	SUB	SEQUENT RI	EPORT OF:	- •	
PERFORM REMEDIAL WORK		EMEDIAL WORK		ALTERING CAS	SING 🗖	
				P AND A	XX	
			· · · · · · · · · · · · · · · · · · ·			
PULL OR ALTER CASING		ASING/CEMENT	JOR []		INC	

OTHER:

DOWNHOLE COMMINGLE

 Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

OTHER:

П

## **SEE ATTACHED**

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

	11//					
SIGNATURE	1/7	TITLE	Agent	_DATE	6/24/2018	
Type or print name	John R Stearns, Jr.	E-mail address:	bobbystearns1@yahoo.com	PHONE:	575-760-2482	

For State Use Only APPROVED BY: Kenny Jurner TITLE Compliance Officer A DATE 2-5-19 Conditions of Approval (if any):

## Plugging Report State 35 H #9 API: 30-025-20228

6/12/2018 Move rig to location.

6/13/2018 Rig up, dig out cellar and install BOP. RIH with wireline and tagged existing CIBP at 8927'. Procedures showed a cement retainer at 5500'. Called OCD in Hobbs. Got permission to spot first plug at 5800'. Picked up workstring and RIH to 5807'. SION.

6/14/2018 Circulated MLF and tested casing to 500#. Casing was good. Spotted 25 sx cement with CaCl at 5807'. POOH and WOC. Tagged cement at 5472'. POOH and perforated casing at 4990'. RIH with packer and pressured up on perfs to 500#. Could not pump into perfs. POOH with packer and RIH with tubing to 5059' and spot 25 sx cement. POOH and SION.

6/15/2018 Tagged cement at 4857'. POOH and perforated casing at 2853'. Set packer at 2498' and established circulation up the intermediate head. Squeezed perfs with 65 sx cement with CaCl. WOC and tagged cement at 2691'. Perforated casing at 1572'. Squeezed perfs with 65 sx cement. Left packer set and SION.

6/19/2018 Tagged cement at 1418'. Laid down remaining tubing and perforated at 435'. Pumped down 5 ½" casing to perfs and established circulation up the 8 5/8" casing. Closed off the 8 5/8" casing and tried to get circulation up the 11 ¾" surface casing. Could pump into the well but no circulation up the surface head. Pumped cement down the 5 ½" casing and up the 5 ½" X 8 5/8" annulus to surface. Took 140 sx to get cement to surface. Closed the 8 5/8" wellhead valve and pumped another 25 sx cement into the wellbore. Rigged down and cut off wellhead. Filled up all three strings of casing to surface with 15 sx cement. Installed marker and cut off anchors. Cleaned the pit and cleared the location.

